



**REGAL®**

— Follow no one.



**OWNER'S MANUAL  
24-27 FasDeck**



## OWNER'S MANUAL

24/27  
FasDeck



## INTRODUCTION

Your Regal Owner's Manual	
General Information	
Regal Warranty	

## 1 SAFETY ON BOARD

Safety Labels	1-1
General Boating Safety	1-3
Required Safety Equipment	1-7
Fire Extinguishers	1-10
Visual Distress Signals	1-12
Sound Protecting Devices	1-15
Navigation Lights	1-15
Marine Sanitation Devices	1-17
Exhaust & Carbon Monoxide	1-21
Boating Under The Influence	1-25
Boating Accidents	1-27
Water Sports	1-29
Weather & Water Conditions	1-34

## 2 RULES OF THE ROAD

Navigation Rules Defined	2-1
Navigation Rules	2-2
Night Running	2-9
Bridge Clearance	2-10

## 3 ENGINES & CONTROLS

Engines	3-1
Propulsion	3-4
Controls	3-6
Remote Control	3-16

## 4 SYSTEMS

Electrical	4-1
Fuel	4-12
Water	4-16
Waste	4-17

## 5 VESSEL OPERATION

Getting Underway	5-1
Fueling	5-3
Starting & Stopping	5-6
Steering	5-8
Fenders	5-10
Dock Line Basics	5-11
Steps To Stern Drive Docking	5-14
Stern Drive Maneuvering	5-16
Trim Angle	5-19
Anchoring	5-24
Emergencies	5-28
First Aid	5-29
Hypothermia	5-30
Environmental Awareness	5-31

# *Table Of Contents*

---

## **6 EQUIPMENT OPERATION    7 COSMETIC CARE &**

Anchor Windlass	6-2
Automatic Fire Ext. System	6-3
Battery	6-7
Battery Switch	6-8
Bilge Pump	6-10
Bow Filler Cushions	6-11
Bow Scuff Plate	6-12
Bow Walk-Through Doors	6-13
Canvas	6-14
Cockpit Carpet	6-20
Cockpit Table	6-21
Cockpit Refreshment Center	6-22
Drain Plug	6-23
Depth Finder	6-24
Engine Hatch	6-27
Fresh Water System	6-28
Gas Vapor Detector	6-30
Gray Water System	6-33
Ladders	6-34
Lighting	6-36
Power Tower	6-39
Regal Vue	6-43
Seating	6-68
Sirius Satellite Radio	6-73
Ski Tow Pylon	6-74
Speed Control Devices	6-75
Stereo	6-76
Swim Platform	6-89
Toilet	6-91
Trailer Switch (Transom)	6-99
Through-Hull Exhaust	6-100
Washdowns	6-101
Windshield	6-102
Wide-Angle Mirror	6-113

## **MAINTENANCE**

Cosmetic Care	7-1
Maintenance	7-11

## **8 TROUBLESHOOTING**

Diagnostic Charts	8-1
-------------------	-----

## **9 STORAGE/WINTERIZATION**

Decommissioning Checklist	9-2
Recommissioning Checklist	9-5

## **10 TRAILERING**

Before Towing	10-1
Driving	10-6
Launching	10-7
Loading Boat	10-9

## **11 GLOSSARY & INDEX**

Glossary	11-1
Index	11-5

## **12 TECHNICAL INFORMATION**





## *Welcome To Regal*

---

*Dear Regal Owner,*

*I know I speak for everyone at Regal when I welcome you to the ever-growing family of Regal boat owners. You've chosen a craft that is recognized worldwide for its standard of excellence. Each step in construction has been carefully scrutinized to assure comfort, performance, reliability and safety for both your passengers and yourself.*

*Your boat is certified by the National Marine Manufacturers Association. It also complies with the applicable standards set by the United States Coast Guard and the American Boat and Yacht Council. Your Regal boat was built with the same attention to detail and quality of construction that we would expect in a boat we would purchase ourselves.*

*Whether you're a veteran boater or a newcomer, we strongly urge you to read this boat owner's manual thoroughly. Familiarize yourself with the various components of your boat, and heed the safety precautions noted herein.*

*If you have questions that are not covered in this manual, please consult your authorized Regal dealer for assistance or phone the Regal factory at 407-851-4360.*

*Thank you, and welcome to the "World of Regal!"*

*Duane Kuck*

*President*



## *Mission Statement*

---

*With God's help*  
*and a steadfast commitment to integrity,*  
*we will develop a team*  
*of exceptional people and relationships*  
*to provide*  
*exceptional customer satisfaction.*



## *Introduction*

---

THIS PAGE IS LEFT INTENTIONALLY BLANK



# *Introduction*

Boating is becoming more popular every year. There are numerous types of recreational vessels on our waterways today involved in an every growing number of activities. Therefore, as a new boat owner it is of the highest priority to learn about general boating practices before operating your craft.

Your Regal dealer will answer many questions and provide valuable “hands on” information during the completion of the new boat delivery process. In addition, your dealer has received special factory training on the product line and his services should be employed to solve technical problems and periodic maintenance beyond the scope of this manual. Also, your Regal dealer carries a line of factory approved parts and accessories.

Your Regal dealer can provide information regarding national training organizations such as the U.S. Power Squadron and United States Coast Guard Auxiliary. Along with other organizations and literature, they can help build your “boating savvy” by developing the necessary skills and awareness to be a safe and competent skipper. Your local library can also help in providing recommended boating literature such as Chapman Piloting (Seamanship & Boat Handling by Elbert S. Maloney).

Remember, the waterways can change from normal to abnormal conditions in a heartbeat. Knowing how to react quickly comes from experience and knowledge which can be gained through boating education.

Welcome aboard!



## *Introduction*

---

### **YOUR REGAL OWNER'S MANUAL**

Your Regal owner's manual has been developed to assist you in operating your vessel with safety and pleasure. Be sure to read and become familiar with the contents before operating your craft. Your owner's manual has been divided into general chapters to assist you in becoming more knowledgeable with your Regal boat. Also, we have added a special technical drawing chapter which can be valuable in maintenance and troubleshooting. This manual is not intended to be a complete source of boating maintenance, boat handling techniques, boating safety or seamanship. These skills require education and experience levels beyond this manual.

**In keeping with its commitment to continued improvement, Regal notes that all drawings, specifications, models, standard and optional equipment referred to in this manual are subject to change without notice.**

### **OWNER'S INFORMATION PACKET**

Regal has provided an information pouch aboard the vessel. Read and become familiar with the materials. This packet contains valuable literature on your propulsion package, standard and optional equipment, systems and various care and cleaning instructions. Be sure to store the information pouch in a clean dry area for quick reference.

### **GENERAL INFORMATION**


#### **Hull Identification Number (HIN) \_\_\_\_\_**

The United States Coast Guard has established a universal system of numerically identifying vessels by using a hull identification number or "HIN." This number identifies your Regal boat's model, hull number, month and year of manufacture. The HIN is found on your boat's starboard side, just below the rub rail in the transom area.



The HIN consists of 12 alpha or numeric characters.

It is recommended that you locate and write down the HIN for future reference. It can be especially useful when ordering parts from your Regal dealer. A second HIN number is found in a hidden location. This second HIN is useful to authorities if for example the boat is stolen and the original transom HIN is modified or eliminated.



## Vessel Information Sheet

It is recommended that you fill out the information on the following page. It will supply vital statistics on your vessel. Make a copy of the data for safe keeping at home.

## Vessel Float Plan

Fill out the float plan on the following page before departing. Leave it with a responsible person who will notify the United States Coast Guard or local law enforcement authorities if you do not return as planned. If you change your plans be sure to notify this person. Make copies of the float plan and use one each time you go boating. This will help people know where to find you should you not return on schedule. Do not file the float plan with the United States Coast Guard.



## *Introduction*

---

### **VESSEL INFORMATION SHEET**

Owner: \_\_\_\_\_

Address: \_\_\_\_\_

City & State: \_\_\_\_\_

Home Phone: \_\_\_\_\_ Business Phone: \_\_\_\_\_

In Case Of Emergency Notify: \_\_\_\_\_

Address: \_\_\_\_\_

City: \_\_\_\_\_ State: \_\_\_\_\_

Phone: \_\_\_\_\_

Insurance Agent's Name: \_\_\_\_\_

Policy#: \_\_\_\_\_

USCG Phone: \_\_\_\_\_ Local Police: \_\_\_\_\_

Marina Phone: \_\_\_\_\_ Slip (Dock#): \_\_\_\_\_

Hull Serial #: RGM \_\_\_\_\_

Key #: \_\_\_\_\_ Engine Serial #: \_\_\_\_\_

Sterndrive Serial #: \_\_\_\_\_

Key #: \_\_\_\_\_ Cabin Door: (If Applicable) \_\_\_\_\_

Selling Dealer: \_\_\_\_\_

Address: \_\_\_\_\_

City & State: \_\_\_\_\_

Phone: \_\_\_\_\_

Servicing Dealer: \_\_\_\_\_

Address: \_\_\_\_\_

City & State: \_\_\_\_\_

Phone: \_\_\_\_\_



---

## FLOAT PLAN

Owner: \_\_\_\_\_ Safety Equipment Aboard:

Address: \_\_\_\_\_ ☐ Life Jackets

City & State: \_\_\_\_\_ ☐ First Aid Kit

Telephone#: \_\_\_\_\_ ☐ Flares

Cell Phone#: \_\_\_\_\_ ☐ Flashlight

☐ VHF Radio

Person Filing Report: \_\_\_\_\_ ☐ Anchor

Name: \_\_\_\_\_ ☐ Compass

Home Telephone#: \_\_\_\_\_ ☐ Food

Cell Phone #: \_\_\_\_\_ ☐ Water

Make Of Boat: \_\_\_\_\_ Destination: \_\_\_\_\_

Registration#: \_\_\_\_\_ Leave From: \_\_\_\_\_

Length: \_\_\_\_\_ Time Left: \_\_\_\_\_

Boat Name: \_\_\_\_\_ Going To: \_\_\_\_\_

Gel Color: \_\_\_\_\_ Fuel Level: 1/4, 1/2, 3/4, F

Trim Color: \_\_\_\_\_ Est. Time Of Arrival: \_\_\_\_\_

Inboard/Outboard: \_\_\_\_\_

Hull I.D.#: \_\_\_\_\_ Return: \_\_\_\_\_

Fuel Capacity: \_\_\_\_\_ Est. Time of Arrival: \_\_\_\_\_

If not back by \_\_\_\_ o'clock  
call Coast Guard

Other Information: \_\_\_\_\_

---

Name Of Person Aboard	Age	Address	Phone#
-----------------------	-----	---------	--------

_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____





### **LAUNCH & CRUISE CHECKLIST**

- ☐ Obtain a current weather report.
- ☐ Inspect the hull and propeller for damage.
- ☐ Check all electrical system switches for proper operation.
- ☐ If your boat has been in the water, run the bilge pump until the flow of water stops.
- ☐ If your boat has been out of the water, check to see that all bilge water has drained out. Install the drain plug.
- ☐ Check that all required safety equipment is on board and in good working condition.
- ☐ Check that all other equipment is on board such as mooring lines, first aid kit, tool kit and extra parts.
- ☐ Open engine compartment. Inspect for fuel odors and visible leaks in the fuel, oil, exhaust & power steering systems.
- ☐ Visually inspect engine for cracked hoses, defective belts, loose fasteners such as bolts, nuts and hose clamps.
- ☐ Check fuel level. Fuel tanks should be filled to near full capacity.
- ☐ Make sure all navigation charts, equipment and vessel registration paperwork are onboard.
- ☐ Check operation of bilge blower, steering system, navigation lights and horn.
- ☐ Make sure passengers and crew know how to operate safety equipment and react to an emergency.
- ☐ File a float plan with a responsible party ashore.



---

## SUGGESTED TOOLS, PARTS & GEAR

### SUGGESTED TOOLS

Allen Wrenches  
Jack Knife  
Phillips Screwdriver Set  
Slotted Screwdriver Set  
Regular Pliers  
Combination Wrench Set  
Ratchet & Socket Set  
Hammer  
Wire Crimpers  
Vise Grip Pliers  
Floating Flashlight  
Nut Driver Set  
Oil Filter Wrench  
Fuel Filter Wrench

### SPARE PARTS

Fuel Filter  
Spark Plugs  
Water Pump Belt  
Propellers  
Alternator Belt  
Anti-Siphon Set  
Propeller Nut & Hardware  
Penetrating Oil  
Extra Light Bulbs  
Extra Batteries  
Duct Tape  
Electrical Tape  
Power Steering Fluid  
Water Pump Impeller  
Spare Keys On Floater

### BASIC GEAR

Tie Lines  
Mooring Lines  
Dock Fenders  
First Aid Kit  
Boat Hook  
Foul Weather Gear  
VHF Radio, EPIRB, GPS, Cell Phone  
Charts & Plotting Instruments  
Emergency Water & Food  
Bailer Or Hand Pump  
Fire Extinguisher  
Personal Flotation Devices  
Anchor & Line  
Life Raft



## Introduction

### Capacity Plate

Close to the helm on Regal boats **up to 26' in length** is a **capacity** plate. A typical capacity plate is shown to the left below.

This plate represents manufacturers who participate in the National Marine Manufacturer's Association small boat certification program.

A similar **yacht certification plate for boats 26' and over** covers many of the above guidelines and others from ABYC into the yacht program. Your boat has been certified by NMMA approved inspectors to be in compliance with their system guidelines along with federal safety regulations. The driver of the craft must read and understand the plate information before operating the vessel.

The capacity plate data applies under normal conditions. **Be sure to read and abide by the capacity limits. Remember, the boat operator is responsible for the vessel and the safety of its passengers.**

Note the typical **capacity** plate information below:

- The plate states the maximum number of persons allowed on the boat.
- The total weight of persons, gear and other items under normal conditions that the boat is capable of carrying.
- Overloading, improper loading and weight distribution are well documented causes of accidents. Provide for an extra margin of safety in rough sea conditions.

TYPICAL EXAMPLES SHOWN





---

## **Owner's Registration & Systems Checklist**

---

Please note that your Regal boat requires the proper registration by your authorized Regal dealer. To initiate your warranty the dealer must complete the owner's registration form and systems checklist at the time of delivery. The owner must sign the paperwork to acknowledge that the dealer has reviewed the boat systems and warranty provisions with the owner. The owner should keep the original paperwork that features a temporary warranty registration. A Regal express limited warranty certificate containing all relevant boat and engine serial numbers will be sent after the factory receives the paperwork.

## **Dealer's Responsibility**

---

Your boat has undergone rigid quality assurance inspections before leaving the factory. However, your dealer has been trained to perform final pre-delivery checks and to service your Regal boat prior to your pick-up. Your dealer's responsibilities include:

- ◆ A complete orientation in the operation of your Regal boat, including matters relating to the safe operation of your craft.
- ◆ Completion and mailing of your boat registration warranty form to Regal.
- ◆ Warranties, registration materials, owner's manual, operation, installation and maintenance instructions for all auxiliary equipment supplied with or installed on your Regal boat.



## *Introduction*

---

### **Owner's Responsibility**

---

You are entitled to all the benefits and services outlined in your Regal boat warranty. However, you have certain responsibilities to ensure warranty satisfaction. These are:

- ◆ To read the warranty materials and understand them fully.
- ◆ To examine the boat in detail at the time of delivery.
- ◆ Apply the following: boating rules and regulations, safety equipment, environmental regulations, accident reports and warranty regulations terms and conditions.
- ◆ To read thoroughly all literature supplied with your boat, including this owner's manual and to follow the recommendations in the literature.
- ◆ To return the boat after the recommended hours of engine operation for the proper dealer service inspections.
- ◆ To provide proper maintenance and periodic servicing of your boat and equipment as set forth in the various manuals supplied.



## RUNABOUTS and CUDDY NEW BOAT DELIVERY CHECKLIST

REGAL MARINE INDUSTRIES  
2300 JETPORT DRIVE  
ORLANDO, FLORIDA 32809  
(407) 851-4360

### OWNER REGISTRATION INFORMATION

NAME \_\_\_\_\_ DEALER \_\_\_\_\_  
ADDRESS \_\_\_\_\_ HULL # \_\_\_\_\_  
CITY \_\_\_\_\_ STATE \_\_\_\_\_ ZIP \_\_\_\_\_ MODEL \_\_\_\_\_  
COUNTRY \_\_\_\_\_ PHONE # \_\_\_\_\_ EMAIL \_\_\_\_\_

**INSTRUCTIONS:** This checklist is designed to assist dealers in the delivery of a Regal Boat to a new owner. Review the location, operation and maintenance of each item noted below with the owner and acknowledge this by checking the appropriate boxes. Indicate if item is not applicable with "NA". This form must be completed and signed by the dealer's representative and the customer to acknowledge proper receipt of the boat. The warranty will not be activated until a fully completed and signed copy has been received by Regal Marine.

#### A. NEW BOAT INFORMATION

DEALER OWNER

1. Review Regal's warranty \_\_\_\_\_
2. Review Engine warranty \_\_\_\_\_
3. Review Regal's owner manual \_\_\_\_\_
4. Review owner's package \_\_\_\_\_
5. Review dealer's service procedures \_\_\_\_\_
6. Review owner's service responsibilities \_\_\_\_\_

#### B. CABIN (IF APP)

DEALER OWNER

1. Location of all storage areas \_\_\_\_\_
2. Cabin lighting \_\_\_\_\_
3. Deck hatch \_\_\_\_\_
4. Port hole \_\_\_\_\_
5. Carbon monoxide detector \_\_\_\_\_
6. Dinette table set up \_\_\_\_\_
7. Cabin cushions set up \_\_\_\_\_
8. Electrical panel \_\_\_\_\_
9. Toilet / head \_\_\_\_\_
10. Water system \_\_\_\_\_

#### C. COCKPIT

DEALER OWNER

1. Swim ladder \_\_\_\_\_
2. Transom shower \_\_\_\_\_
3. Cockpit seating set up \_\_\_\_\_
4. Engine hatch operation \_\_\_\_\_
5. Cockpit storage areas \_\_\_\_\_
6. Refreshment center \_\_\_\_\_
7. Fishing package \_\_\_\_\_

#### D. INSTRUMENTATION

DEALER OWNER

1. Function of all gauges \_\_\_\_\_
2. Function of all switches \_\_\_\_\_
3. Throttle & shifter \_\_\_\_\_
4. Steering \_\_\_\_\_
5. Ignition \_\_\_\_\_
6. Operation of all optional electronics \_\_\_\_\_

#### E. ENGINE ROOM

DEALER OWNER

1. Engine fluid check \_\_\_\_\_
2. Trim pump location / fluid check \_\_\_\_\_
3. Battery I \_\_\_\_\_
4. Battery switch (may be in cockpit) \_\_\_\_\_
5. Bilge pump \_\_\_\_\_
6. Trim tab pump \_\_\_\_\_
7. Fire extinguisher \_\_\_\_\_
8. Blower \_\_\_\_\_

#### F. CANVAS

DEALER OWNER

1. Canvas set up \_\_\_\_\_
2. Canvas storage \_\_\_\_\_
3. Canvas care and cleaning \_\_\_\_\_

#### L. CARE & CLEANING

DEALER OWNER

1. Vinyl uph. care & cleaning \_\_\_\_\_
2. Windshield care & cleaning \_\_\_\_\_
3. Gel coat care & cleaning \_\_\_\_\_
4. Stainless steel hardware care & cleaning \_\_\_\_\_
5. Toilet system care & cleaning \_\_\_\_\_

**CAUTION:** This checklist is only intended to provide a general overview and does not represent all information necessary for proper operation of the boat. It is very important that persons operating this boat study the various manuals and materials provided with the boat and follow the recommendations contained in these materials. They contain important information including cautions and warnings that are vital to safe and enjoyable operation of the vessel. It is the owner's responsibility to insure that anyone operating the boat has been properly trained.

We have completed a review and orientation of the boat and its systems. The boat is in order and functioning properly with the exception of any items specifically noted above. This confirms that owner has received a copy of the Regal Limited Lifetime Warranty and engine manufacturer's warranty and agrees to these warranty terms and conditions.

DEALER REPRESENTATIVE

DELIVERY DATE

OWNER

DATE



## Introduction

### REGAL MARINE INDUSTRIES, INC. LIFETIME PLUS LIMITED HULL WARRANTY

Welcome to the Worldwide Family of Regal Owners! We are very pleased that you have chosen a Regal Powerboat!

This document is your Warranty Registration Certificate and Statement of Warranty. Please check the registration information section for accuracy. If this information is not correct or if you change your address at some future date, please notify us at the following address: Regal Marine Industries, Inc. Attention: Warranty Registrations, 2300 Jetport Drive, Orlando, Florida 32809

Please read the warranty carefully. It contains important information on Regal's claims procedures and your rights and obligations under this warranty.

**WHAT IS COVERED:** This Limited Warranty applies only to Regal boats beginning with model year 2012.

**LIFETIME LIMITED STRUCTURAL HULL WARRANTY:** Regal Marine Industries, Inc. warrants to the original retail purchaser of this boat if purchased from an authorized Regal dealer that the selling dealer or Regal will repair or replace the fiberglass hull if it is found to be structurally defective in material or workmanship for as long as the *original* retail purchaser owns the boat. For purposes of this warranty, the hull is defined as the single fiberglass casting which rests on the water. This limited warranty is subject to all limitations and conditions explained below.

**FIVE-YEAR TRANSFERABLE LIMITED STRUCTURAL HULL WARRANTY:** In addition to the Lifetime Limited Structural Hull Warranty, Regal offers a Transferable Five-Year Limited Structural Hull Warranty. Under the Five-Year Transferable Limited Structural Hull Warranty, Regal will repair or replace the fiberglass hull if it is found to be structurally defective in material or workmanship within the first (5) years after the date of delivery to the original retail purchaser. Any remaining term of this Five-Year Limited Hull Warranty may be transferred to a second owner if within 60 days of purchase, the new owner registers the transfer with Regal and pays the established warranty transfer fee. Contact Regal Customer Service at the above address for details.

**FIVE-YEAR LIMITED HULL BLISTER WARRANTY:** Regal will Warrant to the original retail purchaser, any underwater gelcoated surfaces of the hull against laminate blisters which occur as a result of defects in material or workmanship within (5) years of the date of delivery, provided that the original factory gelcoat surface has not been altered. Alternation would include but is not limited to damage repair; excessive sanding, scraping, sandblasting; or from improper surface preparation for application of a marine barrier coating or bottom paint, any of which shall void this Five-Year Limited Hull Blister Warranty. Regal Marine shall repair or cause to be repaired any covered laminate blisters based on the following prorated schedule. Less than two (2) years from delivery date - 100%, Two (2) to three (3) years from delivery date - 75%, Three (3) to four (4) years from delivery date - 50%, Four (4) to five (5) years from delivery date - 25%.

Reimbursement shall be limited to one repair, not to exceed (\$80.00) dollars per foot of boat length prior to prorating. Regals prior authorization for the method and cost of repair, must be obtained before repairs are commenced. All costs to transport the boat for repairs are the responsibility of the owner.



---

**LIMITED GENERAL WARRANTY:** In addition to above hull warranties, Regal warrants to the original purchaser of this boat if purchased from an authorized dealer that the dealer or Regal will repair or replace any parts found to be defective in materials or workmanship for a period of one (1) year from the date of delivery, subject to all limitations and conditions contained herein.

**LIMITED EXTERIOR FINISH WARRANTY:** Regal warrants that the selling dealer or Regal will repair cosmetic defects in the exterior gelcoated finish including cracks or crazing reported to Regal within 90 days from the date of delivery to the original purchaser, subject to all limitations and conditions contained herein. All warranty work is to be performed at a Regal dealership or other location authorized by a Regal Customer Service Manager after it is established to Regal's satisfaction that there is a defect in material or workmanship.

## **REGISTRATION INFORMATION:**

**CUSTOMER OBLIGATIONS:** The following are conditions precedent to the availability of any benefits under these limited warranties:

(a) The purchaser must sign and the dealer must submit to Regal the "OWNER REGISTRATION AND SYSTEMS CHECKLIST FORM within ten (10) days of the date of delivery and such information must be on file at Regal.

(b) The purchaser must first notify the dealer from whom the boat was purchased of any claim under this warranty within the applicable warranty period and within a reasonable period of time (not to exceed thirty (30) days) after the defect is or should have been discovered.

(c) Regal will not be responsible to repair or replace any part, (1) if the use of the boat is continued after the defect is or should have been discovered; and (2) if such continued use causes other or additional damage to the boat or component parts of the boat.

(d) Based on the dealer's knowledge of Regal's warranty policy and/or consultations with Regal, the dealer will accept the claim and arrange for appropriate repairs to be performed, or deny the claim if it is not within the warranty.

(e) The dealer will contact the Regal boat owner regarding instructions for delivery of boat or part for warranty repair if it is covered by the limited warranty.

**ALL COSTS TO TRANSPORT THE BOAT FOR REPAIRS ARE THE RESPONSIBILITY OF THE OWNER;**

(f) If the Regal boat owner believes a claim has been denied in error or the dealer has performed the warranty work in an unsatisfactory manner, the owner must notify Regal's Customer Service Department in writing at the address listed for further consideration. Regal will then review the claim and take appropriate follow-up action.





## Introduction

---

**WARRANTY EXCEPTIONS: THIS LIMITED WARRANTY** does not cover and the following are not warranted:

- (a) Engines, metal plating or finishes, windshield breakage, leakage, fading and deterioration of paints, canvas, upholstery and fabrics;
- (b) Gelcoat surfaces including, but not limited to, cracking, crazing, discoloration or blistering except as noted above;
- (c) Accessories and items which were not part of the boat when shipped from the Regal factory, and/or any damage caused thereby;
- (d) Damage caused by misuse, accident, galvanic corrosion, negligence, lack of proper maintenance, or improper trailering;
- (e) Any boat used for racing, or used for rental or commercial purposes;
- (f) Any boat operated contrary to any instructions furnished by Regal, or operated in violation of any federal, state, Coast Guard or other governmental agency laws, rules, or regulations;
- (g) The limited warranty is void if alterations have been made to the boat;
- (h) Transportation of boat or parts to and/or from the REGAL factory or service location;
- (i) Travel time or haul outs, loss of time or inconvenience;
- (j) Any published or announced catalog performance characteristics of speed, fuel and oil consumption, and static or dynamic transportation in the water;
- (k) Any boat that has been re-powered beyond Regal's power recommendations;
- (l) Boats damaged by accident and boats damaged while being loaded onto, transported upon or unloaded from trailers, cradles, or other devices used to place boats in water, remove boats from water or store or transport boats on or over land;
- (m) Water damage to, dry rot to, condensation to, or absorption by interior surfaces, wood structures or polyurethane foam; interior wood including, but not limited to, bleeding and/or discoloration as a result of condensation or moisture or water continually contacting the plywood causing staining to upholstery, carpet or other interior surfaces;
- (n) Costs or charges derived from inconveniences or loss of use, commercial or monetary loss due to time loss, and any other special, incidental or consequential damage of any kind or nature whatsoever.

**NO WAIVER OF THESE TERMS:** The terms, conditions, limitations and disclaimers contained herein cannot be waived except by the Customer Service Manager of Regal. Any such waiver must be in writing. Neither the dealer, nor the customer, nor any service, sales and/or warranty representative of Regal is authorized to waive and/or modify these conditions, limitations and/or disclaimers.

### **GENERAL PROVISIONS:**

**ALL GENERAL, SPECIAL, INDIRECT, INCIDENTAL AND/OR CONSEQUENTIAL DAMAGES ARE EXCLUDED FROM THIS WARRANTY AND ARE TOTALLY DISCLAIMED BY REGAL. IT IS THE INTEREST OF THE PARTIES THAT THE OWNER'S SOLE REMEDY IS THE REPAIR OR REPLACEMENT OF THE VESSEL OR ITS ALLEGEDLY DEFECTIVE COMPONENT PARTS AND THAT NO OTHER LEGAL OR EQUITABLE REMEDIES SHALL BE AVAILABLE TO SAID OWNER. SOME STATES DO NOT ALLOW THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE FOREGOING MAY NOT APPLY TO YOU.**



---

**THIS IS A LIMITED WARRANTY; REGAL MAKES NO WARRANTY, OTHER THAN CONTAINED HEREIN; TO THE EXTENT ALLOWED BY LAW ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARISING IN STATE LAW ARE EXPRESSLY EXCLUDED TO THE EXTENT ALLOWED BY LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY IS LIMITED TO THE PERIOD OF THIS LIMITED WARRANTY. ALL OBLIGATIONS OF REGAL ARE SPECIFICALLY SET FORTH HEREIN. REGAL DOES NOT AUTHORIZE ANY PERSON OR DEALER TO ASSUME ANY LIABILITY IN CONNECTION WITH REGAL BOATS.**

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Regal's obligation with respect to this warranty is limited to making repairs to or replacing the defective parts and no claim for breach of warranty shall be cause for cancellation or rescission of the contract or sale for any boat manufactured by REGAL MARINE INDUSTRIES, INC.

Regal will discharge its obligations under this warranty as rapidly as possible, but cannot guarantee any specific completion date due to the different nature of claims which may be made and services which may be required. Regal reserves the right to change or improve the design of its boats without obligation to modify any boat previously manufactured. This limited warranty gives you specific legal rights, and you may also have other rights which may vary from state to state. Regal shall in no way be responsible for any repairs not **PRE-AUTHORIZED** by a Regal Customer Service Manager or repairs performed by a repair shop not **PRE- AUTHORIZED** by a Regal Customer Service Manager.



# Safety On Board



Safety awareness can't be over emphasized. Safety on board needs to be the skipper's number one priority. In this manual you will find many safety precautions and symbols to identify safety related items. Heed all safety precaution information. Remember, the skipper is responsible for the safety of his passengers and crew.

## SAFETY LABELS

### Safety Precaution Definition

Safety precautions are stated as caution, warning and danger signal words. They are highlighted in this manual by font design and symbol usage. Also, a notice heading is included which provides operation and maintenance information but is not hazard-related.

	<b>DANGER</b>
IMMEDIATE HAZARDOUS SITUATION THAT, IF NOT AVOIDED, <b>WILL</b> RESULT IN DEATH OR SERIOUS INJURY.	
	<b>WARNING</b>
POTENTIALLY HAZARDOUS SITUATION THAT, IF NOT AVOIDED, <b>COULD</b> RESULT IN DEATH OR SERIOUS INJURY.	



## CHAPTER 1

---



### CAUTION

Indicates a potentially hazardous situation or unsafe practice that, if not avoided, **may** result in injury or property or product damage.

### NOTICE

General or specific information which is important to correct operation or maintenance, **but is not hazard related.**

### Precautionary Labels

---

Read and understand all safety labels affixed to your Regal boat. Most of the safety labels are found close to the helm, aft cockpit and or swim platform. The location of the labels may vary by model and the label list does not cover everything! Use common sense to analyze the result of an action on board your vessel. **Always think safety first!**

### NOTICE

DO NOT REMOVE OR COVER ANY  
PRECAUTIONARY LABELS.  
KEEP HARSH CHEMICALS AWAY FROM LABELS.  
IF A LABEL BECOMES ILLEGIBLE,  
CONTACT YOUR REGAL DEALER  
FOR ORDERING REPLACEMENTS.



## *Safety On Board*

---

### **GENERAL BOATING SAFETY**

We understand that you are eager to get your Regal boat on the water. However, we strongly suggest that you thoroughly familiarize yourself and friends or members of your family with safe boating practices before setting out.

Remember, that along with the freedom and exhilaration of boating comes the responsibility that you have for the safety of your passengers and other boaters who share the water with you.

Boating regulations vary from state to state. Check with your local state and local authorities for the regulations pertaining to your area.

□ Check with local weather stations, the U. S. Coast Guard, or weather station broadcasts for the latest conditions. Remember getting caught in severe weather is hazardous, Check weather conditions periodically while you are boating and before your outing. If you are forced to operate your boat in a storm condition, take common sense precautions; wear PFD's, store gear, reduce speed and head for safe refuge.

□ It is best to avoid operating your boat in foggy weather. When fog sets in, take bearings, log courses and speeds. You are required to emit a five second blast from your horn or whistle once a minute. Also, have your passengers wear PFD's and observe for oncoming vessels.

□ Operating in shallow water presents a number of hazards including sand bars and water levels influenced by tides. If the vessel strikes an underwater hazard, check for boat and engine damage. If the engine vibrates excessively after striking an underwater obstruction, it may indicate a damaged propeller. If you run aground, seek help by radio or flares.

□ Make sure your boat and equipment are in top condition. Do this by frequently inspecting the hull, engine and gear.



## CHAPTER 1

---

- You must provide a Coast Guard approved personal flotation device (PFD) for every person on board. These PFD's should be in good condition and easily accessible.
- Insist that non-swimmers and children on board wear a PFD at all times. Any time you encounter rough weather conditions, make sure everyone on board is wearing a PFD, including yourself. Instruct your passengers in how to put on their PFDs and be sure they know their storage location on the boat. Remember, in an emergency, a PFD that cannot be quickly located and worn is useless.
- Never allow anyone to sit anywhere on the boat not specifically designed a seat. While underway, **ALWAYS** insist passengers remain seated.
- **Use maximum caution when fueling.** Never allow any smoke or flame nearby while you are fueling. **ALWAYS** check for fuel leaks and fumes when fueling is completed.



### WARNING

GASOLINE VAPORS CAN EXPLODE.  
BEFORE STARTING ENGINE, OPERATE  
BLOWER 4 MINUTES AND CHECK  
ENGINE COMPARTMENT FOR GASOLINE FUMES  
OR LEAKS. RUN BLOWER MOTOR  
BELOW CRUISING SPEEDS.



### WARNING

USE OF ALCOHOL ENHANCED FUEL, OR ANY FUEL  
OTHER THAN GASOLINE,  
CAN LEAD TO DETERIORATION  
OF THE FUEL SYSTEM COMPONENTS AND/OR  
CAN RESULT IN FIRE AND POSSIBLE EXPLOSION!




## Safety On Board

---



❑ **Never drink and drive!** As captain, you are responsible for the safety of your passengers and yourself. Alcohol and boating can be a dangerous combination. **DO NOT** mix them. Alcohol impairs the boat operators ability to make conscious decisions and react to emergency situations quickly.

❑ **Never overload your boat!** An overloaded boat, or one with uneven weight distribution, can be difficult to steer.



❑ **Be certain there is enough fuel aboard for your cruising needs.** Include any reserve that might be needed should you change your plans due to weather or emergency. **Practice the “one-third rule:** (Use one-third of your fuel going out, one-third to return and keep one-third as a reserve).

❑ Check the weather before departure. Be particularly cautious of electrical storms and high winds.

❑ Have up-to-date charts aboard. You will need current charts of the area you’ll be cruising to stay on proper course. Charts can be obtained at your closest marine outlet or store or by contacting one of three federal government agencies.

❑ **File a float plan.** Leave details of your trip with someone responsible who will be remaining on shore. Include expected return, plus name and phone number of a contact person in case of emergency.

❑ Use care, courtesy and common sense when launching, docking or operating your boat.



## CHAPTER 1

---

- Learn and obey the “Rules of the Road”. A copy of the “Rules of the Road” can be obtained from the U. S. Coast Guard Auxiliary or local Power Squadron.
- In case of emergency: Know the international distress signals if you have a VHF radio aboard. The spoken word **“MAYDAY”** is the international signal of distress and is for emergency use only. Under no circumstances should this word be used, unless there is danger at hand.
- Posted speed limits, swimming areas, “no wake” zones and other restrictions should be red-flagged. They are so noted for a reason. Sensible boat use plus courtesy fosters enjoyable and safe boating.
- It is your responsibility to stay abreast of all federal, state and local rules, as some laws or regulations may change or be different from state to state. Contact your local boating agencies for updated information.
- We can not stress safety enough! Remember, there are no brakes on your boat, and the water current and wind velocity all affect your ability to respond. The driver must use caution at all times to maintain control of his vessel and especially to maintain a safe distance from other boats and obstacles.
- Always keep all safety gear in optimum condition. Pay special attention to attached tags and plates indicating expiration dates on equipment such as fire extinguishers, and personal flotation devices. Encourage a periodic maintenance check on all safety equipment. Contact your Regal dealer or marine professional for more information. Again, remember that the captain is responsible for his passengers and vessel.





### REQUIRED SAFETY EQUIPMENT

#### Personal Flotation Devices ---

All personal flotation devices (PFD's) must be Coast Guard approved, in good working condition, and must be the correct size for the wearer. All PFD's must be readily accessible. This means being able to wear them in a reasonable amount of time in case of an emergency (fire, boat sinking, etc.). They should not be stored or locked in closed areas. Also, make sure that all coverings are removed, such as plastic from any PFD's. Throwable devices such as a ring buoys need to be available for immediate deployment. A PFD should be worn at all times when your boat is operating on the water. A PFD may save your life, but it must be worn to do so.

**As minimum U. S. Coast Guard requirements all recreational boats must carry one type I, II, III, or V PFD (wearable) for each person aboard.** See the explanation following for each type. For type V to be counted they must be used according to the label instructions. In addition, all boats over 16' must carry one Type IV (throwable) PFD. Some states require that PFD's be worn by children of specific ages at all times. Check with state boating agencies for particular requirements in your state before taking children on the water.


Remember PFD's will not necessarily keep you from drowning, even though they are designed to keep a person from sinking. When purchasing PFD's make sure it safely fits the person wearing it. It is a good idea to test PFD's in a shallow pool before venturing on the water.

Refer to the USCG minimum equipment requirements at the end of this chapter. It is meant to be a guide only. Contact state and local agencies for additional equipment requirements. Remember as the captain of your vessel you are responsible for its safe operation.




## CHAPTER 1


---




- **TYPE I-** Also known as an offshore jacket, it provides the most buoyancy. It is a PFD for all waters and is especially useful in rough waters where rescue may encompass additional time. It is designed to turn most unconscious users in the water to a face-up position. Type I PFD is available in adult & child sizes.



- **TYPE II-** Also known as near-shore buoyant vest, it is recommended for calm, inland water where rescue time will be minimal. It will turn some unconscious people face-up in the water but not as numerous as Type I. They are available in adult, medium child, along with infant and small child sizes.



- **TYPE III-** Known as a flotation aid it is good for calm, inland water or where there is a chance for quick rescue. It is designed so wearers can place themselves in a face-up position in the water. The wearer may have to tilt their head back to avoid turning facedown in the water.




- **TYPE IV-** Intended for calm, inland water with heavy vessel traffic, where help is constantly present. It is designed to be thrown into the water for someone to grab on to and held until rescued. It should *not* be worn. Type IV includes ring buoys, buoyant cushions, and horseshoe buoys.



## Safety On Board

---



- **TYPE V-** This is the least bulky of all PFD's. It contains a small amount of inherent buoyancy, and an inflatable chamber. It is rated even to a Type I, II, or III PFD (as noted on the jacket label) when inflated. Hybrid PFD's must be worn to be acceptable equipment.

### Maintaining your PFD's

---

A PFD is only useful if it's well maintained. Always be aware of PFD age since it has a life expectancy like any other piece of equipment.

- √ Do a periodic operation check of all PFD's in shallow water.
- √ Be sure to air dry all PFD's after each use. Store in a dry, easily accessible location.
- √ Check periodically for broken zippers, frayed webbing, water soaked kapok bags, missing straps, and sewing that is undone.
- √ Clean each PFD with mild soap and water only. Again, let dry sufficiently before storing.
- √ Keep PFD's out of grease and oil since they can deteriorate the jacket inner and outer materials.
- √ Check any kapok-bagged jackets by squeezing. If jacket loses air the bag is defective and the PFD should be thrown away.
- √ Grab the cover with the fingers. If the cover material rips, the PFD is rotted and should be thrown away.
- √ If the kapok bag is hard the PFD should be discarded.



## CHAPTER 1

# FIRE EXTINGUISHERS

## General Information

Fire extinguishers are classified by a letter and numeric symbol. The letter references the type of fire the unit is designed to extinguish. For example, type B extinguishers commonly used on boats are designed to put out flammable liquids such as grease, oil and gasoline. The number indicates the general size of the extinguisher and minimum extinguishing agent weight.

FIRE EXTINGUISHER CONTENTS				
CLASS	FOAM IN GALS.	CO2 IN LBS.	DRY CHEM. IN LBS.	HALON IN LBS.
<b>B-I</b>	1.25	4	2	2.5
<b>B-II</b>	2.5	15	10	10

MINIMUM PORTABLE FIRE EXTINGUISHERS REQUIRED		
VESSEL LENGTH	NO FIXED SYSTEM	WITH FIXED SYSTEM
LESS THAN 26' 26' TO LESS THAN 40' 40' TO 65'	1 B-1 2 B-1 OR 1 B-II 3 B-1 OR 1 B-II	0 1 B-1 2 B-1 AND 1 B-1 OR 1 B-II



## Safety On Board

---

U. S. Coast Guard approved fire extinguishers are required on all Regal boats. Besides the minimum Coast Guard requirements always check state and local agencies for additional requirements and equipment.


Coast Guard approved extinguishers are hand-portable, either B-I or B-II classification.

U. S. Coast Guard approved hand-portable and semi-portable extinguishers contain a metal plate that shows the manufacturer's name and extinguisher type, capacity and operating instructions. They have a special marine type mounting bracket which keeps the extinguisher solidly mounted until needed. The extinguisher needs to be mounted in a readily accessible location but one out of being bumped by people while underway. All approved extinguishers need to have an indication gauge.

### USCG- Approved Fire Extinguisher Types & Features



The dry chemical agent is widely used because of its convenience and low cost. The extinguisher canister is filled with a white dry chemical powder along with a pressurized gas. It is a good idea to shake this type periodically because they tend to "pack" on the canister bottom.



The foam type uses a chemical foaming agent plus water and is best when used for fires involving flammable liquids- solvents, gasoline, oil, grease and various paints. It will work on fires involving rubber, plastics, cloth, wood, and paper. It leaves a messy residue. Not for electric fires.



The carbon dioxide unit uses CO<sub>2</sub> gas under high pressure, with a funnel discharge hose usually swivel mounted. This extinguisher leaves no residue and does not cause interior engine harm. To ensure workability, weigh the unit annually. A 10% max. wt. variance is allowed.



## CHAPTER 1

---

Another type of liquefied gas is used today in automatic fire extinguishing systems which is used on select models. The canister gas is colorless and odorless, heavier than air and sinks to the lower bilge to extinguish fires. Since the year 2000 ingredients for fire extinguishers have changed to a more environmental friendly formula. The canister needs to be weighed once a year. Automatic fire extinguishing systems feature a dash mount indicator.

## VISUAL DISTRESS SIGNALS

All vessels used on coastal waters, any of the Great Lakes, territorial seas, and those waters connected directly to them, up to point where a body of water is less than two miles wide, must have Coast Guard approved visual distress signals.

### Pyrotechnic Devices

---

Pyrotechnic visual distress signals must be Coast Guard approved, be ready for service and must be readily accessible. They all display a marking which is the service life, which must not have expired. A minimum of 3 devices are required for day and 3 devices for night. Some devices meet both day and night requirements. Pyrotechnic devices should be stored in a cool, dry location. Most of these devices can be purchased in an highly visible (orange) watertight container. Types of Coast Guard approved pyrotechnic distress signals and associated devices are:

- Pyrotechnic red flares, hand- held or aerial type.
- Pyrotechnic orange smoke, hand-held or floating type.
- Launchers for parachute flares or aerial red meteors.



## *Safety On Board*

---

All in all, each distress signal has certain pros and cons. There is no distress signal that is best under all situations. Pyrotechnics are recognized worldwide as superior distress signals. A downfall is they emit a very hot flame that can cause burns and or ignite flammable materials. Pistol launched and hand-held parachute flares operate consistent with firearms and therefore must be carefully handled. Check with local and state regulations since some of these device are considered firearms and are prohibited.

### **Non-Pyrotechnic Devices**

---

Non-pyrotechnic devices must all be in serviceable condition, readily accessible, and must be certified by the manufacturer to comply with Coast Guard standards. They include:

- Orange distress flag.
- Electric distress flag.

The distress flag is for day use only. It must be 3 x 3 or larger with a black square and ball on an orange background. It can be spotted when attached to a boat hook, long fishing rod, or paddle with the person waving the flag back and forth overhead.

The electric distress flag is for night use only flashing the international SOS distress signal (... \_ \_ ...).


Under Inland Navigation Rules, a high intensity white light that flashes at regular intervals from 50-70 times per minute is considered a distress signal.

Remember that regulations prohibit the display of visual distress signals on the water under any circumstances except when assistance is required to prevent immediate or potential danger to passengers on a vessel.




## CHAPTER 1

### INTERNATIONAL DISTRESS SIGNALS



BLACK SQUARE  
AND BALL ON  
ORANGE  
BACKGROUND




CODE FLAGS  
NOVEMBER AND  
CHARLIE



SQUARE  
FLAG AND  
BALL




PERSON  
WAVING  
ARMS



MORSE  
CODE  
S.O.S.



"MAYDAY"  
BY  
RADIO



ENSIGN  
UPSIDE  
DOWN



PARACHUTE  
RED  
FLAG



RED METEOR  
FLARES




SMOKE



FOG HORN  
SOUNDED  
CONTINUOUSLY



GUN FIRED  
AT 1-MINUTE  
INTERVALS



POSITION  
INDICATING  
RADIO BEACON



DYE MARKER  
(ANY COLOR)




HAND-HELD  
FLARE





## *Safety On Board*

### SOUND PRODUCING DEVICES



According to both Inland and International Rules, all boats **must** carry some way of producing an efficient sound signal. If your vessel is 12 meters (39' 4") or longer, a power whistle, power horn or bell must be carried. The bell must be 7 7/8" in diameter.

Boats less than 12 meters a horn or whistle is **recommended** to signal intentions or signal position. The sound signal made in all cases must be capable of a four or six second blast audible for one half mile. See the section discussing bridge and whistle signals for more information.

### RADIO COMMUNICATIONS

VHF radios are used for distress and ship to shore and ship to ship communications today. Learn the specialized messages such as **Mayday, Mayday, Mayday** is only used when life or vessel is in imminent danger.

### NAVIGATION LIGHTS

The U. S. Coast Guard requires recreational boats operating at night to display navigation lights between sunset and sunrise. Navigation lights help avoid collisions by improving the night visibility of vessels. Red and green directional lights, white stern lights, white masthead lights and white all-around lights must be displayed in specified positions, depending on boat size, and mode of operation. The configuration of visible lights tells and operator the size, direction of travel and means of propulsion (sail, power, rowing or at anchor) of another vessel. Larger boats are required to carry larger, brighter lights that are visible over longer distances.



## CHAPTER 1

# NAVIGATION LIGHT RULES




figure 1




figure 2




figure 3




figure 4




figure 5




figure 6





figure 7




*Sailboat using sail alone, less than 7 meters in length: If impractical to display lights in figure 4, 5 or 6, a single white light may be displayed in time to prevent a collision (figure 7c).*

**Row Boats or Paddle Boats**  
One all-round white light ready to display in time to prevent a collision (figure 7 a or b).

### Great Lakes

figure 7d



*Motorboat or sailboat using power on Great Lakes: The lighting arrangements in figure 7d may be used instead of the arrangements in figures 1 and 2.*

Location of lights on vessel	Visible Range		Degrees of arc lights
	Less than 12 m.	12 m. but less than 20 m.	
Masthead	2	3	225°
All-round	2	2	360°
Side lights	1	2	112.5° each color
Stern light	2	2	135°

### Boats less than 12 meters in length

*Motorboats or sailboats using power: The lighting arrangements to figure 1, 2 or 3 may be used.*

*Sailboat using sails alone: The lighting arrangements in figure 4, 5 or 6 may be used.*

### Boats 12 meters but less than 20 meters in length

*Motorboats or sailboats using power: The lighting arrangements to figure 1 or 2 may be used.*

*Sailboat using sails alone: The lighting arrangements in figure 4, 5 or 6 may be used.*

### Location of lights

Lights should be located as shown in the drawings.

The masthead light (forward white light in figures 1, 2 and 7d) must be at least one meter higher than the colored lights on a boat less than 12 meters in length and at least 2.5 meters above the gunwale on a boat 12 meters but less than 20 meters in length.

### Exceptions

*Motorboat or sailboat using power, built before December 24, 1980: The lighting arrangement in figure 1, 2 or 3 may be used. However, the arrangement in figure 3 is not acceptable on a boat that is 12 meters or longer on international waters.*



### **MARINE SANITATION DEVICES**

Recreational vessels under 65' with installed toilet facilities must have an operable marine sanitation device (MSD) on board. Vessels 65' and under may use Type I, II, or III MSD. All installed MSD's must be U.S. Coast Guard certified. The sanitation devices as used are labeled to show conformity to the regulations.

### **POLLUTION REGULATIONS**

The Federal Water Pollution Control Act prohibits the discharge of oil or hazardous substances which may be harmful into U. S. navigable waters. *Vessels 26' and over* must display a placard at least 5" x 8", made of durable material, fixed in a conspicuous machinery space location, stating the following:

#### **DISCHARGE OF OIL PROHIBITED**

THE FEDERAL WATER POLLUTION CONTROL ACT PROHIBITS THE DISCHARGE OF OIL OR OILY WASTE INTO OR UPON THE NAVIGABLE WATERS OF THE UNITED STATES, OR THE WATERS OF THE CONTIGUOUS ZONE, OR WHICH MAY AFFECT NATURAL RESOURCES BELONGING TO, APPERTAINING TO, OR UNDER THE EXCLUSIVE MANAGEMENT AUTHORITY OF THE UNITED STATES, IF SUCH DISCHARGE CAUSES A FILM OR DISCOLORATION OF THE SURFACE OF THE WATER OR CAUSES A SLUDGE OR EMULSION BENEATH THE SURFACE OF THE WATER. VIOLATORS ARE SUBJECT TO SUBSTANTIAL CIVIL PENALTIES AND/OR CRIMINAL SANCTIONS INCLUDING FINES AND IMPRISONMENT.



## CHAPTER 1

---

You must immediately notify the U. S. Coast Guard if your vessel discharges oil or hazardous substances in the water. Call toll free 800-424-8802. Report the following information: location, source, size, color, substances and time observed.

### Garbage

---

The Act to Prevent Pollution from Ships places limitations on the discharge of garbage from vessels. It is illegal to dump plastic trash anywhere in the ocean or navigable waters of the United States. Also, it is illegal to discharge garbage in the navigable waters of the United States, including the Great Lakes. The discharge of other types of garbage is allowed outside certain specified distances from shore as determined by the nature of that garbage.

THE DISCHARGE OF PLASTIC OR GARBAGE WITH PLASTIC INTO ANY WATERS IS PROHIBITED. THE DISCHARGE OF ALL GARBAGE IS PROHIBITED IN THE NAVIGABLE WATERS OF THE UNITED STATES AND IN ALL OTHER WATERS, WITHIN THREE NAUTICAL MILES OF THE NEAREST LAND.		
THE DISCHARGE OF DUNNAGE, LINING, AND PACKING MATERIALS THAT FLOAT IS PROHIBITED WITHIN 25 NAUTICAL MILES FROM THE NEAREST LAND.	OTHER UNGROUND GARBAGE MAY BE DISCHARGED BEYOND 12 NAUTICAL MILES FROM THE NEAREST LAND.	OTHER GARBAGE GROUND TO LESS THAN ONE INCH MAY BE DISCHARGED BEYOND THREE NAUTICAL MILES FROM THE NEAREST LAND.
A PERSON WHO VIOLATES THE ABOVE REQUIREMENTS IS LIABLE FOR A CIVIL PENALTY OF UP TO \$25,000, A FINE OF UP TO \$50,000, AND IMPRISONMENT FOR UP TO FIVE YEARS FOR EACH VIOLATION, REGIONAL, STATE, AND LOCAL RESTRICTIONS ON GARBAGE DISCHARGES MAY ALSO APPLY.		

United States vessels of 26 feet or longer must display in a prominent location, a durable placard at least 4" x 9" notifying crew and passengers of discharge restrictions.



# Safety On Board

USCG Minimum Equipment Requirements for Recreational Vessels				
Boat Size in Feet	16'	26'	40'	65'
Personal Flotation Devices <sup>1</sup>	One Type I, II, III, or V per person		One Type I, II, III, or V per person plus one Type IV throwable	165'
Fire Extinguishers <sup>2</sup>				
No Fixed System	One B-I, any type	One B-II or Two B-I	One B-II and one B-I, or three B-I	One or more B-II (vessels 0-50 tons gross) Two or more B-II (vessels 50-100 tons gross)
With Fixed System	No Portables Required		Two B-I or one Class B-II	
Visual Distress	Night signals required when operating at night		Minimum of three day-use and three night-use (or three day/night combination) pyrotechnic devices <sup>5</sup>	
Signals	Horn or whistle recommended to signal intentions or signal position		One bell, and one whistle or horn required to signal intentions or position	
Sound Producing Devices	One CG-approved device on each carburetor of all gasoline-powered engines built after April 1940, except outboard motors			
Backfire Flame Arrestor	One CG-approved device on each carburetor of all gasoline-powered engines built after April 1940, except outboard motors			
Ventilation	CG standard system required on gasoline powered vessels with enclosed engine compartments built after August 1980			
Navigation Lights	Sidelights, Stern Light and Masthead <sup>6,7</sup>			
Under Power <sup>3,4</sup>	Sidelights and Stern Light <sup>6,8</sup>			
Under Sail	Same as "Under Sail"			
Rowing				
At Anchor	All-round light, 2nm (at night) or black anchoring ball (during the day) when outside a designated anchorage		3nm Masthead, 2nm all others	5nm Masthead, 2nm all others
Visibility Range	1nm Sidelights, 2nm all others		5" x 8" Oil Discharge placard and 4" x 9" Waste Discharge placard	
Pollution	"Honor system" (no plaques required)		Vessels over 40' with a galley must have a Waste Management Plan	Type II or III MSD only
Regulations	Vessels with installed toilet facilities must have an operable,			
Marine Sanitation	CG-certified Type I, II or III Marine Sanitation Device (MSD)		<b>Subject to local laws!</b>	
Devices	Familiarity with the Inland Navigation Rules required		The Inland Navigation Rules ("Rules of the Road") must be kept on board	
Navigation Rules				
<div>1. PFD's must be CG approved, wearable by the intended user and readily accessible.</div> <div>2. Fire extinguishers required on boats with enclosed engine compartments (not outboards), enclosed living spaces or permanent fuel tanks.</div> <div>3. Sailboats operating under engine power are considered power driven and must follow the "Under Power" rules. During the day, motorsailing vessels are required to fly a motoring cone.</div> <div>4. Power-driven vessels under 23' and under 7 knots can substitute a white lantern or torch in place of the required lights.</div> <div>5. Non-pyrotechnic substitutes: 1 orange distress flag (day-use) and 1 electric SOS signal light (night-use).</div> <div>6. All boats under 65' can substitute a single bi-color light for sidelights.</div> <div>7. Boats under power under 40' can substitute a single all-round light for separate stern and masthead lights.</div> <div>8. Boats under sail under 40' can substitute a tri-color light for separate sidelights and stern light.</div>				
Additions to these requirements are prescribed by some individual state laws. Check your state's Boating Safety Handbook for a complete list.				




## CHAPTER 1

---

### Communications

---

EPIRB




It is a good idea to carry communication gear such as a VHF-FM and/or HF transceivers set up for your operating area. Also, cell phones are useful in many coastal areas. Be sure to carry extra batteries. Also, mainly for offshore vessels, EPIRB's are designed to quickly and accurately

alert rescue forces, indicate an accurate distress position, and guide units to the distress scene. These devices operate from satellite signals sent to a ground station where the signal is downloaded. The downside is that they are relatively expensive but they are reliable even when other communications have been exhausted.

### Life Rafts

---



Inflatable life rafts are recommended for oceangoing and operating a vessel in a large body of water like the Great Lakes. They provide a shelter for extended periods. If used, make sure it is large enough for all aboard and contains the proper

emergency equipment pack. Periodically find a professional to service the life raft. Store it on board in an area safe from sharp objects. Make sure the life raft is Coast Guard approved.

**Remember the U. S. Coast Guard requirements are minimal standards.** They are an excellent starting point. Check with local and state boating agencies for further required safety equipment. You are best prepared for emergencies by a well equipped vessel. Don't skimp when purchasing equipment for your boat!



### **EXHAUST & CARBON MONOXIDE**

Carbon monoxide (CO) in exhaust can be hazardous. It is important for you and your passengers to be aware of the potential safety hazard created by exhaust gases. Familiarize yourself with the symptoms of carbon monoxide poisoning.

**For safety sake avoid the following:**

1. Do not allow the boat to remain stationary with the engine idling for an extended period of time.
2. Do not disable the carbon monoxide alarms that come with your Regal boat. Test the unit in accordance with the alarm manufacturers instructions.
3. Do not operate the engine for extended periods of time while in a confined area or where exhaust outlets face a wall or bulkhead.
4. Do not operate the engine for an extended period of time with the canvas in the upright and installed position.
5. Have the engine exhaust system inspected when the boat is in for service.
6. Persons sleeping can easily be overcome by carbon monoxide without realizing it. Do not sleep on board while the engine is running or a neighboring boats engine is running.




### **WARNING**

**AVOID SERIOUS INJURY OR DEATH  
FROM CO POISONING!  
DO NOT OPERATE THE BOAT WITH PEOPLE  
HOLDING ON TO THE SWIM PLATFORM  
WHILE IN THE WATER**







## CHAPTER 1



Blockage of exhaust outlets can cause carbon monoxide to accumulate in the cabin and cockpit area even when the hatches, windows, portholes and doors are open.



Exhaust from another vessel alongside your boat, while docked or anchored, can emit poisonous CO gas inside the cabin and cockpit areas of your boat.



The “station wagon effect” or backdrafting can cause CO gas to accumulate inside the cabin, cockpit or bridge areas when the boat is under-way, using protective weather coverings, high bow angle, improper or heavy loading, slow speeds, or when boat is at rest.

### Typical Carbon Monoxide Label At Helm

<b>⚠ WARNING</b>	
	<b>Carbon monoxide (CO)</b> can cause brain damage or death.
	Engine and generator exhaust contains odorless and colorless carbon monoxide gas.
	Signs of carbon monoxide poisoning include nausea, headache, dizziness, drowsiness, and lack of consciousness.
	Get fresh air if anyone shows signs of carbon monoxide poisoning. See Owner's Manual for information regarding carbon monoxide poisoning.

### Typical Carbon Monoxide Label At Transom

<b>⚠ DANGER</b>	
	<b>Carbon monoxide (CO)</b> can cause brain damage or death.
	Engine and generator exhaust contains odorless and colorless carbon monoxide gas.
	Carbon monoxide will be around the back of the boat when engines or generators are running.
	Move to fresh air, if you feel nausea, headache, dizziness, or drowsiness.


NW-206-05





## Safety On Board

### Typical Carbon Monoxide Label In Cabin/Head


<b>⚠ WARNING</b>	
	<b>Carbon monoxide (CO) can cause brain damage or death.</b>
	Carbon monoxide can be present in the cabin.
	Signs of carbon monoxide poisoning include nausea, headache, dizziness, drowsiness, and lack of consciousness.
	Get fresh air if anyone shows signs of carbon monoxide poisoning.
	Get fresh air if carbon monoxide detector alarm sounds.
	Carbon monoxide detector must be functioning at all times.

In high concentrations, CO can be fatal in minutes. However, lower concentrations over an extended period of time can be just as lethal.

Symptoms of excessive exposure to carbon monoxide are:

- Dizziness
- Drowsiness
- Nausea
- Headache
- Ringing in the ears
- Throbbing temples
- Watery, itchy eyes
- Flushed appearance
- Inattentiveness
- Incoherence
- Fatigue or vomiting
- Convulsions

Carbon monoxide accumulation requires immediate attention! Thoroughly ventilate cabin and cockpit areas. Determine the probable source of the carbon monoxide and correct the condition immediately. Regal has installed CO detectors on your boat. Have these detectors professionally calibrated at regular intervals.



**DESIRED AIR FLOW  
THROUGH BOAT**

To help prevent carbon monoxide accumulation, ventilate your cabin and cockpit while underway. Open a forward hatch, porthole or window to allow air to travel through the boat's interior. See the illustration below for desired air flow.



## CHAPTER 1

---

### Each Trip

---

- ☒ Make sure all exhaust clamps are in place and secure.
- ☒ Look for exhaust leaking from the exhaust system components, indicated by rust and or black streaking, water leaks, or corroded or cracked fittings.
- ☒ Inspect all rubber exhaust hoses for burned or cracked areas. All rubber hoses should feel soft and be free of kinks.
- ☒ Visually verify that water exits at the engine exhaust outlet.
- ☒ Keep an ear tuned for any change in exhaust sound that could indicate an exhaust component malfunction.

**DO NOT OPERATE THE VESSEL IF ANY OF THE ABOVE ITEMS EXIST, CONTACT A MARINE PROFESSIONAL!**

### At Least Annually (To be performed by a marine professional)

- ☒ Replace exhaust hoses or mufflers if any evidence of cracking, charring or deterioration is found.
- ☒ Replace the engine water pump impeller along with the plate and housing if necessary. This will help prevent cooling system and in turn exhaust system overheating.
- ☒ Inspect each of the metallic exhaust components for cracking, rusting, leaking or looseness. Pay detailed attention to the exhaust manifold, cylinder head and water injection elbows. Make sure all exhaust clamps are in place and secure.



### BOATING UNDER THE INFLUENCE



#### **WARNING**

FEDERAL LAWS PROHIBIT OPERATING A VESSEL  
UNDER THE INFLUENCE OF ALCOHOL OR DRUGS.  
THESE LAWS ARE VIGOROUSLY ENFORCED  
BY ALL ENFORCEMENT AGENCIES.

Operating a vessel while intoxicated became a specific federal offense effective in 1988. The ruling set federal standards for determining when an individual is intoxicated. If the blood alcohol content (BAC) is .10% (.08 in some states) or higher for operators of recreational vessels being used only for pleasure are subject to a civil penalty up to \$1,000 or criminal penalty up to \$5,000, one year imprisonment or both. In some states the fines and imprisonment may increase significantly.

The effects of alcohol and drugs account for the highest single cause of marine accidents and deaths. Most deaths in boating accidents occur when someone falls into the water. Balance is one of the first things you lose when drinking alcohol or under the influence of drugs. The problem arises out of not knowing your balance is restricted.

Overall vision is reduced by alcohol especially at night, along with double or blurred vision. Peripheral vision is lessened which restricts seeing vessels or objects on the side. Also, color awareness decreases especially with red and green which happen to be the colors of boat navigation lights, buoys, and channel markers.

Alcohol will greatly increase your heat loss so it increases the effects of hypothermia. Finally, your ability to make correct judgements in emergency situations is greatly reduced. Alcohol takes away the brains ability to process information quickly and delays a persons reaction time. **Don't drink and drive!**



## CHAPTER 1

### Alcohol Myths And Facts

**Myth:** Beer is less intoxicating than other alcoholic beverages.

**Fact:** One 12 oz. can of beer has about the same amount of alcohol as a 5oz. glass of wine or a shot of liquor.

**Myth:** Black coffee, fresh air, and a shower will sober the effects of alcohol.

**Fact:** After consuming alcohol time is the only thing that will sober you up. Our bodies average burning 1 oz. of alcohol every hour. If a person is drunk, it will take about seven or more hours to sober up.

**Myth:** Telling if a person is too drunk to operate a vessel is easy.

**Fact:** Many experienced drinkers have learned to compensate for the visual effects of alcohol and can disguise their drunk condition.

**Myth:** You're the best person to judge if you are fit to operate a boat.

**Fact:** Judgement is one of the first elements you lose when drinking.


BLOOD ALCOHOL CONTENT CHART									
Body Weight In Pounds	Number of Drinks In A 2 Hour Period (12 oz. beer=5 oz. wine=1 oz. 80 proof liquor)								
100	1	2	3	4	5	6	7	8	9
120	1	2	3	4	5	6	7	8	9
140	1	2	3	4	5	6	7	8	9
160	1	2	3	4	5	6	7	8	9
180	1	2	3	4	5	6	7	8	9
200	1	2	3	4	5	6	7	8	9
220	1	2	3	4	5	6	7	8	9
240	1	2	3	4	5	6	7	8	9
BAC to .05%	— Be Careful- Loss of Judgement & Coordination								
BAC .05% to .10%	==== Abilities Impaired- Accident Chance Increased								
BAX. Over 10%	===== Do Not Operate A Boat- High Accident Risk								



## *Safety On Board*

---

### **BOATING ACCIDENTS**



The following is a list of common causes of boating accidents. Be aware of them and take the necessary steps to ensure that your crew and yourself are educated and prepared to act in an emergency.

- Mixing boating and alcohol. Remember the skipper is responsible for his boat and crew.
- Trying to reach the bow by the deck walk-around while the boat is moving too fast.
- Someone sitting on the bow, deck, or swim platform while underway.
- Choosing a boating outing day with inclement weather, especially with high winds and thunderstorms in the forecast or staying out when bad weather is approaching.
- Disembarking without checking all fluids or systems and especially fuel system components.
- Not monitoring the boating traffic or possible obstructions around you.
- Emergency communications equipment, signaling devices, and navigation lights not working.
- Improper boat handling especially high speed turns in rough water. Improper trim.
- Being too far from shore with inadequate fuel supply or navigational aids.



## CHAPTER 1

---

- Passengers, especially children that are not wearing the proper life saving devices.
- Skipper or passengers not seated in the boat.
- Running a craft that is mechanically marginal.

### Reporting Boating Accidents

---

According to the Federal Boat Safety Act of 1971 involving collision, accident or other casualty, the operator must make a formal report within 48 hours to the nearest state boating authority when the incident involves:

1. Death
2. Injury requiring treatment other than first aid
3. The disappearance of someone from a boat under death or injury circumstances.

A formal report must be made within 10 days for accidents involving more than \$500 damage or complete loss of vessel.

For information regarding accident reporting, please call:

**Boating Safety Hotline** at 800-368-5647.

### Rendering Assistance

---

The operator of a vessel is obligated by law to provide assistance that can be provided safely to any individuals in dangerous situation on the waterways. The operator is subject to fine and or imprisonment for failure to do so. Move cautiously and think before acting.



## *Safety On Board*


---

### **WATER SPORTS**

Besides learning the safety precautions for safe boating, as well as understanding and knowing required rules and regulations, you are obligated to be particularly careful around other water sportsman, such as scuba divers, water skiers, wake boarders, and fisherman.

#### **Skin & Scuba Divers**

---



Whenever you see a “Diver Down” flag, maintain a distance of at least 100 feet on inland waters. In bays and open waters stay 300 feet away. The flag indicates a diver in the water. If a diver is operating from your boat, be certain to use this flag and post a lookout on board for a divers air bubbles. Sometimes divers stray from the flag area.

#### **Water Skiers & Wakeboarders**

---



For information on water skiing and how to get started, we recommend you contact the American Water Ski Association, P. O. Box 191, Winter Haven, Florida 33880. They offer pamphlets and instructional materials.

For wake boarding information there are numerous training schools throughout the country along with instructional videos and the internet.



## CHAPTER 1

---

General safety procedures for towing skiers and wake boarders include the following:

- Know your hand signals and make sure all your passengers know them. See the illustration.
- Do not allow non-swimmers to ski or wake board. You're asking for trouble!
- Always have an observer on board whose sole job is to watch the skier/wakeboarder and communicate with the driver.
- If you plan to do a lot of skiing/wake boarding, it is advisable to have a ski pylon and driver's rear view mirror installed.
- Acquaint yourself with the ski site before skiing/wake boarding.
- Follow the speed limits and all posted signs- i.e. no wake, etc.
- Keep the boat away from swimmers or other people in the water.
- Avoid running near the shoreline or in heavily congested areas with skier/wake boarder in tow.
- Do not allow skier/wake boarder to spray fisherman or other parties.
- Keep the engine speed steady while towing a skier/wake boarder.
- Make wide turns with skier/wake boarder in tow.
- Instruct skier/wake boarder in case of a fall to raise his ski in the air to ensure his visibility.
- Always turn your engine off when the skier/wake boarder is near the platform or transom.






## Safety On Board

---

□ If the skier falls, return promptly to retrieve him, circling wide from the starboard side, to bring his rope within easy grasp.

### Ski Tow

---



Insert the ski tow line as shown for safe operation. It provides a tight fastening for skiing while allowing the line to be readily removed if needed. Check your tow line for abrasion and tow ring for tightness periodically. The illustration shows a typical hookup.



## WARNING

AVOID SERIOUS INJURY OR DEATH!  
DO NOT USE SKI TOW FITTING  
FOR LIFTING OR PARASAILING.  
THE FITTING COULD PULL OUT OF DECK.

### Swim Platform

---

**WARNING!**  
**MAXIMUM CAPACITY**  
**OF SWIM PLATFORM**  
**500 POUNDS**  
**226 KG**








On integrated or extended swim platforms you should make periodic inspections of the swim ladder and swim platform hardware to ensure that all connectors and fittings are tight and free from corrosion. Check the laminated fiberglass under platform supports for fatigue and cracks. Never run the boat

with someone holding on to or standing/sitting on the platform. Use heed when operating the boat in reverse to insure that water does not accumulate excessively on the platform especially in rough seas or strong currents. Do not exceed the platform recommended maximum capacity **label!**



## CHAPTER 1

### WATER SKI & WAKEBOARD SIGNALS





## Safety On Board

---




### WARNING

AVOID SERIOUS INJURY OR DEATH!  
DO NOT OPERATE THE BOAT  
WITH PEOPLE IN THE WATER  
OR ON TOP OR HOLDING ON TO  
THE SWIM PLATFORM STRUCTURE OR HARDWARE.

### Fishing

---



Most boaters fish from time to time. With the propulsion systems of today it is possible to fish in out-of-the-way places. When cruising, stay clear of fisherman. They may have lines or nets out which might be cut or get caught in your propeller if you come too close. Slow down when approaching fishing boats.

Do not return to cruising speed until the boats have been passed. If a fishing boat should be anchored, a large wake could flip or swamp the boat, upset fishing gear, pull the anchor loose from the bottom or worse yet cause someone to fall overboard.

When fishing from your boat, never anchor in shipping channel or tie up to any navigational aids. These must be kept clear of at all times. Be sure to carry a chart of the area and be on the lookout for shallow water and hidden obstructions. Pick up a local tidal chart if appropriate so you do not end up grounded.

**Remember, the skipper is responsible for any damage caused by his wake. Use common sense and be a responsible captain!**




## CHAPTER 1

# WEATHER & WATER CONDITIONS

Before a boating outing check the weather conditions. As we all know the weather can change rapidly in many parts of the country. It does so sometimes without being predicted. NOAA weather radio reports are continuously available on designated frequencies installed on VHF radios and various handheld devices. Also, many local radio stations carry weather reports.

## Cloud Formations



Clouds indicate the type of current weather and upcoming changes in the weather. Knowing the type of cloud formations can assist you in choosing the appropriate boating day or if already on the water will help you understand any upcoming weather changes.

Flat clouds (stratus) normally indicate stable air. Cumulus clouds indicate unstable air.

Many times a “cotton

ball” or cumulus cloud builds vertical height in the afternoon and the result is a thunderstorm with increased winds and waves; sometimes these storms are quite violent. You can find additional information on weather (meteorology) at your local library.



## *Safety On Board*

---

### **Waves & Fog**

---



As the wind blows across water waves are created. The stronger the wind and increased distance across the water enlarges the wave action.

Other factors that can cause problem situations for vessels are fog, currents, and tidal changes.

Fog can develop inland on clear, calm mornings. Coastal areas see large “blankets” of fog roll in and stay for extended time periods causing sometimes hazardous navigation conditions. If you are caught

in the fog, do not panic. Think of the best plan of action and proceed carefully. If you are limited in navigation equipment at the first sign of fog proceed to the nearest shoreline and wait until the fog lifts.

Boats equipped with navigation equipment, local waterway experience and charts should proceed to a safe harbor. Use extreme caution, signal as needed, and reduce to a speed where you can stop within half of your forward vision range.









#### **If foul weather catches you at sea do the following:**

1. Slow down. Proceed with caution and put on your life vests.
2. Try to reach the nearest safe shoreline.
3. Navigate your vessel slowly into the waves at a 45 degree angle.
4. Passengers should sit low in the center of the vessel.
5. Monitor your bilge pump. Make sure sump stays free of water.
6. Secure loose gear. Make ready emergency equipment.
7. If the engine stops, throw the anchor over the bow. If needed use a sea anchor. Never anchor off the stern.



## CHAPTER 1

### Marine Weather Symbols

	SMALL CRAFT	GALE	STORM	HURRICANE
DAY FLAGS	 RED	 RED	 RED & BLACK	 RED & BLACK
NIGHT LIGHTS	 RED WHITE RED	 WHITE RED WHITE	 RED WHITE RED	 RED WHITE RED

Although the National Weather Service has discontinued the use of the day flags and night lights, many marinas and ports of call still display them.



# *Rules Of The Road*

## **NAVIGATION RULES DEFINED**

The Navigation Rules set forth actions to be followed by boats to avoid collision. They are referred to as the “Rules of the Road”. There are two main parts referred to as the inland and international rules. The inland rules apply to vessels operating inside the boundaries of the United States. The international rules referred to as COLREGS apply to vessels operating on the high seas and all connected waters outside the established demarcation boundaries. Most navigational charts show the demarcation lines by red dotted lines and are published in the navigation rules. Remember to consult state and local agencies since areas such as “no wake zones”, swimming beaches, “diver down flag” and inland landlocked lakes fall under their jurisdiction. This section is only an introduction to the “rules of the road”. We strongly recommend additional training before getting behind the “wheel” of your boat.

	<b>WARNING</b>
<b>TO AVOID INJURY AND DEATH FOLLOW THE NAVIGATION “RULES OF THE ROAD” TO PREVENT COLLISIONS.</b>	

You can order the Inland & International Navigation Rules from:  
Superintendent of Documents  
U. S. Government Printing Office  
Washington, DC 20402  
Telephone: (202-512-1800) Fax: (202-512-2250)



## CHAPTER 2

---

### NAVIGATION RULES

#### Right Of Way

---

1. Cross waves at right angles.
2. When caught in heavy water or squalls, head either directly into the waves or at a slight angle. Reduce speed, but maintain enough power to maneuver your boat safely.
3. Keep your speed under control. Respect the rights of other boaters engaged in all water sports. Give them a “wide berth”.
4. Whenever meeting a boat head on, keep to the right where possible.
5. When two boats cross, the boat to the right (starboard) has the right of way.
6. When overtaking or passing, the boat being passed has the right of way.

In general, boats with less maneuverability have right-of-way over more agile craft. The skipper must keep his craft clear of the following vessels:

- A vessel not under command or aground; due to their circumstances, these vessels have no maneuverability.
- A vessel restricted in its maneuverability; these vessels usually are performing work which limits their maneuverability such as surveying, dredging, laying pipe or cable, or servicing navigational markers among others.
- A vessel engaged in fishing; these include boats fishing with lines, trawls or nets, but not trolling lines.





## Rules Of The Road

---

- Sailboats; they have the right-of-way over power boats. However, if a sailboat is using a prop to move forward, it is considered a powerboat even if the sails are up.
- Remember the unwritten “rule of tonnage”. Basically a smaller tonnage vessel should take every effort to avoid close quarters with a larger tonnage vessel. One way to accomplish this is to have a designated human lookout to “eyeball” the horizon for any developing collision course.
- Use defensive driving skills on the waterway just as you do on the roadway. The other vessel may not know the “rules of the road” Be alert and ready to take immediate action.
- If a collision course is unavoidable neither boat has the right of way. Both boats must react to avoid an accident according to the rules of the road.







## Signals

---

### WHISTLE SIGNALS

**ONE LONG BLAST:** Warning signal  
(Coming out of slip)  
**ONE SHORT BLAST:** Pass on my port side  
**TWO SHORT BLASTS:** Pass on my starboard side  
**THREE SHORT BLASTS:** Engine(s) in reverse  
**FOUR OR MORE BLASTS:** Danger signal

### BRIDGE SIGNALS


SOUND		VISUAL	
VESEL: Open	— ●	VESEL: Open	DAY (Flag)  NIGHT (Lights) 
BRIDGE: OK	— ●	VESEL: OK	DAY (Flag)  NIGHT (Lights) 
No	● ● ● ● ●	BRIDGE: OK	Same or Same
VESEL: Replies:	● ● ● ● ●	No	 
RADIO: VHF CH. 13			




## CHAPTER 2

### NAVIGATION RULES


The Navigation Rules set forth 3 types of crossing situations- crossing, meeting, and overtaking. In each case, both boats are governed by special procedures.



In a head-on meeting, both vessels must sound a single blast to give way toward starboard and pass to port.



These rules appear when there is a risk of collision. In a crossing situation be aware of the other craft's position. For safety, there should be a noticeable change in the angle, bow or stern; a gradual change in position indicates possible danger.







# Rules Of The Road

## NAVIGATION RULES

An overtaking boat is burdened, and is not the privileged craft, even though it approaches the danger zone of the overtaken boat.



The overtaking boat first signals with a single blast if that boat desires to pass on the starboard side of the boat ahead, or a double blast if passing to port. The overtaken craft responds with the same signal if it is safe, or with the danger signal (5 short blasts or more) if unsafe. The boat overtaking must not pass unless the appropriate signals are sounded.





## CHAPTER 2

---

### NAVIGATION AIDS

Navigation aids are placed along coasts and navigable waters as a guide for mariners in determining their position in reference to land and hidden danger. Each aid provides specific information. They form a continuous system of charted markers for accurate piloting on paper and on the water.

Nautical charts are provided by the National Ocean Service (NOS) and are distributed nationwide through marinas and outlet stores. These charts show the geography of the coast, water depth, landmarks, navigation aids (buoys and markers), marine hazards, and port facilities. Use only up-to-date charts for navigation. We recommend when purchasing a chart to look for the weather resistant ones.

Buoys provide a road map to keep the skipper on course and to avoid hazards. Buoys are identified by light, shape, color and in severe weather conditions by sound.

Buoys or beacons called lateral markers indicate the port and starboard sides of the waterway to be followed. U. S markers follow the buoy system known as Red Right Returning. When returning from sea or traveling upstream, the green markers are to port (on your left) and the red markers are to the starboard side (on your right). When traveling downstream or out to sea the marker color would be reversed. The Intercoastal waterway uses a different system of lateral markers for port and starboard. Before operating your vessel, learn to identify the various navigational aids such as lateral aids, mid-channel markers, information and regulatory markers.

### NOTICE


SKIPPERS MUST NOT RELY ON BUOYS ALONE  
TO MARK THEIR POSITION.  
SEVERE WEATHER CONDITIONS  
AND WAVE ACTION CAN ALTER A BUOYS POSITION.  
NEVER TIE UP TO A BUOY.  
IT IS ILLEGAL AND EXTREMELY DANGEROUS.



# Rules Of The Road

## LATERAL AIDS

Port Side  
Odd Numbers




Lighted Buoy  
(Green Light Only)

Chart Symbol




Starboard Side  
Even Numbers




Lighted Buoy  
(Red Light Only)

Chart Symbol



Can Buoy  
(Unlighted)

Chart Symbol



Nun Buoy  
(Unlighted)

Chart Symbol



Daymark

Chart Symbol



Daymark

Chart Symbol







## CHAPTER 2

---

### MID-CHANNEL MARKERS



### REGULATORY MARKERS



Diamond Shape  
Danger Warning



Diamond Shape With Cross-  
Boats Keep Out



Circle Marks Area Controlled  
As Indicated



For showing information such  
as locations, distances and  
directions




## Rules Of The Road

### NIGHT RUNNING

Boats operating between sunset and sunrise (hours vary by state), or in conditions of reduced visibility, must use navigation lights. Nighttime operation, especially during bad weather and fog, can be dangerous. All Rules of the Road apply at night, but it is best to slow down and stay clear of all boats regardless of who has the right-of-way.

To see more easily at night, avoid bright lights when possible. Also, it is helpful to have a passenger keep watch for other boats, water hazards and navigational aids.

To determine the size, speed and direction of other vessels at night, you should use the running lights. A green light indicates starboard side, and a red light indicates port side. Generally, if you see a green light, you have the right-of-way. If you see a red light, give way to the other vessel.





## CHAPTER 2

---

### BRIDGE CLEARANCE

Be aware that your vessel requires a specified bridge clearance height. This height is a measured estimate from the waterline to the top of the highest object usually the power tower, radar or the masthead light depending on what tower equipment is installed. All canvas should be in the stored position. The estimated height can change because of variances in the loaded condition of the vessel. Consult the bridge clearance specifications located in Chapter 12 (technical information section). An easy way to measure bridge clearance is to have someone place a long straightedge such as a piece of wood at a 90 degree angle across the highest point of the boat with the boat in the water. Then with a tape rule measure the distance straight down (90 degrees) to the waterline. Take this measurement with the fuel and water tanks 1/2 full and only 1 person besides yourself on board. This will give you a safe measurement. As your boat is loaded down with people the bridge clearance will be slightly lower.

Some bridges are tendered. Know and use the proper bridge signals when approaching these bridges (see bridge signals on page 2-3). You can also monitor and communicate on channel 13 of a VHF radio for bridge information in most domestic locals. Other bridges are marked with a clearance measurement and you are on your own. After determining your vessel will clear the bridge proceed with caution at a safe idle speed. Keep your eye on vessel traffic at all times in order to react quickly. Resume a safe speed once clear of the bridge structure and acknowledgment of clear visibility.

Use common sense regarding bridge clearance because bodily injury and property damage could result if a mishap occurs with a bridge structure.





# *Engines & Controls*

## ENGINE

### Engine Basics

It is important that you read the engine manual carefully and become familiar with the operation as well as necessary maintenance on the engine and propulsion systems. Pay careful attention to the sections on winterization if you live in freezing climates. Extensive damage can result if proper winter storage is not followed. Your Regal dealer has been factory trained on Regal boat systems. Consult your Regal dealer for further information regarding technical issues and parts.



## **WARNING**

**AVOID SERIOUS INJURY OR DEATH!  
READ ALL MANUFACTURER'S ENGINE AND  
PROPULSION OWNER MANUALS  
BEFORE OPERATING YOUR VESSEL.**

### Engine Mounts

The engine is set in the boat on a group of metal platforms called mounts. These rubber isolation mounts keep the engine from moving laterally and at right angles to the center-line. The mounts help reduce the vibration caused by the engine and drive. Periodically, the mount hardware should be checked for tightness.



## CHAPTER 3

---

### Engine Alignment

---

The engine uses a rubber spline hub to which the stern drive shaft is attached. This alignment specification between the engine and stern drive needs to be checked periodically. It should be checked after each 50 hours of operation or if the vessel has run aground or hit a submerged object. Alignment should be checked by a Regal dealer or marine professional since special tools and procedures are required.

### Engine Removal

---

In the event the engine or out-drive (sometimes referred to as stern drive) requires major service where it needs to be removed, consult your Regal dealer.

### Engine Ventilation

---

Ventilation systems are required for engine compartments. Your boat features a set of deck vent shrouds with mesh covers which supply fresh air constantly to the engine compartment. A powered blower motor connected to ducts in the lower one third of the bilge evacuates air to the atmosphere. **Read and understand the following warning.**



## WARNING

GASOLINE VAPORS CAN EXPLODE. BEFORE STARTING ENGINE, OPERATE BLOWER 4 MINUTES AND CHECK ENGINE COMPARTMENT FOR GASOLINE LEAKS OR VAPORS. RUN BLOWER BELOW CRUISING SPEED.

All owners are responsible for keeping their boat's ventilation systems in operating condition. This means making sure the ventilation covers are obstruction free, ducts are not blocked or torn, blower operates properly and any worn parts are replaced with approved marine parts.



## **Catalyst Engines**

---

Due to federal and state regulations many newer marine engines are retrofitted from the engine manufacturer with a catalytic converter system for a cleaner environment. The sheer numbers of these engines will fill the marine propulsion market over the next few years.

Simply stated, a catalytic converter utilizes extreme heat to reduce the engine's output of hydrocarbons and carbon monoxide thus reducing pollutants. The system theory involved follows the automotive market but the actual parts and closed loop designs are unique to the marine industry due to temperature, space restrictions, weight and corrosion factors found in the marine environment.

Both major engine manufacturers incorporate catalytic converters within a water-jacketed manifold. Oxygen sensors are placed in the system along with on board monitoring equipment. The systems permit the engines to operate at normal horsepower ratings.

Read and understand the typical emission monitoring system explained later in this chapter. Also, read the engine manufacturer's operation manual for more detailed information regarding catalytic converters and the system maintenance information.



## CHAPTER 3

---



### WARNING

TO PREVENT FIRE OR EXPLOSION  
USE ONLY APPROVED MARINE REPLACEMENT  
PARTS THAT ARE IGNITION PROTECTED

## PROPULSION

### Stern Drive

---

It is important that you read the engine/stern drive manual carefully and become familiar with the operation as well as necessary maintenance on the drive unit components. Pay careful attention to the sections on winterization if you live in freezing climates. Extensive damage can result if proper winter storage is not followed. Refer to the maintenance section of this manual for more information or call your nearest Regal dealer.

### Propellers

---



We have carefully tested and chosen the propellers to give your stern drive boat the best possible performance and have allowed for the additional weight in equipment that might be added to the boat. It is a good idea to carry a spare set of propellers and hand tools in order to handle an emergency propeller change. Refer to the engine manual for

proper procedures since each stern drive application is unique. Call a marine professional or your Regal dealer for further information.



### DANGER

PREVENT SEVERE INJURY OR DEATH!  
SHUT OFF ENGINE NEAR SWIMMERS  
TO AVOID ROTATING PROPELLER BLADES.

#### Propeller Checklist

At least twice a year check the propeller for:

- ☒ Loose, missing or corroded hardware.
- ☒ Nicks, dings or missing propeller material.
- ☒ Bent propeller blades.
- ☒ Objects wrapped around the prop such as fish line.
- ☒ Decomposing propeller blades (electrolysis symptom).
- ☒ Aluminum prop with paint coming off near blade tip (ventilation symptom).
- ☒ Check the propeller pressed in rubber hub for slippage.

Contact a propeller shop or your closest Regal dealer if any of the above symptoms exist. They have special equipment to refurbish both stainless steel and aluminum propellers. After making any blade alternations the propellers are “re-pitched” in special prop jigs.




## CHAPTER 3

---

### CONTROLS

#### Instrumentation

---



The helm station is equipped with a complete set of instruments that allows you to monitor the condition of the engines. Close observation of the gauges may save

the engines from damage.

The dash ignition switch is protected by a main 20 amp ignition breaker located close to the ignition switch.

The engine wiring is protected by a main breaker with a push button found in the engine area. If a breaker “pops” figure out the reason why before resetting it.

Also, each dash switch is protected by a fuse (part of a fuse block assembly) found under the dash area.


### NOTICE

WITH BATTERY SWITCH IN THE “OFF” POSITION  
THERE IS NO POWER TO THE DASH.



## Engines & Controls

### Typical Helm Overview





## CHAPTER 3

---

### Gauge Operation

---

Following is a general description of typical gauge operations. An alert skipper monitors his gauges constantly for any system malfunctions. The gauges are lighted for night operation. Gauges are an early warning system for marine engines just as for automobiles. For more information, refer to the engine manufacturer's manual in the owner's pouch.



#### Tachometer:

The tachometer indicates the speed of the engine in revolutions per minute (rpm). The tachometer allows you to monitor the engine speed so you can be sure not to exceed the recommended limits of the engine manufacturer. *Selected* tachometers have built in hour meters.



#### Multi-Function Gauge

The multi-function gauge reads 4 separate engine functions which makes viewing much easier especially when cruising. The parameters covered are fuel, volt, oil, and temperature. Refer to the individual sections on the next page for a full description of the multi-function gauge operation.





## *Engines & Controls*

---

### **Fuel Gauge:**

The fuel gauge indicates the level of fuel inside the fuel tank. It is a good idea to keep the fuel tanks “topped off” when possible to reduce fuel vapors inside the tank. It is also a good idea not to run the fuel level close to empty in order to leave an adequate “safety” factor.

### **Volt Meter:**

The volt meter monitors the battery condition as well as the alternator performance. Normal voltage is between 12.0 and 15.0 volts. Readings outside of this range may indicate a charging system or battery problem.

### **Oil Pressure:**

The oil pressure gauge indicates the pressure of the oil inside the engine lubrication system. A drop in oil pressure may be an indication of a low oil situation or a leak. Continued operation of the engines with low oil pressure could lead to engine damage. Refer to appropriate manufacturer’s engine manual for more information.

### **Temperature Gauge**

The temperature gauge monitors the cooling system of the engine. A sudden increase in the temperature could be a sign that the engine cooling system is malfunctioning. Shut down the engine immediately and investigate the problem. Consult your engine manual for allowable limits.



## CHAPTER 3

---



### Depth Gauge:

The depth gauge is standard equipment on selected models. The depth gauge indicates the water depth under the keel of the boat. It features an shallow water alarm. By monitoring the water depth closely, damage to props and underwater hardware can be avoided.



### Speedometer:

This instrument used on selected Regal models indicates miles per hour and kilometers per hour. Like the other gauges in the instrument cluster it is illuminated for night operation. Consult the owner's packet for additional information.



### Trim Gauge:

This gauge measures the stern drive tilt and indicates the relative position of the bow, up or down when the boat is on plane. The power trim normally begins in the down position when used to accelerate the boat onto a plane position. The gauge can be helpful in achieving the most economical running condition.



## Engines & Controls

### Other Gauges & Indicators



The optional gas vapor detector determines if there is a level of gasoline vapors that is unsafe in the engine room of the boat. If installed, turn on the unit and wait about one minute for it to do its safety test. If all is well it will display a green light. You must run the test before you start the engines. In the event you don't get a green light, you must investigate the bilge of the boat for gas fumes or

signs of a fuel leak before starting the engines. If uncertain, consult a marine service professional



The automatic fire extinguishing system utilizes an instrument display unit (gauge) that provides the operator with a system status of charged or uncharged condition by an audible alarm. With the ignition turned on the indicator light shows system is charged and operating properly. With the ignition on and no light indicates the system has discharged.

If the system should discharge the ignition system will be instantaneously interrupted. Should this occur shut down the engine, ventilation blower and any electrical system components. Investigate the source of the shutdown immediately and take appropriate action. Also, in the cockpit is located a manual release for the fire extinguishing system. Find the release and read the related sections in this manual along with the vendor's information concerning the operation of the manual release. In case of emergency inform other crew members on the operation of the fire extinguishing system.



## CHAPTER 3

---

### Typical Catalyst Engine Monitoring Panel

---



Shown is a typical dash mounted engine emission status panel used with catalyst engines. It provides a visual and audible (beeping alarm) means of monitoring engine and emission control systems. The panel will show the outline of an engine on the left side and a warning sign on the right.

When an emissions related fault is detected an amber colored light will appear on the left side.

When an engine related malfunction is detected the warning sign will light red on the right side. If the situation is serious enough there may be a significant power reduction of the engine.

If either of the above lights is lighted an audible short beep alarm will be activated.

When the engine is initially started there is a series of self-checks involving the various emission system sensors.

Read the engine manufacturer's operation manual for more detailed information on emission monitoring systems related to the particular engine brand installed on your vessel.



## *Engines & Controls*

---

### **Regal Vue**

---



The Regal Vue is a touch screen used on electronically controlled engines that host NMEA 2000 and SAE J1939 communication systems. The unit features multi-dimensional displays which may include speed control and rider profiles which help make water

sports such as wakeboarding easier due to the ability to maintain the appropriate speeds.

Other displays include quick access controls for stereo, video, engine diagnostics, GPS maps and waypoint positions, engine statistics and along with home and settings calibrations.

Under the helm is a yellow RCA auxiliary plug which can be used to plug in a video camera to replay on the RegalVue dash display screen.



## CHAPTER 3

---

### Audible Alarms

---

Most Mercruiser and Volvo engines use audible alarms. They are designed to use sensors which pick up deviations from the normal operating parameters. Oil pressure and temperature sensors send a signal to a buzzer under the dash which sounds a high pitched alarm indicating a possible problem. In addition to the dash, some engines use buzzers at the engine itself.

### NOTICE

PREVENT POSSIBLE ENGINE DAMAGE  
WHEN AN AUDIBLE ALARM SOUNDS  
SHUT DOWN ENGINE IMMEDIATELY,  
INVESTIGATE & REPAIR THE PROBLEM.

On start up it is not unusual to hear an audible alarm sound when cranking the engine over. This occurs normally because it takes a second or two to build up the engine oil pressure. Then the alarm will stop. A seasoned skipper monitors his instrument panel often while cruising.

Also, a single catalyst engine may use an emission status panel.

### Instrument Lighting

---

Each gauge is designed with a light bulb so it can be seen at night. On most models you activate the instrument lighting by energizing the navigation light switch. Eliminate condensation inside the gauges by activating the gauge lights in high humidity environments.




## Engines & Controls

### Ignition Switch

The ignition switch features 4 positions. In a clockwise direction they are auxiliary, off, run, and start. The start position is spring loaded and the key should be held in this position to engage the starter. Once the engine has started release the key from the start position. The electrical system will then be energized in the run position.

The auxiliary position is counterclockwise from the “off” position. When it is activated the stereo and dash switches can be energized without the instrumentation engine ignition wiring and engine warning buzzers being energized. Be a smart skipper and remove the ignition key from the ignition switch with children aboard and/or when there are people in the water.



## NOTICE


TO AVOID DRAINING THE BATTERY  
DO NOT LEAVE IGNITION KEY  
IN THE “ON” POSITION  
WITH THE ENGINE NOT RUNNING



## CHAPTER 3

---

### REMOTE CONTROL OVERVIEW



Your vessel uses a single lever remote control similar to the illustration.

To help visualize the operating principals we have used a clock mode. The lever in the straight-up or 12 o'clock (neutral) position is detented and features a push button (see illustration) which allows advancing the throttle for neutral or starting the engine without engaging the gearshift. This feature is

useful when trying to start a cold engine.

**Pushing** the throttle lever forward from the neutral 12 o'clock position to the 11 o'clock position will engage forward gear with minimum throttle. From the 11 o'clock position to the 9 o'clock position the vessel is in forward gear with forward throttle selections.

**Pulling** the throttle back from the neutral 12 o'clock position to the 1 o'clock position will engage reverse gear with minimum throttle. From the 1 o'clock position to the 3 o'clock position the vessel is in reverse gear with reverse throttle selections.

As you shift from neutral to forward or reverse positions, *push up on the neutral interlock button* located under the gearshift knob. This will allow the control to shift into the desired gear.

#### Neutral Safety Switch

---

The remote control features a neutral safety switch which ensures the stern drive and control handle are in the detented neutral position for starting the engine.





## Engines & Controls



You will hear a distinct sound and will “feel” the remote control in the neutral position. If you turn the key to the “start” position and the engine starter doesn’t crank over the engine make sure the remote control is in the neutral position.

*Remember these points when shifting :*

1. Do not shift quickly from forward to reverse gear position. Drive system damage may occur.
2. Do not “pump” the throttle in neutral or flooding will result. Today’s engines require very little starting throttle.
3. Do not try to shift into forward or reverse gear at high rpm’s as personal injury, drive system or property damage may result.
4. Remember to squeeze the shift interlock button to engage the remote control into forward or reverse.
4. Only use idle throttle positions when docking or maneuvering in tight quarters.
5. Wear your safety lanyard at all times.
6. Never shift the controls with the engine not running. Control, linkage and or stern drive damage may occur. For more information read your engine operator’s manual for additional control data.




## CHAPTER 3

---

### Safety Lanyard (Interrupt Switch)

---

The safety lanyard (**used on select remote controls**) sometimes called an interrupter switch is attached to the operator and the remote control panel (See the illustrations). Should the operator lose control of the vessel and become dislodged from his seat or fall overboard the lanyard will shut the engine off.



Make sure the lanyard is installed to a part of clothing such as a belt before operating the vessel. Never disconnect the hook from attached clothing while the engine is running.

### NOTICE

IF THE INTERRUPT SWITCH IS IN THE "OFF" POSITION  
THE ENGINE WILL CRANK OVER  
BUT WILL NOT START.



### WARNING

INTERRUPT SWITCH MUST BE ATTACHED TO  
OPERATOR WHILE ENGINE IS RUNNING.  
QUALIFIED OPERATOR MUST BE IN CONTROL  
AT ALL TIMES. READ OWNER'S MANUAL BEFORE USE




# *Systems*

## **ELECTRICAL**

The electrical system on board is called direct current (DC for short). It is referred to as DC because it flows one-way in a circuit. This system is featured on your Regal FasDeck .

### **Direct Current (12 volt DC)**



Storage batteries (sometimes called wet-lead cell batteries) furnish 12 volt DC electricity to boat components. Storage batteries use 2 dissimilar metals immersed in an liquid to carry current (acid). The engines require large reserve amounts of battery power for starting purposes. Check the maintenance chapter for battery information.

The automobile battery is charged up by the engine alternator. The same holds true for the marine battery. The dash volt meter displays the battery voltage. If the volt meter shows below 12 volts there could be a charging system malfunction. This condition needs to be investigated before the batteries become completely drained.

Note: Never disconnect the battery terminal with the engine running. Never charge a battery in the boat or directly on cement. Remove the battery from the boat first. On non-maintenance free batteries check the water level periodically. Add distilled water only.



## CHAPTER 4

---

### WIRE COLOR CODES (solid color/stripe)

Color	Gauge	Function
Red	00	Battery Cable To Engine
Black	16 to 4	All Grounds
Black/White	16	Halon Fire Extinguisher
Brown	12	Water Pressure Pump
Brown	16	Aft Bilge Pump/Manual
Brown	16	Fwd. Bilge Pump/Manual
Brown/Black	10	Overboard Discharge Pump
Brown/White	16	Aft Auto Bilge Pump
Brown/Red	16	Fwd. Auto Bilge Pump
Brown/Pink	16	CO Detector
Yellow	12	Blower
Yellow/Black	16	Stereo Memory
Orange	12	Refrigerator, Hatch Ram
Orange	16	Windshield Wiper/Run
Orange/White	16	Windshield Wiper/Park
Orange/Black	16	Horn
Orange	10	Spotlight
Blue	14	Interior Lights
Blue/White	14	Cockpit Lights
Yellow/Red	14	Engine Cranking Circuit



## WIRE COLOR CODES (CON'T.)

Color	Gauge	Function
Blue	10	Cabin Light Main Feed
Blue/White	16	Transom Courtesy Lights
Gray	16	Bow, Navigation Lights
Gray/White	16	Mast Light (Fwd. Running)
Gray/Black	16	Mast Light (Anchor Light)
Red/Black	16	Windlass Up
Red/White	16	Windlass Down
Red	16	Gas Vapor Detector, Stereo Remote, Breaker To Dash Feed Leads
Red	2/0	Main DC Panel Feed
Red	2	Positive Feed, Starter, Battery
Red	4	Positive Feed
Red	6	Positive Feed, Alt. Charge
Red	8	Positive Feed, Alt. Charge
Red	14	Positive Feed, Electronics
Yellow/Black	16	Tank Monitor
Purple	16	Hour Meter
Green	8	Bonding
Green	16	Tank Level Monitor
Pink	16	Fuel Tank Sender Feed



## CHAPTER 4

---

The standard wire color, gauge size and function shown is used throughout the marine industry. The charts shown on the previous pages are helpful in identifying wire circuitry during troubleshooting or the adding of marine accessories. Never replace a wire with a size other than shown in the chart as a fire could result.

### DC Switches

---

Following is a summary of direct current switches used on your Regal boat. Your boat *may not* use some of the switches mentioned because they represent optional equipment not installed on your vessel. Also, electrical components and specifications can change at any time. These switches are illuminated for night operation.

#### Port Switch Bank



#### Nav/Anc

This switch controls the running and stern lights. It is a two position switch. Activate the forward section and the running lights (navigation and stern lights) are activated along with the instrumentation and switch lights for night running. Activate the aft portion and the stern light (360 degree light) is activated. Remember the navigation lights, sometimes called running lights must be used between sunset and sunrise. Should you anchor or stop the vessel at night the 360 degree light is required to be lighted.



### **Cockpit Lights**

This switch controls the courtesy lights in the cockpit area. Using these lights is especially useful when boarding or exiting the vessel at night.

### **Docking Lights**

This switch controls the forward hull docking lights. They are very useful for night maneuvering and docking.


### **(Acc.) Accessory**

This switch normally controls the fresh water system pump or the Volvo neutra-salt system or other optional equipment. If unused at the factory it may be utilized for any after market equipment installed on the boat. Make sure any added components are matched to the over current protection (fuse).



## CHAPTER 4

---



### **(Acc.) Accessory**

This switch normally controls the folding power tower if installed. The tower folds forward as needed. If unused at the factory it may be utilized for any after market equipment installed on the boat. Make sure any added components are matched to the over current protection (fuse).

### **Bilge Pump**

This switch controls the bilge pump located in the engine compartment. Mechanically, the switch features a manual position forward and an off position. When the switch is manually activated the bilge pump sends the accumulated bilge water overboard. There is an outlet on the starboard aft hull where you can visually monitor the bilge water.

The bilge pump uses an automatic float switch. In the off position the float switch activates the bilge pump as needed. This feature is especially useful when the vessel is moored and vacant. There is a built-in lighted icon on the bilge pump switch that illuminates when the automatic mode is activated. The operator should monitor this icon periodically while operating the vessel. If the light activates stop the vessel and investigate the problem. Check the bilge pump before each outing and remove any foreign objects caught in the float switch or bilge pump grating. Never run the bilge pump in a dry mode since it may shorten the pump life. The bilge pump is energized even with the battery switch turned to the “off” position.





### WARNING

GASOLINE VAPORS CAN EXPLODE. BEFORE STARTING ENGINE, OPERATE BLOWER 4 MINUTES AND CHECK ENGINE COMPARTMENT FOR GASOLINE LEAKS OR VAPORS. RUN BLOWER BELOW CRUISING SPEED.

#### Bilge Blower

This switch controls the bilge ventilation blower. The blower's function is to evacuate any fumes and engine exhaust gases that have accumulated in the lower bilge. The blower must be activated at least 4 minutes prior to starting the engine. Check the ventilation ducts and black bilge hose to ensure they are not obstructed. Be careful not to step on the bilge hoses when doing bilge maintenance. The blower should be used below cruising speeds.

#### Horn

This **red or silver** button controls the audible electric horn signal. The horn is located at the starboard forward hull. It is protected by a stainless grille cover. Be sure to test the horn before each outing and learn the horn and bridge signals.



## CHAPTER 4

---

### TYPICAL DC BREAKER & FUSE LISTING

Function	Breaker/Fuse Size	Fuse Or Breaker
Ignition	20	Breaker
Water Pressure Pump	7.5	Fuse
Electric Toilet	30	Fuse
Cockpit Lights	10	Fuse
Docking Lights	15	Fuse
Nav/Anchor Lights	10	Fuse
Stereo Performance	30	Breaker
CO Monitor	2	Fuse
Bilge Pump	7.5	Fuse
Bilge Blower	10	Fuse
Horn	10	Fuse
Automatic Fire Ext.	5	Fuse
Acc. Switch	15	Fuse
12 Volt Outlet	15	Fuse
Main Dash Feed (red)	50	Breaker
Cabin Lights (Head)	5	Fuse
Windshield Wiper	10	Fuse
Stereo (Memory	15	Fuse



## DC Circuit Protection

Typical Main  
Ignition Bkr.



As part of the direct current circuitry protecting the dash wiring a breaker with a reset button is found in the engine area. This breaker protects the engine wiring from overloads. In addition, there is a breaker protecting the ignition switch. If it “pops” due to an overload, it can be reset.



Behind the helm sometimes mounted on a bulkhead accessible through the starboard bow backrest is the main fuse block. It features standard automotive style fuses for a majority of the DC electrical system components.

Carry extra fuses which are available at auto, marine supply stores or the closest Regal dealer parts department. Periodically check the main ground terminations for tightness as well as each circuit spade connector



## CHAPTER 4

---

### Battery Switch-Single Battery

---



Most FasDecks feature a battery switch with 2 functions; off and on. Turn the selector to the “on” position before cranking over the engine. **Never turn the battery switch to the “off” position with the engine running.**


The battery switch is located inside the engine hatch area.

The automatic bilge pump float switch and stereo memory are wired directly to the battery switch. This permits the vessel bilge pump to be energized with the battery switch in the “off” position along with the stereo retaining its pre-set functions and stations.

When leaving the vessel for extended periods it is recommended that the battery switch be positioned in the “off” mode.



### Battery Switch-Dual Batteries



On selected FasDecks a dual battery switch system displays 4 functions; off, 1, all and 2. They stand for off position, battery 1, both batteries and battery 2. This switch is designed to start the engine from either battery if one is low or from both batteries. Simply turn the knob to the desired position before cranking over the engine. This switch features “make before

break” technology which allows the operator to rotate the switch between 1, 2, or all positions with the engine running.

**Never turn the battery switch to the “off” position with the engine running.** It is recommended that you alternate between battery 1 and 2 positions each outing. Both batteries will stay charged this way. *If you need to parallel the batteries to start the engine simply turn the switch to the yellow area.*

Note: Should the batteries be disconnected for a short period of time on the dual battery switch system the stereo memory fuse protects selected stations and other stereo functions. The aft bilge pump fuse protects the bilge pump normally located in the engine compartment area.

Normally, vessels with a stereo performance package or windlass option use this system.

## NOTICE

AVOID DAMAGE TO THE ALTERNATOR  
AND OR CHARGING SYSTEM COMPONENTS.  
NEVER TURN THE BATTERY SWITCH TO THE “OFF”  
POSITION WITH THE ENGINE RUNNING



## CHAPTER 4

---

### FUEL

#### Fuel System-General Information ---

Gasoline Requirements- Use nonleaded gasoline with the following minimum octane rating:

- Inside United States-(R+M)2 (AK)- 87
- Outside United States- (RON) -90

The use of leaded fuels will damage the catalysts and can not be used with catalytic converters.

Gasoline in the United States and other areas is blended with 10% ethanol and is known as E-10 at the pumps. Marine engines used in your Regal boat may be operated with gasoline blended with no more than 10% ethanol and that meets the minimum octane specification.

*Do not use ethanol blends greater than 10%* such as a newer blend for select motor vehicles called E-15. Your marine engine may be damaged by more than 10% ethanol, loss of performance will occur and the engine will not be covered by the engine manufacturer's warranty.



### Fuel System

---

The domestic EPA compliant fuel system consists of an aluminum fuel tank, fuel fill fittings marked “gas” or “diesel”, fuel hoses, fuel vents, anti-siphon valve, fuel filter, fuel gauge, sender and carbon canister. Each one of these components plays an important role in providing an uninterrupted flow of fuel while operating your boat.

### Fuel Tank

---

Current domestic vessels feature an aluminum fuel tank. These tanks are tested several times along with the fuel system components for safety requirements and quality in house and inspected independently by National Marine Manufacturers Association personnel.

### Fuel Fill

---

The fuel fill is labeled “gas” or “diesel” and is located on the deck for more convenient filling. When fueling the boat keep the fill nozzle in contact with the fuel fill pipe since it decreases static electricity. Always use the recommended fuel octane rating as specified in your engine owners manual.

*Extinguish all flame producing agents before fueling!*



## CHAPTER 4

---

### Fuel Vents

---

Currently, EPA compliant fuel tanks are vented through the carbon canister overboard.

Your vessel uses a combo type (internal vented) fuel fill. Both the fuel fill and vent occupy the same cavity under a protective cover. If fuel overflows through the vent the design forces it back into the fuel fill hose and tank.



#### **COMBO FUEL FILL W/ INTERNAL VENT**

A seasoned skipper will hear a distinct sound as the tank nears the “top out” or full mode and may see fuel overflowing back into the fuel

hose through the vent. This helps avoid any overboard spills which harm the environment. There is a key that fits the fuel fill. Use it to secure the fitting from leaking fuel. Store the key in a safe place so it can be easily found for fueling. Check the vent fill screen periodically for debris.

### Anti-Siphon Valve

---

The fuel feed line at the fuel tank is equipped with an anti-siphon valve. The valve is threaded into the fuel tank fitting at the feed line. The valve is pulled off its seat by fuel pump pressure as the engine is cranking or running. It allows a one-way fuel roadway to the engine fuel pump . It prevents fuel from siphoning out of the tank in the event of a fuel line rupture or disconnected fuel feed hose. See the fuel tank maintenance chapter for more specific information on the anti-siphon valve location. Never remove the anti-siphon valve as it is a fuel system safety item.





Clean or replace a clogged or stuck anti-siphon valve. Contact your closest Regal dealer or marine professional for more information

### Fuel Gauge & Sender

---

The dash fuel gauge is only an indication of the on board fuel supply. They are not exact reading instruments. Therefore, use the one third rule discussed earlier for monitoring your fuel supply. *There are not many filling stations on the open waterways!* The gas sender located in the fuel tank uses a float system which sends a signal to the dash fuel gauge as to the fuel tank level.

### Carbon Canister

---

Current domestic EPA compliant fuel systems utilize a carbon canister in the vent line as a means for cleaner air. It is positioned between the vent fitting and and overboard hull discharge. This item requires no maintenance and lasts the life of the fuel system.

### Fuel Filters

---


Fuel filters are installed on marine engines. They are of the spin on type similar to an automobile oil filter. Their main purpose is to trap dirt particles and water in fuel. It is a good idea to keep an extra fuel filter on board along with a filter wrench, catch pan and clean rags for emergencies. Dispose of all fuel residue materials in an environmentally safe fashion. Never use automotive style fuel filters on your vessel.



## CHAPTER 4

---

### FRESH WATER SYSTEM



Your vessel may be equipped with a fresh water supply system. It consists of a water tank, fill/vent, sink, drain hose, faucet and possibly a washdown or transom shower. Water is supplied by a fresh water pump located in the bilge.

WATER FILL




A deck water fill is located on the forward deck area. It features an internal vent. When the water tank reaches full capacity water will be seen cycling from the vent into the fill hose. To energize the system there is a dash switch marked fresh water pump. When activated the switch sends power to the pressure pump which supplies fresh water.

When the water supply line is full a pressure valve switch releases and the fresh water pump stops.

We recommend turning the dash pressure switch “off” when the vessel is left for extended periods. For initial filling of the water system and winterizing refer to the operation and maintenance sections.

TYPICAL WATER PUMP





### **WASTE SYSTEM**

#### **Chemical Toilet**

---

If equipped, a self-contained sanitation device known as a chemical toilet features an upper fresh water tank and a lower deodorized tank. These two components can be separated for waste disposal, cleaning and refilling. The lower tank contains a capacity gauge. Before each outing, check the waste level since it is illegal to dump waste within and extending out to the United States territorial limit.




## CHAPTER 4

---

Be sure to use the proper chemicals and paper in the unit that are biodegradable and environmentally friendly.

Chemical toilet supplies are available at most marine outlet stores and marinas. An optional waste fitting is available that permits a pump out station hookup for removing waste. This procedure saves manually dumping the tank. These pump-out stations can be found at most marinas.

### TYPICAL CHEMICAL TOILET





### **Toilet-(Vacuum) Suction Style Flush** ---



A suction style electric toilet system may be installed as optional equipment. The head uses a combination of suction and water flow from the fresh water tank to clear the head of waste. The system typically uses much less water than other waste systems.

As part of this option a pump-out fitting and overboard discharge accessory are available. Pump-out stations are normally found at most marinas.

To use the toilet make sure the battery switch is energized. At this point power is available to the rocker switch located inside the head. There is a 30 amp automotive type fuse in the fuse block accessible inside the forward starboard bow seat backrest that protects this toilet system.



## CHAPTER 4

---

### *Notes*



# *Vessel Operation*



This chapter explores the many faucets of running your vessel from casting off to docking and handling emergencies. We cover the basics but suggest you read other information on the chapter topics. Also, become familiar with your engine owner's manual since many of the items discussed here are found there in more detail.

## **GETTING UNDERWAY**

### **Pre-Departure Questionnaire**

- Have all fluid levels been topped off?
- Is the fuel tank full?
- Is all safety equipment accounted for and easily accessible?
- Are navigation lights and horn operating properly?
- Is the bilge free of water and does the bilge pump operate?
- Is the engine, stern drive, and propeller in good working condition?
- Is the drain plug in place ?
- Have all passengers been briefed on emergency procedures and seated for departure? Is the boat load balanced?



## CHAPTER 5

---

- Is the operator sober, alert and ready to skipper the vessel?
- Have all passengers been fitted for life jackets?
- Has a float plan been filed and left with a competent person?
- Has the bilge been sniffed and the fuel system leak checked?
- Are the seacocks open (if applicable)?
- Is all communication equipment in good operating condition?
- Has a second person been briefed on operational procedures should the skipper become disabled?
- Are all gauges and electrical switches functioning properly?
- Has weather information been gathered and analyzed?

### Underway Questionnaire

---

- After casting off have all dock lines and fenders been stowed?
- Are all passengers seated and all transom doors closed?
- As skipper are you monitoring the dash gauges for changes?
- As skipper are you on the lookout for changing weather?
- As skipper are you checking for abnormal vibration?
- Is the remote control safety lanyard (if equipped) tightly secured to your belt or clothing?





## *Vessel Operation*

### Disembarking Questionnaire

- Have you removed the keys from the ignition and secured them?
- Have all systems been checked for leaks?
- Has the battery switch been turned to the “off” position?
- Are all seacocks closed?
- Has the fuel tank been filled enough to prevent condensation?
- Is the vessel properly tied and covered with equipment stored?

## FUELING



### **DANGER**

AVOID PERSONAL INJURY OR DEATH!  
GASOLINE IS A HIGHLY FLAMMABLE  
AND EXPLOSIVE MATERIAL.  
PRACTICE “NO SMOKING” AND EXTINGUISH ALL  
FLAMMABLE MATERIALS WITHIN 75 FEET  
OF THE FUEL DOCK.



### **WARNING**

AVOID SERIOUS INJURY OR DEATH  
FROM EXPLOSION OR FIRE  
RESULTING FROM LEAKING FUEL.  
INSPECT ENTIRE FUEL SYSTEM  
AT LEAST ONCE A YEAR.



## CHAPTER 5

---

### NOTICE

SINCE GASOLINE IS AVAILABLE IN SEVERAL GRADES INCLUDING ETHENOL & VARIOUS OCTANE LEVELS, REFER TO THE ENGINE MANUFACTURER'S OWNER'S MANUAL FOR THE CORRECT ONE FOR YOUR ENGINE. USING IMPROPER OCTANE FUEL CAN CAUSE ENGINE DAMAGE AND VOID THE WARRANTY.

### Before Fueling

---

- ☒ Make sure a working fire extinguisher is available.
- ☒ Stop engines and any device that can cause a spark.
- ☒ Disembark all passengers and crew not needed for fueling.
- ☒ Fuel if possible during the daylight hours.
- ☒ Check to ensure nobody is smoking in the boat or near the fueling dock.
- ☒ Close all portholes, hatches and doors to keep vapors from blowing aboard and settling in the bilge.
- ☒ Tie up your boat securely at the fuel dock.
- ☒ Identify the fuel fill. Unfortunately, people have mistakenly filled the water or waste with fuel.
- ☒ Visually inspect all fuel system components before each filling.
- ☒ Avoid using fuels with alcohol additives. They can attack fuel system hoses and cause deterioration.



## Vessel Operation

### During Fueling

- ☑ Keep the fuel nozzle in contact with the fuel fill to guard against static sparks. The fuel fill pipe is grounded through the fuel system wiring to protect against static electricity.
- ☑ Avoid overfilling the fuel tank. Leave room for expansion. Also, if fuel exits the fuel vent indicating the tank is full, this situation is dangerous and unfriendly to the environment.
- ☑ Avoid spilling any fuel. Clean up any fuel accidentally spilled with a clean rag and dispose of it onshore.

### After Fueling

- ☑ Close all fuel fill openings tightly. Use a fuel key if needed.
- ☑ Open all portholes, hatches and doors.
- ☑ Energize the blower for a minimum of 4 minutes.
- ☑ Sniff in the lower bilge and engine compartment for gas fumes. If fumes are detected continue to ventilate until the odor is gone. Look for any traces of fuel droplets or spillage. **Do not start the engines, smoke or run any electrical components except the blower until the fumes can no longer be detected.**



## WARNING


AVOID SERIOUS INJURY OR DEATH!  
THE OPERATOR OF THE CRAFT MUST HAVE  
COMPLETE CONTROL OF THE HELM STEERING  
STATION WHILE THE VESSEL IS MOVING.  
NEVER LEAVE THE HELM STATION UNATTENDED  
WHILE THE VESSEL IS MOVING.



## CHAPTER 5

---

### STARTING & STOPPING



The following general information covers starting and stopping your engine. Read and understand all previous information on remote controls, fueling and operational procedures. Pay particular attention to all labels. Refer to the engine owner's manual for in depth propulsion system information.

#### Starting Guidelines

---

Review all pre-departure information. Before starting your engine make sure all canvas is removed and stored. Start engine only in a well ventilated location to avoid CO buildup. Turn the battery switch to the number 1 or 2 position.

Set the remote control handle in the neutral position. Advance the neutral throttle position as instructed in the engine owner's manual. Connect the safety lanyard to a belt or secure to clothing such as a pants belt loop. Keep passengers seated and away from controls.

Turn the ignition key to the momentarily start position. You will hear the starter cranking over the engine. When the engine starts release the key switch. It will automatically align itself in the run position (ignition).

If the engine does not start, refrain from cranking the engine over 10-12 seconds. Allow the starter and battery a chance to recover. Advance the remote control in the neutral throttle position as recommended in the engine manual. Do not race the remote control in the neutral position.



## Vessel Operation

---



### WARNING

GASOLINE VAPORS CAN EXPLODE. BEFORE STARTING ENGINE, OPERATE BLOWER 4 MINUTES AND CHECK ENGINE COMPARTMENT FOR GASOLINE LEAKS OR VAPORS. RUN BLOWER BELOW CRUISING SPEED.



### CAUTION

TO AVOID ENGINE DAMAGE!  
CHECK THE OIL GAUGE IMMEDIATELY AFTER  
STARTING. IF LOW OR NO READING SHUT DOWN  
ENGINE IMMEDIATELY AND  
INVESTIGATE THE PROBLEM.

### Shifting Guidelines

---



Before shifting into reverse or forward gear positions make sure the coast is clear. When shifting to either gear from neutral make sure the throttle is in the idle position. Allow your vessel to lose all headway before shifting into reverse or forward gear. Practice shifting! You will become more familiar with the procedure and self-confidence will build especially in tight docking situations. Stay alert at all times!



## CHAPTER 5

---

### Stopping

---

Before stopping the engine make sure it is in neutral and idle speed. After an outing let the engine cool down at idle speeds for a few minutes before turning the ignition off. Glance at the gauges one last time to monitor their readings. Do not pull on the safety lanyard verses the ignition switch to stop the engine. Never turn off the engine while in forward or reverse gear since water could enter the engine through the exhaust system and cause extensive damage. The same holds true for running the boat in reverse. Above all, use common sense.

## STEERING

Your Regal uses a rotary or rack style steering system. These systems transfer helm mechanical motion to the engine. There is a hydraulic steering cylinder which with the assistance of a steering pump sends fluid force to the stern drive steering arm changing the course of the boat, depending on the direction the steering wheel is turned.

Since the steering system is the primary link for engine control, it must be periodically inspected and maintained. The hardware at both the helm and engine must be checked regularly for tightness.

Check the steering system for full steering port and starboard before disembarking. Refer to the steering manufacturer's literature in the owner's pouch and the maintenance chapter for more information.




### WARNING

**AVOID PERSONAL INJURY AND PROPERTY DAMAGE!  
LOOSENING OR LOSS OF ONE OR MORE FASTENERS  
MAY CAUSE FAILURE OF THE STEERING SYSTEM  
OR DAMAGE TO THE STEERING CABLE,  
RESULTING IN LOSS OF STEERING CONTROL.  
PERIODICALLY INSPECT THE STEERING SYSTEM.**



## Vessel Operation





## CHAPTER 5

---

### FENDERS

#### Fender Usage

---

Fenders are normally made of a rubberized plastic and are usually filled with air. Most have a fitting like a basketball so they can be inflated or deflated. Fenders are available in a wide range of sizes and shapes to fit both small and large vessels. Fenders are normally designated in inches. They are used between piers, docks, sea walls and the boat. They protect the top sides of the boat from rubbing against rough objects. Most fenders have eyes of attachment which allow a line to be inserted vertically or horizontally. This will permit the fender to be tied off to fit a variety of marina, dock and tidal situations. Be sure the fender is correct for the vessel size. It is a good idea to carry extra fenders but half a dozen is normally an acceptable number. Remember to store fenders on board so they can be easily accessed. Some people incorrectly call fenders “bumpers”.

#### Fender Types

---




There is a variety of fender styles and types, each selected for specified uses. When choosing fenders, contact a marine dealer or supply house. Explain how you moor and use your vessel so they can recommend the best fender type for you. We suggest the type with a fill plug so you can inflate them with a hand pump like the ones used for bicycles.





### DOCK LINE BASICS



Most skippers use dock line terminology fairly loose but there is more to the basics than just bow or stern lines. There are several lines that can be secured to the bow and stern and depending on their direction and use, can be called other names. Remember that “forward” and “aft” refer to the direction that a spring line runs from the vessel, and not where it is secured on board.

#### **Bow & Stern Lines**

---

There is only one true bow line. It is secured to the forward cleat and run forward along the dock to prevent the vessel from moving to the stern. The stern line leads from a rear cleat to a piling or cleat on the dock astern of the vessel. This line keeps the boat from moving ahead. For small vessels these are the only lines needed for normal wind and current conditions. If located in a tidal environment, keep slack in the lines.

#### **Breast Lines**

---

These lines are attached to the bow and stern that lead to nearly right angles from the center of the vessel to the dock. They help keep larger vessels from moving away from the dock, or are pulled in to help people board the vessel. Larger vessels may use bow or quarter breast lines.

#### **Spring Lines**

---



Most small boats use two spring lines although it is possible to have four. They are called the after bow spring and forward quarter spring.



## CHAPTER 5

---

Bow springs are secured at the vessels bow area. Forward spring lines lead forward from the boat to the dock and control movement toward the stern. After springs stem aft from the vessel, and stop movement ahead. Spring lines are used to prevent movement in a berth, ahead or astern. They are really useful in controlling the effects of a real active tidal surge. Spring lines are useful where fenders need to be kept in place against piles.



### Boat Mooring

---

Most boats can be secured to a dock using four lines. The after bow spring is crossed with the forward quarter spring and secured to individual dock cleats or pilings. This ensures longer springs and can be snugged up tighter for more efficient tidal control. Remember, if you only have one piling available, position the vessel so this point is opposite admidships. Run both spring lines to it. These lines will be shorter but still useful.



## *Vessel Operation*

---

The bow and stern lines should be relatively at a 45 degree angle with the dock. The stern line can be attached to the near-shore quarter cleat, but will work more efficiently to the offshore quarter cleat. The longer line will allow the boat flow with the tide with less time checking the vessel.

### **Dock Line Sizing**

---

Most dock lines today are made of nylon, either of twisted rope or braided core and cover. The most often used material is nylon because of its stretching abilities absorbing shock loads. It is chafe resistant for extended life and is easier on bare hands.

The line's size varies with the vessel. Normally, a vessel in the 20' to 40' boats will use 1/2" diameter nylon lines. Larger yachts use 5/8" and 3/4" diameter nylon lines. Smaller boats can use 3/8" nylon lines.

Dock lines need to have the strength to hold the vessel and have enough density to resist chafing. They shouldn't be too heavy that they lose their shock-absorbing capabilities. Use the right size line for the vessel since a line too large for the boat will pull hard against the vessel since it won't be forced to stretch. If the line is too small for the vessel, there is no margin for wear and chafe when under strain.

### **Securing Lines**

---

When mooring your boat, make sure the dock lines are secured at both ends. Depending on your situation you may need to loop the eye splice of the dock line around a piling. Sometimes the mooring line will lead down sharply from the piling to the deck cleat. Loop the eye splice around the piling twice to keep it from being pulled up off the pile. Pull the line through the looped eye if the mooring line is too small to go around the piling twice or too small to fit over once.

If you must drop a line over a piling that already holds another boat's line, run the eye of the line up through the first eye from below, then loop it over the pile. This will allow either line to be removed without disturbing the other. If another line is dropped over yours, simply



## CHAPTER 5


reverse the process. Secure a little slack in the other dock line, then slip your eye up through its loop and over the top of the pile. Your line can be dropped through the other eye.

When debarking from a dock, it is easier to release the line from a cleat or piling, from on board the boat, as soon as you leave the dock. Loop a long line around the cleat or pier and leading both ends on board you can release the line easily. Slip one end around the cleat or pile, the pull it back on board. Release the line without the eye splice, so it will run freely from around the pile without hanging up on the splice.

### STEPS TO STERN DRIVE DOCKING

Inboard/Outboard powered boats are fairly easy to back up and maneuver with a little knowledge and docking practice. One of the most important aspects of the process is to keep your calm in the wake of a busy marina. Basically, the reversing propeller is turned in the direction you want to go by using the wheel.

Some boats tend to be influenced by the wind. When backing down in a crosswind, allow room to maneuver and watch the bow. Try not to overreact or get excited, but use your knowledge and experience. If the wind begins to swing the bow, you need to stop backing, turn the wheel to port and go forward to straighten the boat. Use a quick burst of power but not too much to knock your crew off balance.





A. Stop the boat by shifting in reverse. Put the wheel over to the port and begin backing in. Slow down your speed by momentarily shifting into reverse.


**\* Control in reverse idle position, Outdrive to port.**



## Vessel Operation

<p>B. Continue backing up the boat with the wheel hard to port. Keep an eye on the bow, and begin to straighten the wheel as the boat enters the slip.</p>	
<p><b>* Control in reverse idle position, Outdrive to port.</b></p>	

<p>C. Center the wheel to align the boat parallel with the dock. If the stern is too far from the dock, shift to neutral, then put the wheel hard over to port and then go forward a second or two.</p>	
<p><b>* Control in neutral idle position. Drive centered.</b></p>	

<p>D. When the boat is completely into the dock, stop stern movement by shifting into forward. Put the wheel to port to kick the stern over close to the dock if necessary. Shift into neutral and tie up the boat.</p>	
<p><b>* Control in forward idle position. Drive to port.</b></p>	



## CHAPTER 5

---

### STERN DRIVE MANEUVERING

Inboard/outboard, I/O or sometimes called stern drive boats do not have rudders. The boat uses a steering system that directs the propeller thrust, by turning the stern drive unit where the propeller is mounted. Normally maneuvering the I/O boat is easier than a similar single screw vessel.

Directing propeller energy (thrust) makes slower speed maneuvering easier. The propeller discharge current is turned from one side to the other which results in turning forces. Rudder boats need water to flow by the rudder to be efficient. Stern drive units are designed to have reduced shaft angle, so the propeller does not produce as much unequal blade thrust and resistance as does a propeller on a single screw boat. Large horsepower stern drive boats do produce more thrust and steering torque but your vessel has the advantage of power steering. Below is some basic information on how single stern drive boats handle in normal conditions.

#### Gathering Headway

---

When a stern drive is not moving forward or reverse in the water and the propeller is not turning, (shift in neutral) the boat will not react to the helm steering wheel.

As soon as the vessel is shifted into forward gear the propellers action creates a discharge motion and generates energy in the form of thrust. If the stern drive is centered, the discharge motion is directed straight back causing the vessel to advance forward.

You may notice that if you advance the throttle quickly in initial take-off (make sure you have a firm grip on the wheel), the boat has a tendency to pull the stern of the vessel to starboard. There is a trim tab (also serves as a sacrificial anode) located on the vertical drive housing just to the top of the propeller blade. This trim tab helps compensate for the low speed steering torque. Once the boat increases headway and the propeller is operating in a faster water flow this torque effect



## *Vessel Operation*

---

decreases.

Sometimes the trim tab may need adjustment on stern drive models. Contact your Regal dealer for further information or consult your engine manufacturer's manual.

### **Turning**

---

Once the boat has gathered headway, with the boat planing at the correct bow angle and the stern drive unit and helm straight the boat tends to stay on a uniform course heading. To assure the boat trim angle is correct use the trim gauge as a guide while activating the trim button on the remote control panel.

When the helm wheel is turned to the right or starboard, the stern drive unit is turned in the same direction. The propeller's discharge force is directed to starboard forcing the boats stern to port. Water flowing past the hull strikes the stern drive gear housing in its starboard side, creating additional turning torque. The stern starts a move to port, forcing the bow to starboard.

If the helm is turned to the left or port the stern drive turns to port, the stern of the boat goes starboard as the bow turns to port.

As the vessel operator gains experience, he will better gauge each maneuver and speed situation. In this way he will understand the handling characteristics of his boat. He needs to keep the safety of his passengers in the highest priority.

### **Backing Down**

---

Inboard/Outboard (I/O) boats do not have rudders. The boat uses a steering system that directs the propeller thrust, by turning the stern drive unit where the propeller is mounted. Normally maneuvering the I/O boat is easier than a similar single screw vessel.

If your boat has the steering wheel and stern drive straight with the control in reverse, the stern will be pushed a bit to port by the reversing propeller thrust. This tendency to back to port can be eliminated by turning the stern drive to starboard.




## CHAPTER 5

---

When the vessel begins to gather speed to stern, the water passing by the lower gearcase housing will continue to increase steering torque. If the helm wheel is turned to starboard, and will direct the propeller thrust to port, tracking the stern to starboard.

Wind and current will affect how a vessel backs. Stern drive boats tend to be light displacements and when backing down in a strong crosswind, the bow will tend to fall toward the windward. This may cause steering problems.

Once increased headway is gathered in reverse gear, the force of the lower hull moving through the water is enough to track straight. When backing, the stern will lead as it heads to port or starboard, before the vessel actually starts to turn.



When the control is put in forward gear position, the stern is pushed to starboard; the amount of push depends on the hull design and the amount of throttle advance. See illustration.

### Stopping

---

Remember that your boat does not have any brakes. It uses reverse thrust from the propeller to stop. If the vessel has headway, with the helm and propeller in reverse the propeller thrust is directed backwards, past the lower gearcase of the stern drive.

Depending on how far the throttle is advanced, the discharged thrust may not be strong enough to reverse the water flowing by the gearcase. As the power is increased, the propeller thrust becomes strong enough to stop the flow of water past the lower unit, and, as the throttle is advanced it reverses its flow more completely.

When water is flowing past the gearcase, steering torque is increased, but when the thrust stops the water flow, the boat will not respond to the helm. This is a short lived event and is overcome quickly when the water again flows past the gearcase. Furthermore, added to the energy






## Vessel Operation

---

of the water hitting the lower gear case, the propeller thrust is directed by turning the stern drive, which can add to the steering torque.



The prop tends to throw the stern to port. This is why experienced skippers undertake a portside landing when wind and current conditions permit. They allow the prop to move the stern to port toward the dock. With a forward motion when the helm wheel is turned hard to one side, the vessel pivots around a point about 1/3 its length abaft to stern. See illustration.

## TRIM ANGLE

Stern drive boats have the ability to angle in or out their drive unit in relationship to the transom. This is accomplished by hydraulic shocks located on the stern drive along with an electrical sender unit that reads the drive angle and sends information to the dash trim gauge showing a reading.

### Purpose Of Power Trim

---

The purpose of the power trim/tilt is to enable the operator to change the angle of the drive while at the helm. Changing the angle of the drive or “trimming” provides the following benefits:

1. Improves acceleration onto a plane.
2. Maintains boat on plane at reduced throttle settings.
3. Increases fuel economy.
4. Provides smoother ride in choppy water.
5. Increases top speed.



## CHAPTER 5

---

In short, it is a way of fine-tuning the ride of your boat and will enable you to get the most efficient and comfortable ride possible, whatever the conditions.

### Use Of Power Trim

---

The power trim is normally used prior to accelerating onto a plane, after reaching the desired RPM or boat speed and when there is a change in water or boating conditions. Position passengers and equipment in the boat so that the weight is balanced correctly fore and aft as well as side to side. Trimming will not compensate for an unbalanced load.

To operate the trim, push the switch until the desired bow position is reached. The trim may be operated at any boat speed or at rest. Avoid operating the trim system when running in reverse. Observe the trim/tilt gauge which indicates the boat's bow position achieved by the trim angle of the vertical drive unit. "Bow-Up" corresponds to the upper portion of the trim range on the gauge while "Bow Down" corresponds to the lower portion of the trim range on the gauge.

To determine the proper trim angle, experiment a little until you are familiar with the changes in your boat. The vessel will be properly trimmed when the trim angle provides the best boat performance for the particular operating conditions. A trim position that provides a balanced steering load is desirable.

To familiarize yourself with the power trim, make test runs at slower speeds and at various trim positions to see the effect of trimming. Note the time it takes for the boat to plane. Watch the tachometer and speedometer readings as well as the ride action of the boat.




## Vessel Operation

---

### Operation In “Bow Up” Position

---


The “Bow Up” or out position is normally used for cruising, running with a choppy wave condition, or running at full speed. Excessive “bow up” trim will cause propeller ventilation resulting in propeller slippage. Use caution when operating in rough water or crossing another boat’s wake. Excessive “bow up” trim may result in the boat’s bow rising rapidly, creating a hazardous condition.



### Operation In “Bow Down” Position


---

The “Bow Down” or in position is normally used for acceleration onto a plane, operating at slow planning speeds, and running against a choppy wave condition. It is also used when pulling water skiers, tubers, kneeboarders, etc. In this position the boats’ bow will want to go deeper into the water. If the boat is operated at high speed and/or against high waves, the bow of the boat will plow into the water.



### Operation In “Level” Position

---



In normal running conditions, distribute passengers and gear so boat is level. At or below cruising speeds, trim the vessel for optimum performance. The trim gauge will show somewhere in the center of the gauge. This position will also enhance running visibility and overall stability. Again, each outing provides different wave, load and running conditions. Be prepared to make trim changes as needed.



## CHAPTER 5

---




### CAUTION

THE BOAT TRIM SHOULD BE ADJUSTED TO PROVIDE BALANCED STEERING AS SOON AS POSSIBLE EACH TIME YOU GET UNDERWAY. SOME BOAT/ENGINE/ PROPELLER COMBINATIONS MAY CREATE BOAT INSTABILITY AND/ OR HIGH STEERING TORQUE WHEN OPERATED AT OR NEAR THE LIMITS OF THE “BOW UP” OR “BOW DOWN” POSITIONS. BOAT STABILITY AND STEERING TORQUE CAN ALSO VARY DUE TO CHANGING WATER CONDITIONS. IF YOU EXPERIENCE BOAT INSTABILITY AND/OR HIGH STEERING TORQUE, SEE YOUR AUTHORIZED REGAL DEALER.

### Shallow Water Operation

---



Operating your vessel in shallow water presents various hazards. You are more apt to hit a submerged object such as a rock, sand bar, stump coral, or other unmarked objects.


Pay close attention to your charts for descriptions of any shallow areas along with marked submerged objects. Always post a lookout when operating in shallow water. Trim your outdrive up as needed to

provide adequate draft. Set the alarm on your depth sounder and travel at a speed that will keep the boat level in these shallow areas.

**If your boat strikes a submerged object stop immediately and check for hull, outdrive and propeller damage.**



## Vessel Operation



### CAUTION

DO NOT RUN ENGINE ABOVE 1000 RPM  
WITH THE STERN DRIVE TRIMMED  
FOR SHALLOW WATER MANEUVERING SINCE THE  
STERN DRIVE IS OUT BEYOND THE GIMBAL RING  
SIDE SUPPORT BRACKETS.  
OPERATING IN ABOVE MANNER COULD PRODUCE A  
DANGEROUS STEERING CONDITION OR COULD  
DAMAGE THE STERN DRIVE COMPONENTS.



## CHAPTER 5

---

### ANCHORING



Selecting the correct anchor is an important decision. The anchor style in part depends on the usage and boat type. Regal boats designate an anchor type and or model. Some models incorporate chain, line with an optional windlass. Contact an authorized Regal dealer for more information.

Anchoring is easier with another person on board.

First be certain that the line for the anchor is properly attached, to avoid losing the anchor and anchor line overboard.

For most anchors to perform more efficiently, you should attach 3 to 6 feet of chain. The chain will stand up to the abrasion of sand, rock, or mud on the bottom much better than a nylon line. It should be galvanized to reduce corrosion. Next, attach a length of nylon line to the other end of the chain.

The nylon will stretch under a heavy strain cushioning the impact of waves or wind on both the boat and the anchor.

To anchor, select a well protected area, preferably with a flat bottom. Contrary to modern belief, you do not throw the anchor over while the boat is making headway, or moving forward. In fact, the bow of the boat should be brought slowly backward, while easing the anchor slowly over the side of the boat until it hits the bottom. To “snub the line” means to stop its outward “pay” or movement. Usually the length of anchor line used should be 5 to 10 times the depth of the water.


After you have anchored, check your position with landmarks if possible. You need to continue to monitor these landmarks to make sure you are not drifting. Since anchoring can also be an emergency procedure, the anchor and line should be readily accessible.

For increased holding power in windy conditions, two anchors are sometimes set. If your primary anchor drags, you can run out your secondary anchor without picking up the primary one. The important thing is to lay them out at an angle. When setting two anchors, make sure they are fastened to separate rodes or cleats. This is done in case you need to adjust one later so the line is accessible.



## Vessel Operation

If two anchors are used ahead of a boat, make sure to set the rode at an angle than in a straight line to reduce the chances of tangeling as the boat moves in wind and current. See the above illustration.



## TOWING

In case you find yourself aground or in need of a tow, or should you want to tow another vessel, keep in mind that you **never use deck hardware or cleats to secure lines for towing!**

Deck hardware is intended for mooring and anchoring, and is not designed to withstand the strain and pull of towing. Rather than tie the line to your cleats on deck, it is suggested that you tie a bridle by passing a line completely around the hull of your boat to avoid damage.

When towing, always stand clear of a taut line, as any type of line breaking under stress can be extremely dangerous. The preferred line for towing is double-braided nylon, as it has sufficient elasticity to cushion shock loads. Move slowly and cautiously.



## CHAPTER 5

---

### Law Of Salvage

---

The Admiralty law sometimes referred to as the salvage law was founded primarily on English law fundamentals and basically says that a vessel distressed, in danger of flounder, if rendered assistance from a towing company or private agency, can be forced to relinquish a portion of the vessels' worth for the assistance received.

#### **NOTICE**

IN THE EVENT YOUR VESSEL IS IN DISTRESS,  
PRIOR TO ALLOWING ANY TOWING COMPANY OR  
PRIVATE AGENCY THE RIGHT TO PASS A LINE TO  
YOUR VESSEL, BE SURE TO ESTABLISH THAT YOU  
DO NOT AGREE TO ANY SALVAGE RIGHTS.  
ESTABLISH WITH THE CAPTAIN OR OPERATOR  
THAT YOU WISH TO BE ASSISTED IN A CONTRACT  
BASIS AND ESTABLISH A PRICE.  
OF COURSE IN CERTAIN SITUATIONS, YOU MAY  
NOT HAVE THIS OPTION.

**USE YOUR BEST JUDGEMENT!**





### DANGER

AVOID DEATH OR SERIOUS BODILY INJURY!  
DO NOT USE DECK HARDWARE INCLUDING  
CLEATS FOR TOWING.

### Knots

Knots are useful in docking, towing and other emergency situations. Learning to tie knots requires practice. As they say “Practice makes perfect”. Some of the knots used in boating are the square, bowline, anchor bend, clove hitch, figure eight and half hitch. There are several periodicals available that explain various knots and how to tie them effectively. An experienced skipper will know the basic nautical knots and will use them when on the water. Take the time to know the basic knots.

**Figure 8 Knot  
Tied To Cleat**



A useful knot to learn for general docking is the figure eight with one end reversed. By turning the free end of the line back under, the knot can be released without disturbing the boat. After some practice one person can secure a vessel easily to a dock or pier in a variety of weather conditions. This knot normally is used to tie the bow and stern. Then the vessel can further be fastened by tying the spring line in the figure eight knot. Wrap it around the cleat 2 or 3 times.



## CHAPTER 5

---

### EMERGENCIES

Always be ready to help others on the water if possible, but do not take any unnecessary risks. Use equipment to save a life, but do not risk a life to save equipment. Consult earlier information in this manual concerning accidents, etc. Also, read other literature concerning on the water emergencies. Be alert and prepared!

#### Fire

---

Fire aboard a vessel can spread quickly and can cause tremendous alarm among everyone. Most fires can be prevented by keeping the bilge free from oil and debris. Keep all equipment stowed and maintained in working order. Carry a backup fire extinguisher on board. If something becomes a possible fire hazard, remove that possibility at once.

Never use water on gasoline, oil or electrical fires. When you dump water on an electrical fire a you can be shocked since water conducts electricity.

Follow these instructions if a fire breaks out:

- A. Fit everyone aboard with a life jacket. Turn off the ignition.
- B. Try to keep the fire downwind. If the fire is to the stern, head the bow toward the wind. If forward, put the stern to the wind.
- C. If the engine should catch fire, shut off the fuel supply. Usually there is a fuel tank access that you can crimp the fuel feed line.
- D. Use a hand fire extinguisher. Make sure to point it at the base of the flames. Use short bursts and sweep the extinguisher side to side.

**Remember : (4 lb. extinguisher discharges in 20 seconds)**

These actions help prevent the fire from spreading to other parts of the boat. You can extinguish fires quickly if you act swiftly. Have a plan of action in motion in case a fire breaks out.



### **FIRST AID**

Knowing first aid can save lives. A first aid kit and the ability to use it are important ingredients for the safety of a skippers' passengers, crew and vessel. Having confidence and competence in handling medical emergencies on board is a must for the skipper. Invest your time in a first aid course available at the American Red Cross.

### **CPR (Basic Life Support)**

---

If someone is seriously injured have someone call for help while the injured person is being attended.

Check for possible danger signs; loss of breathing, unconsciousness, severe bleeding and heartbeat. If you determine the individual is not breathing or unconscious place the victim on their back on a hard surface and do the following:

1. If unconscious, open the airway. Neck lift, head lift or chin head lift.
2. If not breathing, begin artificial breathing. Pinch the nose. Give 4 quick breaths. If airway is blocked, try back blows, abdominal or chest thrusts and finger probe until airway is open.
3. Check for pulse. Begin artificial circulation. Depress sternum 2". 15 compressions rate 80 per minute. 2 quick breaths. Continue uninterrupted until advanced medical support is available.

**Follow up immediately with medical authorities!**



## CHAPTER 5

---

### HYPOTHERMIA

Hypothermia is a condition where the body temperature decreases because the body can't generate enough heat to maintain its normal temperature. It can be serious and usually occurs where victims have been immersed in water (under 68 degrees) for extended periods of time. If you encounter a possible hypothermia victim call for help on the radio and get the person out of the water.

Symptoms are:

1. Shivering that if condition is advanced may stop.
2. Confusion, clumsiness or slurred speech.
3. Rigid muscles.
4. Semiconscious to unconscious.

#### **Treat hypothermia by the following:**

- ☐ Remove wet clothing.
- ☐ Monitor the victim's pulse and breathing.
- ☐ Rapidly apply heat to the body core by using blankets, naked bodies or warm water.
- ☐ Do not give the person any food or drink.
- ☐ Do not warm the arms and legs. Warming of these extremities can be fatal.

**Follow up immediately with medical authorities!**



### **ENVIRONMENTAL AWARENESS**

There are numerous vessels operating on our waterways on a daily basis. Each boat has an impact on our environment. Boat operation habits, marine sanitation, and maintenance all play a role in a delicate battle to keep the ecosystem clean. Each of us has a role in doing our part as an environmentally conscious skipper to conserve our waterways.

The National Marine Manufacturer's Association lists their top ten of Eco-Boating Practices as follows:

1. Observe all regulatory agency policies regarding marine toilets.
2. If equipped with a holding tank, use marina pump-out facilities.
3. If used, make sure bottom paints are legal and ecosystem friendly.
4. Use only biodegradable cleaning agents.
5. Dispose of all garbage and litter on shore properly, not on the water.
6. Don't top off fuel tanks. Leave expansion room. Clean up spills.
7. Watch your wake and propeller wash.
8. Make sure your engines are well tuned and maintained.
9. Control your bilge water.
10. When fishing, practice the "catch and release" principle.

Follow these basic practices when on the waterways. Treat the environment in a way that you would like to be treated.



## CHAPTER 5

---

### *Notes*



# Equipment Operation

## INTRODUCTION



This chapter assists the operator in understanding typical standard and optional equipment which may be featured on your vessel.

*A portion of the equipment described may not be installed on your boat or the pictorials may not exactly match your*

*components. A portion of the Regal boat illustrations in the owner's manual may represent typical examples.*

Regal is constantly improving its product line and therefore may make changes in vendors, parts and specifications at any time without notice. **For further equipment information, refer to the individual vendor literature provided in the owner's packet. Read and understand all equipment information before attempting to use the components.**



## CHAPTER 6

---

### Anchor Windlass

---



If installed the optional windlass features up and down deck foot switches and 11 pound stainless steel anchor complete with swivel. A rocker switch located at the helm controls power to the windlass and foot switches. The unit normally is outfitted with 100' of galvanized anchor chain.

A 50 amp breaker for overcurrent protection is used.





## Equipment Operation

---

### Automatic Fire Extinguisher

---



The automatic fire extinguishing system if installed is normally located in the bilge at the engine aft end. See the illustration. The system uses an environmentally friendly agent FE-241 which has been approved by the EPA to replace the old Halon agent. This

system is formulated only for use in the engine compartment of your vessel. FE-241 is to be used with gasoline fuel systems only since the agent will not “stall” diesel engines. This could cause a fire to re-flash.

#### Operation-Automatic

Automatic fire extinguisher systems are not nor are they intended to be explosion suppression devices. **Boat owners still need to take normal precautions for checking gasoline fumes and using blowers.**

Read the information regarding the dash and manual operation portions of the fire extinguisher system. When the system actuation starts you may hear a loud sound similar to that of small arms fire, followed by a rushing air sound.



## CHAPTER 6

---



The system will show actuation whenever the ignition key is ON and the indicator light is OFF. The actual actuation time when a fire occurs is dependent on the severity of the fire.

When the automatic fire extinguisher activates IMMEDIATELY SHUT DOWN ALL ENGINES, POWERED VENTILATION (BLOWER), ELECTRICAL SYSTEMS AND EXTINGUISH ALL SMOKING MATERIALS. DO NOT OPEN THE ENGINE COMPARTMENT IMMEDIATELY.

Allow the agent to “soak” the compartment for a period of time and wait for hot metals and any fuels to cool before inspecting for the fire cause. Premature opening of the engine compartment allows an in-rushing of oxygen and could result in a flash-back. When the engine compartment is opened have portable fire extinguishers ready.



### WARNING

AVOID SERIOUS INJURY OR DEATH!  
DO NOT BREATHE FUMES OR VAPORS  
CAUSED BY A FIRE AS THEY ARE  
HAZARDOUS AND TOXIC.



## Equipment Operation

### Operation-Manual



If a fire has started in the engine compartment where the automatic fire extinguisher system is located, do not wait for automatic activation. Release the system manually. Close any opened hatches leading to the engine compartment, shut down all forced ventilation devices, engines, and electrical components.

Remove the safety pin from the "Fire" T-handle, and

pull firmly on the "FIRE" cable handle which will activate the fire extinguisher unit in the engine compartment. A loud "rushing" or air" sound may be heard. Complete discharge will take several seconds. Do not open the compartment immediately! Keep the compartment closed for a period of time sufficient to allow the agent to soak all areas of the protected space. This allows hot metals and fuel to cool.

KEEP ADDITIONAL MARINE APPROVED HAND HELD FIRE EXTINGUISHERS ON BOARD AS BACKUPS. THESE UNITS SHOULD BE SERVICED PERIODICALLY.




## WARNING

AVOID SERIOUS INJURY!  
ACCIDENTAL DISCHARGE COULD OCCUR  
DURING HANDLING, INSPECTION,  
OR WORKING IN THE ENGINE COMPARTMENT.  
WEAR EYE PROTECTION AT ALL TIMES!



## CHAPTER 6

---



Premature opening of the compartment could cause a reflash. When opening the engine compartment for inspection have hand held portable extinguishers ready.

Inspect the pressure gauge and system before and after each outing. Refer to the maintenance chapter for caring for your fire extinguisher system.

The illustration above shows the actuator not discharged at the top and one which has been discharged at the bottom.



## Equipment Operation

---

### Battery

---



The battery is the heartbeat of the on-board DC (direct current) electrical system. It supplies the power to crank over the engine (650 or 1000 Cold Cranking Ampres) and to operate the electrical equipment through the engine charging system.

The battery is a wet-cell design with maintenance free features. The battery system features a red boot to protect the positive terminal and a battery tray with hold downs. Make

sure the red (positive) boot is completely covering the positive terminal of the battery. The terminal nuts should be checked periodically for tightness and corrosion. In colder climates battery removal for the winter months is to be considered. Contact your closest Regal dealer for recommended battery service schedules.




## CHAPTER 6

---

### Battery Switch Circuitry

---



Battery  
Switch

Your FasDeck may feature a single battery on-off switch. The battery switch is located in the engine compartment.

Select vessels use a dual battery switch which have the ability to use both batteries in parallel to start an engine. The selector switch needs to be positioned in the all or yellow decal area on the switch

before cranking over the engine. In the same locale a 50 amp breaker normally protects the main harness feed wiring (red).

The stereo memory fuse (15 amp) located near the battery switch protects the stereo memory circuit and holds the stereo settings for a predetermined time frame should the stereo lose power due to a dead battery.

The aft bilge pump fuse (10 amp) protects the aft bilge pump and if the stereo performance package is installed a 30 amp breaker normally protects it.

**Note: Should a breaker “pop” or fuse “blow” determine the cause of the problem before resetting the breaker or replacing the fuse. When replacing breakers and fuses use the correct type and amperage.**



## *Equipment Operation*

---

The battery switch features ignition protection technology which makes it safe to use in the engine compartment. It features “on” and “off” positions.

To energize the battery switch simply rotate the knob to the “green” or “on” position. Current will now be available at the helm to start the engine and run the accessories. To denenergize the battery switch rotate the knob to the “red” or “off” position.

Note: **Never** turn off the battery switch with the engine running as damage to the engine charging circuit will occur.

With the battery switch in the “OFF” position (recommended for docking and mooring for extended periods) the aft bilge pump continues to function in the automatic position and the stereo memory continues to function as normal.

As




## CHAPTER 6

---

### Bilge Pump/Automatic Float Switch

---



Before each outing check the operation of the bilge pump and automatic switch. With the dash switch in the automatic position manually pick up the automatic switch or you can activate the switch by throwing a bucket of water in the bilge. The automatic switch should energize the bilge pump. Periodically, check for debris around the grates of bilge pump base. The bilge pump and automatic switch are located in the bilge in front of the engine.

By holding up the end of the float switch, you can periodically test the unit. With the automatic float switch held up the bilge pump should activate itself.





## Equipment Operation

### Bow Filler Cushions



BOW FILLER CUSHIONS

Dual bow filler cushions are featured on select FasDeck models. Normally these cushions are stored inside the port or starboard bow areas. Place support bars across the center openings matching each one to fit

the width. Once in place, insert filler cushions. Use the reverse procedure to disassemble the bow filler area.





## CHAPTER 6

---

### Bow Scuff Plate

---



Selected models feature a stainless steel bow scuff plate. This stainless steel plate protects the fiberglass bow area from trailer roller scuffing which may occur during the boat launching process.

The innovative de-

sign protects the boat bow when pulling up anchor especially in foul weather conditions.



## *Equipment Operation*

---

### **Bow Walk-Through Doors**

---




Walk-through bow doors are great for foul weather. With the tonneau cover in place, simply open the doors and pull across the bow opening. Secure shut by lining up the latch and pushing down to catch both doors. Snap the tonneau cover to the fasteners provided on the center windshield frame.

To store, fold against the walk-thru and secure with snaps, snap strap or latch.



## CHAPTER 6

### Canvas



BIMINI TOP AND BOOT

To install a typical *bimini* top/sunshade on FasDeck models without the optional power tower unzip the top boot and remove it from the bimini

top. Store it for future use. Unroll the canvas and install both of the front bimini canvas/sunshade straps. Adjust the straps to make them equal in length. Install the aft support stanchions and place them in the arch mount located on the deck. Lock each stanchion with a pin. Insert the pin completely through ball and socket mount and lock.

**Note:** Sometimes canvas straps are noisy when underway. To help deminish the noise simply twist the straps as needed and relatch.

**Note:** While cruising the bimini top/sunshade should be zipped in the boot to avoid damage due to wind and sea conditions as well as from possible higher cruising speeds.




### CAUTION

TO PREVENT BODILY INJURY AND PROPERTY  
DAMAGE, DO NOT TOW BOAT  
WITH BIMINI TOP/SUNSHADE UP.  
TOW BOAT WITH ALL CANVAS ZIPPED IN BOOT.  
FOR WATER USE,  
PLACE THE BIMINI TOP IN THE CRUISE POSITION.  
CHECK ALL FASTENERS.



## Equipment Operation

### Canvas-Bimini Top/Sunshades w/Power Tower



TYPICAL INSTALLATION



## CHAPTER 6

---

### Cockpit Cover

---



TYPICAL COCKPIT COVER

The cockpit cover installs over the windshield and snaps to the deck. To install the cockpit cover, note that at the bow end of the cover there is a seam on the inside which separates the port and starboard sides. Align this seam with the center snap

below the windshield. Complete snapping the canvas to the outside and then down each gunnel to admidships.

This type of canvas cover requires several cockpit poles. Their purpose is to keep the canvas tight and water out of the interior. Notice on the underside of the cover there are areas of reinforced canvas material. These are for the cockpit cover poles. Each pole is adjustable by opening it to the desired length and tightening the thumb screw. You may find it helpful to mark the poles so you can install them in the same location each time.

**Note: The cockpit cover is not designed to be used at highway speeds. Do not tow your Regal boat with a cockpit cover installed as personal injury and/or property damage could result.**

A suitable travel cover for highway towing is available for your particular model. They can be ordered from your authorized Regal dealer. For further information refer to the following pages regarding travel covers.





## Equipment Operation

---

### Canvas-Bow

---



TYPICAL TONNEAU COVER

The bow cover (sometimes called a tonneau cover) is used mainly for mooring purposes. To set it up, fasten the cover starting at the front center snap working your way around the port and starboard sides. When you reach the aft section fasten the snaps to the center windshield. Install the pole at the center of the cover at the designated point which is designed to fit the pole. Adjust the pole to a point where water will be drained off the cover and the canvas is tight. Tighten the pole.

**Note: The bow cover is not designed to be used at highway speeds. Do not tow your Regal boat with a bow cover installed as personal injury and/or property damage could result.**

You may want to purchase a suitable travel cover designed for highway use before towing your vessel. They can be ordered from your authorized Regal dealer.



## CHAPTER 6

### Canvas- Travel/Storage Cover

**▲ WARNING:** To prevent damage to your boat and/or cover please read and understand instructions before attempting to use cover.

It features:

1. **ON SOME MODELS:** A special anti-pooling system is included to prevent large puddles from ruining your cover.
2. The SurLast® all-weather fabric was chosen to allow stability, water repellency and breathe-ability.
3. The Vacu-Hold™ system allows trailering at highway speeds (65 mph) without billowing or buffeting.
4. The new ratchet and drawstrap type attachment will allow easy, tight and secure installation.

#### CARE, WARRANTY AND INSTALLATION INSTRUCTIONS

**Hint-**To properly install ratchet strap system.

1. Pull the webbing through the channeled ratchet cylinder and tension while ratcheting to "start" the webbing.
2. Tension the ratchet with about 5 lbs. of pressure (pinky finger). Pull the sides of the cover to even the webbing throughout. Re-tension about 5 lbs. (the ratchet should be tight on the side of the boat lever, perpendicular to the hull).
3. Crank the ratchet approximately 5 full additional times to add tension (based on an 18' boat).
4. Check boat webbing for tension during stops while trailering. (webbing may stretch during first installation and use CHECK OFTEN).

**▲ WARNING:** Readjust and retighten the cover after trailering and before storage. To prevent pooling do not allow snow and ice to accumulate on the cover. Never trailer at speeds above the speed limit.

**CARE INSTRUCTIONS-** Wash with warm soapy water (while installed if possible) and allow to air dry. For stubborn stains, mild detergent is recommended.

Storing the boat in constant direct sunlight will shorten the life of the cover and the components used to construct it. We recommend storing the boat in a location that exposes it to some sun and also shades it throughout the day. Preferably morning sun and afternoon shade.

**WARRANTY-** This cover includes a two-year warranty from date of purchase against any defects in material or workmanship. If you incur any problems or have any comments please contact your dealer or call Commercial Sewing Customer Service directly at (860) 482-5509.

#### PROPER INSTALLATION-

##### A. Pooling System Installation:

**Note:**

Install anti-pooling system as per illustration putting the front webbing to the cleats, standing pole upright. Pull the other two webbing straps to the two rear cleats. Tighten adjustable buckle strap, until the pole stands upright.

##### B. Proper Cover Installation:

- Place cover on boat starting at front, use cleats as buttons to keep cover in place, work toward back over pooling system until back cleats are "buttoned" in place.
- Maneuver in place until cover fits over gunwale. Check the symmetry. Connect the confidence straps through the openings on the swim platform to the "U" bolts. Disconnect velcro wrap around ratchet. Begin ratcheting by unzipping ratchet pocket(s) and pulling ratchet(s) handle in right-to-left motion until zippered ratchet pocket no longer sags but rests against the hull.
- Pull on webbing to even the tension around the cover and again tighten the ratchet until it does not sag but rests against the boat. Tighten ratchet four to five more times. The ratchet should be very hard to pull with your pinky finger. Zip ratchet pocket closed and connect velcro wrap around ratchet pocket. **On some models:** Connect the rear strap tiedowns in the back of the boat.

**Note:** Proper installation and operation of this cover requires that it be very tight at the gunwale. Retighten as necessary before, after and during stops while trailering. **BE SURE** cover is installed below gunwale before final ratchet adjustment. ZIP ratchet pocket closed for final installation.

**▲ Warning:** Zippered ratchet mechanism should be hand tightened only. Do not pry or attempt to operate ratchet mechanism with any type of tool.


#### REMOVAL-

- Disconnect velcro wrap & zip open ratchet pocket.
- Follow instructions on ratchet label to release pressure.
- Once pressure is released pull out webbing to allow simple future installation, then close handle and ZIP POCKET closed (this is important to prevent damage in future installation).
- Disconnect holddown straps. Remove and fold cover working from rear to front.

#### ANTI-POOLING POLE STORAGE-

- Disconnect anti-pooling pole from either the front (colored webbing) or back.
- After disconnecting collapse poles by pushing buttons and telescoping them down.
- Wrap webbing around poles.

ISBLANKMOORING/RO







## Equipment Operation

---



TYPICAL TRAVEL/STORAGE COVER



RATCHET STRAP

Ensure the ratchet strap is tight and the velcro flap is closed on the travel cover before pulling boat at highway speeds. Tie cover securely to bow and stern eyes. Do not exceed manufacturer's 65 miles per hour speed limit. Once on the road periodically pull over and check cover, ratchet strap and pertinent hardware for tightness.



## CHAPTER 6

---

### Cockpit Carpet

---



Cockpit carpet features a forty ounce weight with an “aqua tread” slip resistant backing. As required, snaps are installed.

When storing the carpet, roll it up verses folding it. If the carpet gets wet dry out before storing it. Unsnap individual

fasteners carefully when storing carpet to help protect the snaps from pulling out. Do not yank on the carpet to remove it.

**Note: Always roll-up the cockpit carpet and store it in a locker before towing the vessel on the highway. This will prevent the carpet from blowing out of the vessel.**



## Equipment Operation

---

### Cockpit Table

---

A cockpit table may be installed in the cockpit. When using the table ensure the nylon sleeve is installed in the table pedestal located under the table. It locks the table and provides additional stability. If a table is installed, table receivers are located in select cockpit locations as shown below.



TYPICAL TABLE



TYPICAL RECEIVER



## CHAPTER 6

---

### Cockpit Refreshment Center

---



The cockpit refreshment center is available on select models. The unit features a Corian countertop with stainless steel sink, strainer, and FRP cabinet. All parts are made to resist the harsh marine environment.

There is a fresh water tank and pressurized water system with a 12 volt

pump. It features a fresh water filter which can be easily removed for periodic cleaning. See the section on the fresh water system for further maintenance information.

See the winterization chapter for vessels in colder climates. Follow the procedure for “laying up” the fresh water system to prevent system and/or component damage.



## Equipment Operation


### Drain Plug



## CAUTION

TO PREVENT VESSEL FROM SINKING,  
INSTALL DRAIN PLUG!

TIGHTEN-CLOCKWISE



Your boat is equipped with a garboard style drain plug. Make sure it is tightly installed before launching. *Tighten with a wrench.* Do not use your fingers alone. After your outing while the boat is angled on the ramp remove the drain plug to help eliminate any bilge water accumulation or run the

bilge pump. When the water stream is diminished, remove foreign objects stuck in the drain hole. Pull the drain plug if storing the boat for extended periods especially in colder climates.



TYPICAL DRAIN PLUG



## CHAPTER 6

---

### Depth Finder/Sounder

---



In theory the depth finder picks up a bottom signal sent through a transducer to the helm gauge unit which is converted to readings in feet, meters, or fathoms and displayed on the gauge. The unit features shallow or deep water alarms, both of the audio and visual type, and keel offset.

#### General Description

If equipped the depth finder will display depths of 2-199 feet, 1-92 meters, or 1-54 fathoms. To accommodate greater depths to be displayed in the “ft” feet mode the depth sounder will automatically change to “F” fathoms mode and continue to display depths to around 54 fathoms.

When the depth decreases below 200 feet the display will return to the “ft” mode. Limits on depth will vary depending on transducers and bottom conditions.

If the reading is less than 19.9 feet, meters, or fathoms, 1/10th increments will be displayed. If the reading is more than 19.9 feet, all readings will be in whole numbers.

The depth finder features an audible and LCD displayed depth alarm with adjustable shallow and deep limits and a depth below keel offset feature. These settings once made are stored in memory and will remain even if the battery is not connected.



## Equipment Operation

---

### Operation

---

**Power On.** When the helm is powered up by the key switch 12 volt DC energy is available at the depth gauge along with the remainder of the instrument cluster. You do not need to press the “ON/OFF MODE” keypad.

The LCD will illuminate showing the depth and the type of units selected; feet (FT), meters (M), or fathoms (F). To deactivate the depth sounder, hold the “ON/OFF MODE” keypad for 4 seconds. If you press the “ON/OFF MODE” keypad again the unit will be reactivated.

**Depth Alarm. *Shallow mode:*** If you press the “ON/OFF” MODE” keypad again the “SH” shallow depth alarm setting is displayed. This is the shallowest water that will energize the alarm. Press and hold the up or down arrow keypads to adjust the reading to the desired depth.

**Depth Alarm. *Deep Mode:*** By pressing the “ON/OFF MODE” keypad displays again the “DP” deep depth alarm setting. This is the deepest water that will energize the alarm.

Press and hold the “UP” or “DOWN” keypads to adjust the reading to the desired depth. When the shallow depth setting is read by the depth finder, the “SH” will flash on the LCD and the audible alarm will sound in a rapid sequence. When the deep depth setting is read by the depth finder the “DP” will flash on the LCD and the audible alarm will sound at 2 beeps per second.

**Note:** To fully deactivate the alarm, reset it to zero. Pressing the “ON/OFF MODE” keypad temporarily deactivates the alarm. To reactivate the alarm press the “ON/OFF MODE” keypad until the depth reading appears.



## CHAPTER 6

---


**Keel Offset.** By pressing the “ON/OFF MODE” keypad again displays the “KL” keel offset setting. It can be set so the depth finder shows the depth below the transducer or the depth under the keel. Press the “UP” or “DOWN” arrow keypads to adjust the reading to the desired depth no further than 19.9 feet.

An example would be if the keel bottom is 3 feet below the transducer and you desire the depth sounder to read the depth below the keel, the display should be adjusted to read 3.0 FT.

**Note:** Once the keel offset is programmed, the shallow and deep alarms will be energized by the depth under the keel.

**Units.** Pressing the “ON/OFF MODE” keypad again displays “UN” on the LCD indicating the units mode.

Press either the up or down arrow keypads to set the units desired to (FT) feet, (M) meters, or (F) fathoms. Once these units are set, they will remain the same for all modes. By pressing the “ON/OFF MODE” keypad again returns the depth finder to normal operation.



**Note:** Near the keel (center of boat bottom) the depth sounder transducer is located. It bounces a constant signal off the bottom and sends it to the dash head unit. Never use bottom paint on the hull side of the transducer since it will effect the unit's operation.





## Equipment Operation

---

### Engine Hatch

---




Your vessel features an engine hatch latch which when turned 90 degrees will open the compartment. The hatch uses a set of hydraulic rams to aid in a smooth opening and closing operations. Accessing the hatch is a real plus when performing pre-cruise and maintenance functions. To close the engine hatch lower it and turn the latch to lock it in place.

Note: To aid in opening or closing the hatch, use your hand to push the hatch unit down while turning the latch in the closed or open position.



## CHAPTER 6

### Fresh Water System (Pressurized)




FRESHWATER TANK 24 FD

Fill Hose

Feed Hose

Vent Hose



FRESHWATER TANK 27 FD

Fill Hose

Vent Hose

Feed Hose

Hold Down Bracket



Outgoing Water To  
Equipment

Pressure Pump

Water Filter

Incoming Water  
From Water Tank

Note: The fresh water tank level should be topped off before leaving the dock. Ensure the water quality before filling the tank at the deck or bow fill point. To fill the system follow the steps on the following page.



## Equipment Operation

---

1. Unscrew the “water” fill deck fitting. Fill the fresh water tank with approximately 10 gallons of fresh water with a suitable container or hose. Make sure the water is safe for drinking.
2. Find the dash fresh water pump switch (normally marked accessory) and energize to the “on” position. You will hear the pressurized water pump fill the entire system with fresh water. When full the pump pressure switch will stop the pressure pump.
3. Open the faucet to allow any air to escape. Close the faucet when there is a steady stream of water without air. You will hear the pressure switch shut off the pump indicating the system is full.
4. After these initial procedures, “top” the system off with fresh water.
5. Check for system leaks as evidenced by the pressure water pump recycling even though no water is being used from the components.
6. It is a good idea to turn “off” the fresh water pump switch after each use and especially during extended times of non-use.
7. Clean the pressure water filter periodically by disassembling the filter element and rinsing in fresh water. Ensure the pump switch is off. Replace and check for leaks. For parts, contact an authorized Regal dealer.



### CAUTION

AVOID PRESSURE PUMP BURN OUT!  
DO NOT ACTIVATE THE FRESH WATER  
SYSTEM WITH THE WATER TANK EMPTY.



## CHAPTER 6

---

### Gas Vapor Detector

---

If equipped, a gas vapor detector is a state of the art fume monitoring and alarm system. It is a highly effective detector of engine compartment gasoline fumes from unburned hydrocarbons emitted from faulty exhaust systems and hydrogen battery vapors.

The unit operates with a head unit at the helm, a sensor located in the bilge installed just above the normal accumulation of oily bilge water. A .5 amp buss fuse (for overcurrent protection) is located behind the helm head unit.

#### Operation

The display panel at the helm features 3 windows. The left window is a green power on indicator. The right window is an opening for the Var-a-Brite light intensity detector. The center window is the red warning indicator.

To check for fumes, turn the ignition key to the "on" position. The green power on LED will show on and the red warning LED may light momentarily to indicate a warm-up period for the sensor. The alarm horn will not sound during this period.

If a vapor build-up reaches 10-20% of lower explosion limit the red warning LED will light indicating a detection of fumes. Should this condition last for longer than 10 seconds, the alarm horn will sound. The alarm will continue as long as vapors are present. The alarm horn may be silenced by pressing the "mute" switch, the red warning light will remain on until the vapor problem has been resolved.

**NOTE: THE PROBLEM SHOULD NEVER BE CONSIDERED CORRECTED UNTIL RED WARNING LIGHT IS OUT.**

If the red LED begins to glow softly and or intermittently, it is an indication that the gasoline vapor build-up is beginning to occur and you can anticipate a full alarm momentarily.



## Equipment Operation

---

Immediately have all passengers and crew exit the passenger compartment. If an explosion or fire should occur, the probability of injury will be greatly reduced if no one is in a confined area of the vessel.

### IN THE EVENT OF AN ALARM:

NOTE: IT IS IMPORTANT TO UNDERSTAND THAT AN ALARM WOULD NOT OCCUR UNLESS A PROBLEM EXISTED. CAREFULLY CHECK ALL FUEL LINES, GAS LINES, AND ANY OTHER POTENTIAL SOURCES OF GAS LEAKS.

#### Testing System



The head unit can be tested for electrical continuity by pressing the “Test” switch. The Red LED will come on. The light will glow as long as the switch is held down. If the test switch is held down longer than 10 seconds the horn will sound and the “MUTE” switch must be pushed to silence the horn.

Unplug the sensor wire from the helm display head while the unit is powered up. The Red LED will

illuminate and within 10-15 seconds the alarm horn will sound. If warning Red LED fails to come on & horn fails to sound, remove display head & return to factory for repair.



## CHAPTER 6

---



### **WARNING**

AVOID INJURY AND DEATH!  
GASOLINE VAPORS CAN EXPLODE!  
OPERATE BLOWER FOR AT LEAST 4 MINUTES  
AND CHECK THE ENGINE COMPARTMENT  
AND BILGE FOR GASOLINE VAPORS.  
RUN BLOWER BELOW CRUISING SPEEDS.



## *Equipment Operation*

---

### **Gray Water System**

---

The gray water system option consists of a holding tank along with a deck mounted waste pump-out fitting. Water from a cockpit refreshment center or head sink normally exits the boat at a through hull fitting. With the gray water system any used potable water is stored via the drain hoses to a holding tank. Once the gray water holding tank is full it is pumped overboard by a pumping station vacuum pump much the same way a toilet holding tank is pumped out.

This system is environmentally friendly as it keeps many soap related alkalines and harsh detergents out of the water supply. Check with local and state agencies regarding gray water regulations.



## CHAPTER 6

---

### Ladder-Bow

---



Selected models feature a stainless steel bow ladder. Open the bow deck hatch to access the ladder. Unfasten the strap and pull the ladder up and over the bow. Check to ensure it is extended completely.

Close the hatch. Use the integrated hand hold to exit and enter the vessel. Keep body parts clear of the hinged top.

*Remove the ignition keys and store them away while people are using the bow or stern ladder along with the swim platform! Remember, the captain is responsible for the safety of his passengers.*





## Equipment Operation

---

### Ladder-Transom

---



Your vessel is equipped with a stainless steel transom boarding ladder. Be sure all body parts are clear of the ladder when folding the ladder up or down and repositioning it under the swim platform. Be sure to read and adhere to any written warnings posted at the helm area or swim platform regarding ladder

load limits or CO (carbon monoxide poisoning).

**Always turn the engine off and remove the ignition keys while people are in the water near the boat, or using the swim platform and/or bow and transom boarding ladders.** Also, insist people always use the ladder and **never use the stern drive ventilation plate for entering and exiting the vessel.** Again, safety first!

Periodically rinse the ladder frame and rungs to keep the device clean and in a non-slip condition. Salt water usage will require even closer attention to cleaning cycles over fresh or brackish water.

**Note: Before cruising, ensure the ladder is fastened properly under the platform.**



## WARNING

AVOID BODILY INJURY DUE TO MOVING PARTS!  
KEEP ALL BODY PARTS CLEAR OF THE LADDER'S  
MOVING AND ROTATING PARTS!




## CHAPTER 6

---

### Lighting-Docking

---

If equipped, docking lights are integrated into the hull. They are very useful for night docking and maneuvering. To operate turn on the helm switch marked “docking lights”.



### Lighting-Courtesy

---

LED cockpit courtesy lights are standard equipment on your vessel. They are located along the cockpit at various locations. To operate, turn the “cockpit light” helm switch to the “on” position. They provide a blue color light which is very pleasant for night time usage.



## Equipment Operation

---


### Lighting-Stern/All Around

---



STERN LIGHT

The stern light is normally stored in the ski locker. It must be used between dusk and dawn. It is controlled by the navigation-anchor light switch located at the helm. Simply remove the light from the holders and install it in the stern light receptacle located at the aft starboard deck and activate the top portion of the switch.



Boats with power towers use an all-around light which is mounted at the center of the tower. It is controlled by the navigation-anchor helm switch. It must be used between dusk and dawn and must be lighted when the vessel is stopped or anchored at night.

### Lighting-Towing

---



Located on the upper transom are a set of integrated red reflector lights. These lights can be used to enhance the rear lighting while trailering the vessel. They add aft lighting to the boat above the normal trailer lights add a safety factor for night towing.

There is a harness that fits into a plug located at the bow area. The other end must be connected to the trailer harness to complete the circuit.



## CHAPTER 6

---

### Lighting-Underwater

---



As an option light bars w/ LED bulbs make up the underwater lighting system. The lights are located on the transom on both port and starboard sides of the stern drive. There is a dash switch for energizing the lights. The un-

derwater lights circuit protection fuse is found at the under dash fuse block and is rated at 10 amp.





## Equipment Operation

---

### PowerTower

---

As part of the innovative design the tower hinges forward for tight overhead clearances such as bridges and restricted storage situations. The tower is a FRP product offered in black or white gelcoat. The bimini/sun shades are attached via stainless steel bows to the power tower.



Typical Power Tower With Tops In “Up Position


The tower hinges forward for tight overhead clearances such as bridges and restricted storage situations. **For highway towing the powertower shall be in the complete upright position and all canvas shall be in their dedicated boots. All attached canvas bow hardware shall be checked for tightness before and after towing.**

**Cockpit carpet shall be rolled up and stored in a dedicated cockpit locker.**



## CHAPTER 6

---



Typical Power Tower Shown In Up Position



Typical Power Tower Shown In Forward Tilted Position



## Equipment Operation



Typical Hinging  
Mechanism



The PowerTower can be hinged forward for clearance purposes or for highway towing. Normally one of the accessory switches at the helm area is designated for the tower. It connects to a lift motor and a set of hydraulic rams that raise or lower the tower.

*Before energizing the switch pay special attention that all passengers maintain a safe distance from the tower hinge mechanisms located at the base of the power tower on the deck.*

As the operator energizes the switch to hinge the tower forward visually monitor the port and starboard deck to ensure all passengers are clear of the hinge mechanism. This same procedure applies for lowering the mechanism to the original position.



### WARNING

WHEN OPERATING POWERTOWER  
KEEP ALL BODY PARTS CLEAR  
OF TOWER HINGE MECHANISMS.





## CHAPTER 6

---

### Power Tower Board Racks

---



As an option sport tower racks mount on both port and starboard sides of the power tower to carry wakeboards, aquatic toys, etc. Strap equipment in place by using the tie downs built into each rack. Periodically check the hardware for tightness.





## Equipment Operation

---

### Regal Vue Display

---

#### Product Information

RegalVue is a touch screen display solution. It is designed for instrumentation on electronically controlled engines communicating via SAE J1939 and NMEA 2000. The display is a multi-functional tool that provides GPS tracking, Multimedia Display, Speed control and rider profiles. In addition, enables equipment operators to view many different engine parameters and service codes.



#### Care and Maintenance


General maintenance is not required; however a soft cloth can be used for cleaning the units. Window cleaner or alcohol can also be used to clean the glass portion of the display. Do not use harsh or abrasive cleaners on the unit.

Note: We continually strive to bring you the highest quality, full featured products. As a result, you may find that your actual Regal Vue display screens may be slightly different than what is represented in this manual at the time of printing.




## CHAPTER 6

### INSTALLING/REMOVING MEMORY CARD




As an option Regal Vue is installed as shown. Each unit is outfitted with a memory card with predetermined geographical regions. Should the operator want a different memory card access to the Regal Vue panel is outlined below.



FASTENERS

1. The battery switch should be turned to the “off” position before starting to work behind the dash. At the rear of the Regal Vue display (behind the dash) you will see a small compartment with 2 allen head type fasteners. Remove both fasteners with the panel cover to access the memory card compartment.



2. Insert a fingernail or small slotted screwdriver into the memory card end tab. Push up to disengage the card. Next, pull down on the card to remove it from the card slot.



## *Equipment Operation*

---



3. Install the new card with written side out into the card slot. Make sure the memory card seats into the card slot.
4. Reinstall the panel cover and tighten the allen head screws. There must be a small “crush” on the cover gasket to ensure a tight fit but do not over tighten the fasteners.
5. Energize the battery switch and test the display unit.



## CHAPTER 6

### Basic Navigation Features

All product features are easily accessed through Quick Access Keys and Touch Menus and Touch Screen commands.



### Quick Access Keys

The following controls are accessed via the Quick Access Keys:

- Stereo
- Video
- Diagnostic Messages
- Settings
- Maps
- Speed Control
- Engine Statistics
- Home

### Touch Point Commands

Touch key commands provide additional features and navigation shortcuts. Depending on the current screen being displayed, they may appear as icons or a vertical control bar. Touch key commands are

Touch point commands are used throughout the RegalVue display to:










- Access features
- Edit settings
- Navigate to deeper levels
- Navigate the screen



# Equipment Operation

**NOTE:** Touch points are defined by words or graphics that are highlighted with a soft glow.



## Touch Screen Navigation

Widget	Description
	<p><b>SHOW DATA BAR</b> – Touch this to display the engine status at the bottom of the screen. The data bar provides the following information:</p> <ul style="list-style-type: none"> <li>Fuel Level</li> <li>Oil Pressure</li> <li>RPM</li> <li>Speed</li> <li>Engine Temperature</li> <li>Voltage</li> </ul>  <p><b>NOTE:</b> This data bar can be customized in the Data Bar Settings.</p>
	<b>HIDE DATA BAR</b> – Touch this to remove the data bar from the bottom of screen..
	<b>DECREASES VALUE</b> – Touch this to decrease the value in the selected field.
	<b>INCREASES VALUE</b> – Touch this to increase the value in the selected field.
	<b>DONE</b> – Touch this to save updated settings and exit the screen..
	<b>CANCEL</b> – Touch this to leave the screen without accepting any changes.
	<b>CONTINUE</b> – Touch this to move to the next page of settings if there is one.
	<b>BACK</b> – Touch this to move to the previous screen. The changes will be saved.



## CHAPTER 6

---

Widget	Description
 	<p><b>ZERO OFF</b> – Touch this to turn ZERO OFF on or off. This function is found in the lower left corner of every page of the display.</p> <p><b>NOTE:</b> When cruise is turned <b>OFF</b>, the driver must pull the throttle back slightly. This shows "throttle authority". It must be done in order for the system to release the cruise set point and return to speeds not governed by the Zero Off commanded speed.</p>




## Equipment Operation


### Quick Access Key Features

This section describes the features accessed through the Quick Access Keys located to the left and right of the display.


#### Stereo Feature

Stereo Display can be accessed by pressing the Quick Access Key 

This feature provides universal control to the stereo mimicking all the controls of a standard remote control. This includes iPod and Thumb Drive music.









#### Stereo - Touch Commands

Touch Command	Description
 SOURCE >	<p><b>SOURCE</b> – Touch this to select a connected source. RegalVue supports the following devices:</p> <ul style="list-style-type: none"><li>• FM radio</li><li>• AM radio</li><li>• Sat</li><li>• iPOD</li><li>• DVD</li></ul> <p>Touching and holding [SOURCE] will turn the device On or Off.</p>



## CHAPTER 6

---

Touch Command	Description
	<p><b>MENU TBD</b></p> 
	<p><b>VOLUME - / + --</b> Touch the - to lower the volume and + to raise the volume.</p>
	<p><b>PREV TRACK</b> – plays the previous track current CD.</p>
	<p><b>NEXT TRACK</b> – plays the next track of the current CD.</p>
	<p><b>PLAY/PAUSE</b> – toggles between Play and Pause modes when a CD is playing.</p>





## Equipment Operation

### Video Feature

Video can be accessed by pressing the Quick Access Key

This feature provides the ability to play the DVD player or a connected video camera or other device.





### Video Feature - Touch Commands

Touch Command	Description
	DVD – Touch this to use the DVD player. The following screen is displayed: 
	VOLUME - / + -- Touch the - to lower the volume and + to raise the volume.



## CHAPTER 6


---

Touch Command	Description
	<b>PREV TRACK</b> – plays the previous track current CD.
	<b>NEXT TRACK</b> – plays the next track of the current CD.
	<b>PLAY/PAUSE</b> – toggles between Play and Pause modes when a CD is playing.
	<b>VIDEO 1</b> – Touch this to play a video device connected to the auxiliary input.  <b>NOTE:</b> There are no controls associated with this screen. Use the connected device to control the video.



## Equipment Operation

### Diagnostic Message Feature

Press the  button to access the diagnostic messages. This feature provides a view into the engine behavior. If there is a fault, it will be displayed on this screen with a description of the fault and corrective action to take. In addition this screen provides the:

- **Source** – identifies the component having the fault; engine 1, 2, or auxiliary.
- **Status** – indicates whether the fault has been corrected.
- **SPN** – "Suspect Parameter Number" - fault code  
If not translated into text by the display, see the engine manufacturer's literature for the definition of the SPN number.
- **FMI** – "Failure Mode Indicator" - fault code  
The FMI is defined by SAE J1939. If not translated into text, see the SAE standard, or the engine manufacturer's literature.
- **Count** – The number of times the event has been flagged.

Touch [Get Faults] to retrieve diagnostic messages. Use the Left and Right arrows to scroll through the messages.

- **Description** – Most common SPN's and FMI's have text for the description stored in the display. If there is no text, then this SPN and FMI must be defined by referring to the engine manufacturer, or the SAE J1939 standard.

**NOTE:** This field is only used with certain brands and models of engines.

- **Correction** - suggested action for correction.











## CHAPTER 6

### GPS Feature

The Maps feature can be accessed by pressing . The Maps feature displays map data, Latitude and Longitude coordinates, time, and speed.












### GPS Display - Soft Key Commands

Screen Element	Description
	COMPASS – North-up compass. .
	ZOOM IN – Touch this to zoom in on the location of the cursor.
	ZOOM OUT – Touch this to zoom out on the location of the cursor.
	LEFT ARROW – Touch this to move the cursor to the left on the map.
	RIGHT ARROW – Touch this to move the cursor to the right on the map.



## Equipment Operation


Screen Element	Description
	UP ARROW – Touch this to move the cursor up on the map.
	DOWN ARROW – Touch this to move the cursor down on the map.
	TRACKING – Touch this to access the Tracking feature. 
	CURRENT POSITION – used to return to the current boat/satellite position after having moved the cursor to another location.
	CREATE WAYPOINT – places a marker or 'waypoint' on the map to mark a favorite location after displaying the following confirmation message..
	CLEAR TRACK – displays the following confirmation message before deleting the current track information.
	SAVE TRACK – displays the following confirmation message before saving the current track information.
	ZOOM/PAN – displays the positioning screen.



## CHAPTER 6

### Profiles Feature


\*\*\*This feature is only available for boats equipped with Zero Off speed control. See dealer for upgrade.\*\*\*



**NOTE:** the above screen will be displayed if this boat is not equipped with Zero Off.






Rider profiles can be accessed by pressing the Quick Access Key

### New Rider Profile

Function	Description
	<p>To create a new profile touch [+ NEW RIDER]. The keyboard is displayed.</p>  <p>Type a name for the new rider using the touch keyboard and touch <b>[DONE]</b>.</p>



## Equipment Operation


Function	Description
	 <p>On this screen, the name and set speed can be edited. Touch <b>[SAVE]</b> to save the profile or touch <b>[CANCEL]</b> to cancel the new rider profile.</p>
 EDIT	<p><b>EDIT</b> – Touch this to Edit the name and/or the set speed of the current rider. Touch <b>[SAVE]</b> to save the changes or <b>[CANCEL]</b> to return to the Rider list screen.</p>
 CHANGE RIDER	<p><b>CHANGE RIDER</b> – Touch this to select a different rider.</p>  <p>Touch the Up or Down arrow to scroll through the list of currently set up riders. Touch the <b>[SELECT]</b> the rider profile is displayed.</p> <p>Touch the <b>[X]</b> to delete the profile from the unit. The DELETE confirmation screen is displayed.</p>  <p>Touch <b>[YES]</b> to continue the deletion process. The profile is removed from the selection list. Touch <b>[CANCEL]</b> to return to the selection screen without deleting the profile.</p>



## CHAPTER 6

---

### Engine Statistics

The engine statistics can be accessed by pressing the Quick Access Key 

This feature displays a summary of the engine statistics. It includes:

- Engine Temperature
- Oil Level
- Fuel Level
- Speed
- Engine RPMs
- Trim Tabs
- Battery Charge








## Equipment Operation

### Settings Main Menu

When the settings key  is pressed the Main Menu is displayed. From the Touch Menu on the right of the screen, specific settings can be selected using the touch keys. Touch key areas are indicated by a soft glow highlight.



The following settings are available:

- GPS Utilities – In this area, are the following:
  - Waypoint Manager
  - Track Manager
  - Chart/Time Setup
  - Depth/Position Settings
  - GPS Status
- User Settings
- Data Bar Settings
- System Information
- Dealer Settings




## CHAPTER 6

---

### GPS Utilities

The GPS Utilities include the following:

- Waypoint Manager
- Track Manager
- Chart and Time Setup
- Depth and Position Settings
- GPS Status



### Waypoint Manager

Waypoints allow you to mark specific locations by latitude and longitude. Once the waypoints are established, the Waypoint Manager allows you to associate an icon with them for identification. You can delete a single waypoint by using the **DELETE** key, or all of them at once with **DELETE ALL**. Pressing the **GO TO WPT** key displays the GPS screen containing the currently highlighted waypoint.




## Equipment Operation



- **Waypoint List** – displays a list of the waypoints that have been set. Use the **UP** and **DOWN** keys to highlight the desired waypoint.
- **Waypoint Icon** – allows you to assign one of four different icons to any of the waypoints listed.

### Track Manager

Multiple tracks for displaying on the GPS map can be set up. The Track Manager allows you to select tracks to 'show' on the map or 'hide' a map not currently used. You can **DELETE** one track or **DELETE ALL** at the same time.



Touch **[DONE]** when finished.

### Chart and Time Setup


This menu option allows you to set up viewing options for the GPS Display.



## CHAPTER 6

**Chart Setup Parameters** – use the **PLUS/MINUS** soft keys to select the information you want displayed on the GPS screen.

**Time Setup Parameters** – is used to select correct time zone and clock mode for either 12-hour or 24-hour time formats. You can also enable DST (Daylight Savings Time) by using the **PLUS/MINUS** soft keys to select the box.



### Depth and Position Settings

This feature allows you to define the amount of detail to display for longitude and latitude information on the GPS map and depth display.






## Equipment Operation

---

### GPS Status

Shows the location of the satellites.





## CHAPTER 6

---

### User Settings

User Settings provide options to specify viewing preferences. Pressing **PREV** and **NEXT** navigates through the options, and **UP** and **DOWN** scrolls through the selections for each option.



Touch Commands for User Settings include:

**Up Arrow or Down Arrow**—increases or decreases values within a field.

**DONE** – saves the current values and exits.

#### Brightness

You can set the brightness control by using the **UP** and **DOWN** soft keys to change the settings in 5% increments until the desired brightness is achieved.

#### Audio Intensity

The Audio Intensity feature allows you to set values to automatically increase or decrease the audio volume according to what speed you are traveling.

#### DVD VIDEO CUTOFF

Speed restriction setting. This shuts off the DVD/Video when the boat reaches a predetermined speed. This can be disabled or set to a speed from between 5 to 45 mph in five mile per hour increments.


### Data Bar Settings

The data bar is a popup that shows the engine statistics at a glance. The data bar has some settings that can be customized. They can be edited here. It can be shown at the bottom of



## Equipment Operation

most screens or be hidden from view. Select the number of desired slots to be displayed (3, 4 or 5) on the first screen shown below and touch continue:



After the number of slots have selected, choose the statistics to be displayed and the order in which they are to be displayed on the second screen:




Touch [DONE] when finished and the data bar will have the appearance chosen.

**NOTE:** The fuel level indicator is always displayed and always displayed first.



## CHAPTER 6

### System Information



Component	Version	Part No.
Application	The version number of the application installed on the hardware.	The part number for the application.
OS	The version number of the operating system installed on the hardware.	The part number for the operating system.
Bootloader	The version number for the bootloader.	The part number for the bootloader.
Software	The version of configuration software loaded on the machine	N/A





# Equipment Operation

---

## Troubleshooting

### General Troubleshooting Guide

**Display appears not to work or doesn't come "ON".**

1. Display could be in *sleep* mode. Touch a key on the keypad to activate the display.
2. Check for loose connections at battery and display unit.
3. Check for reversed polarity on the power connections.
4. Verify battery has a minimum voltage of 6 Volts.

**Display resets or goes "OFF" when starting engine.**

1. Check display supply wires are connected properly to battery.
2. Verify battery is charged properly.
3. Check battery for efficient starter current.

**Display has no backlight.**

Contact your Regal service center.

**Display has no keypad backlight.**

Contact your Regal service center.



## CHAPTER 6

---

### Seating-Bucket Operation

---

The bucket seat features a handle mechanism that operates multiple seat functions. The separate handles prevent the seat from rotating and sliding fore and aft during operation of the vessel. This provides the operator with a safety margin. Do not alter the seat slide mechanism. To adjust the seat slider follow the instructions and refer the illustration.

1. To adjust fore and aft seat positions, pull up on handle “A”, slide seat to desired location and release the handle. The slide will lock in position.
2. To rotate seat and adjust the drag control feature for rotation, pull handle “B” up to the horizontal position and release. The handle will maintain the horizontal position. The seat is now able to be rotated 360 degrees. To increase the drag on rotation, turn handle “C” clockwise to desired resistance. To decrease drag, turn handle “C” counterclockwise.
3. To lock the rotational feature, push handle “B” down and the positive quick lock feature locks for the next available locking spline.

**Always use the positive lock feature when your vessel is underway.**




### CAUTION

TO PREVENT BODILY INJURY!  
PERIODICALLY CHECK AND TIGHTEN  
THE MOUNTING BOLTS  
BETWEEN THE SEAT SLIDER  
AND THE BUCKET SEAT BOTTOM  
ALSO, CHECK THE FLOOR INSERT BOLTS.



## Equipment Operation



TYPICAL BUCKET SEAT LOCK MECHANISM



## CHAPTER 6

---

### Seating/Bow-Arm Rests

---



ARM REST- UP POSITION

Some vessels feature bow seating arm rests. They utilize a tracking system that permit the arm rests to slide down. To extend the arm rest simply pull up on the bottom of the arm rest until it snaps in the lock position.



ARM REST- DOWN POSITION

To unlock the arm rest tracking mechanism simply push up on the black knob with one hand and while holding the knob up, push down on the front end of the arm rest until it folds down into a vertical position. Keep body parts away from the track itself to avoid injury.



Other vessels feature bow seating arm rests where you push down on the arm rest to engage.



To fold away pull up on the arm rest.



## Equipment Operation

---

### Seating/Multi-Position UltraLounge

---

The FasDeck products feature a 6 position UltraLounge. Using the handle on the port forward lower section of the seat you can push or pull on the lever which will change seat positions from a seat to a lounger.



FORWARD FACING SEAT  
POSITION



AFT FACING SEAT POSITION



### CAUTION

PREVENT FALLING OVERBOARD!  
DO NOT OCCUPY THE SUNDECK  
REAR FACING POSITIONS  
WHILE THE BOAT IS MOVING.



## CHAPTER 6

---



AFT FACING SUN LOUNGE WITH  
FLAT HEAD REST

The backrest can be positioned forward or aft to form a horizontal sun lounge head support or the headrest can be angled up for aft viewing as shown in the lower photo.



AFT FACING SUN LOUNGE WITH  
TILTED HEAD REST





## *Equipment Operation*

---

### **Sirius Satellite Radio**

---

Sirius® satellite radio is an available option on all Regal models. Sirius satellite radio features over 120 channels of music entertainment completely commercial-free along with sports and news channels. Sirius emphasizes the music and entertainment you want. Channels use the most updated digital filtering available for the clearest sound. Sirius uses three satellites flying over the United States for coast to coast coverage with high elevation angles. The result is a clearer line of sight and less signal blocking.

The system consists of the stereo receiver (sometimes called the head unit), Sirius radio tuner and antenna. With these components and an active account (6 month initial subscription initialized by the customer after delivery) your Sirius system should be activated. Following are the activation steps to be taken:

- A. Unit must be completely installed and the antenna must have a clear view of the sky.
- B. Turn on the radio and go to satellite mode.
- C. Confirm reception by tuning to SIRIUS WEATHER & EMERGENCY//CHANNEL 184. If you are not receiving Channel 184, please refer to the radio manufacturer owner's manual.
- D. Call SIRIUS sales support 1-866-580-7234 or customer care 1-888-539-7474
- E. Please have your name, address, phone number and the SIRIUS ID#ESN available for the agent.



## CHAPTER 6

---

### Ski Tow/Pylon

---



A water sports ski pylon is located center line at the stern deck. Double loop the line first through the hole and then around the ski pylon and cinch it tightly. This procedure helps to keep the line intact when there is no strain on it.

Always appoint a person to keep their “eye out” for the tow line when the vessel is running to prevent the line from being caught in the propeller.

If your vessel is equipped with a power tower a universal roller type pylon may be positioned at the top of the tower. This provides a higher angle to enhance water sport activities.





## *Equipment Operation*

---

### **Speed Control Devices**

---

Regal FasDecks offer a variety of speed control options. These may include a Regal View Display, Regal Vue Display with cruise control (Volvo only), Perfect Pass (cruise control), not applicable with Volvo-Regal Vue combo.

Refer to the speed control device operator's manual for information regarding the operation of these components.

Regal Vue is covered earlier in this chapter.



## CHAPTER 6

---

### Stereo/CD Player- Fusion

---



Regal boats feature Fusion® marine stereo audio systems. Fusion stereo systems are designed and engineered to perform to the highest standards in the harsh marine environment. The head units use easy to read displays, oversized rubber buttons and controls for easier operation on a moving vessel. Being at the leading edge in stereo technology the head unit opens to a truly

unique internal iPod dock. The iPod dock handles many generations of iPods through a set of sleeves. These sleeves hold the iPod in position ensuring ease-of-use and protect the iPod from the marine environment.

The standard MS-IP700 provides 70 watts x 4 total output.

All components including the speakers comply with the international IP waterproof standards. Selected optional system components include an amplifier and additional speakers.

The system utilizes a 15 amp automotive style fuse located behind the stereo head unit.

See the amplifier and remote information for vessels equipped with the optional stereo performance package and remote controls.

Note: As standard equipment on Regal sport boats the stereo functions from the auxiliary key switch position which is located to the left of the normally “off” position. Here the stereo can be operated without the typical draw on the ignition circuit which normally occurs when the key switch is in the “on” position. Refer to the Fusion owner’s manual located in the owner’s information pouch for more detailed information.



## Equipment Operation









### BUTTON DESCRIPTION

BUTTON	DESCRIPTION
	<b>Power</b> Press to turn the unit ON/OFF
	<b>Menu</b> Press to enter menu system and press again to return to previous screen
	<b>Radio</b> Press to access the Radio source FM - AM - SAT
	<b>CD (MS-CD500 only)</b> Press to access the CD/MP3 source
	<b>AUX (MS-IP500 only)</b> Press to access Auxiliary source
	<b>iPod.</b> Press to access the iPod source Press again to access AUX [MS-CD500]
	<b>Back/Previous.</b> <b>Short Press:</b> To select the previous track in CD/MP3 or iPod mode. Start automatic tuning down the frequency spectrum in the Tuner mode. <b>Press and hold:</b> Rewind in CD/MP3 or iPod mode. Start manual tuning down the frequency spectrum in the Tuner mode.




## CHAPTER 6

BUTTON	DESCRIPTION
	<b>Forward/Next</b> <b>Short Press:</b> To select the next track in CD/MP3 or iPod mode. Start automatic tuning up the frequency spectrum in Tuner mode. <b>Press and hold:</b> Fast-forward in CD/MP3 or iPod mode. Start manual tuning up the frequency spectrum in the Tuner mode
	<b>Play/Pause</b> Play/Pause track in CD/MP3 and iPod mode.
	<b>Mute</b> Mutes all sound in all zones
	<b>Clock</b> Displays the clock
	<b>Display Brightness</b> Press to enter display brightness setting. Turn the <b>Rotary Encoder</b> to adjust
	<b>Rotary Encoder</b> The rotary encoder operates similar the click wheel on an iPod.  Turn to adjust volume or move up or down a menu structure.  Press the <b>Rotary Encoder</b> to select a highlighted option.

### RESET BUTTON

- Press the Reset button to reset the unit to the factory settings






# Equipment Operation

## OPERATION

The MS-CD500 and MS-IP500 features Clock battery back up and Eprom technology. This allows it to be completely disconnected from the vessels +12volt Voltage supply [Battery switch] with No settings lost.

### Power

Press  to turn the unit ON/OFF

## RADIO OPERATION

### Region Selection

Press  and turn  to select setup - Press to enter - turn the  to select tuner region  
Press to enter and press to select region



### Band Selection

Press the  to select band  
FM - AM - SAT



### Tuning

There are 15 presets available per band.

### Seek Tuning



1. Press the  or  to scan to the next station.
2. The selected station will be auto saved into the station presets menu.

### Manual Tuning

1. Press and hold the  or  for 3 seconds to enter. The manual tuning icon will flash on screen.
2. The selected station will be Auto saved into the presets menu.

**Note:** Once the station is selected the station will be stored into the pre-set menu and the manual tuning icon will be removed.

### Auto Tuning


Press the  and turn the  to navigate to the "Search Station" function. Then press to search and store.

**Note:** Automatic tuning mode will erase all other presets already stored for the selected band and will automatically store the station into the Preset menu in numerical order.

### Recalling a Preset Station

1. Select the required band. FM - AM - Sat

2. Press the  and then turn the  select the "Presets" option and press to enter.

3. Turn the  to select the desired preset and press to select



## CHAPTER 6

### SIRIUS SATELLITE RADIO - USA only - SIRIUS TUNER NOT INCLUDED

#### SIRIUS ACTIVATION


##### Activating Your Sirius Tuner

You must activate the SIRIUS tuner before you can begin to receive the SIRIUS Satellite Radio Service. In order to activate your radio subscription, you will need the SIRIUS ID (SID) which uniquely identifies your tuner. The 12 digit SID is displayed on the LCD on initialization. MS-CD500 and MS-IP500 will display the SID on Channel 0. Power on your system and make sure that you are receiving good signal you are able to hear audio on the SIRIUS Preview channel [Ch-184]




##### Note:

Have your credit card handy and contact SIRIUS on the internet at <https://activate.siriusradio.com/> and follow the prompts to activate your subscription. You can also call SIRIUS toll-free at 1-888-539-SIRIUS [1-888-539-7474] Once activated, you will be able to begin enjoying SIRIUS Satellite Radio's digital entertainment and can tune to other channels.

#### SIRIUS OPERATION


Press the  to select Sat Radio


#### SIRIUS NAVIGATION

Press the  and enter the menu, turn the  to navigate the functions and press  to select.

- **Channels**  
Select the desired channel (listed in channel order) and music preference
- **Category**  
Select the desired genre type. (The unit will only play the selected option)
- **Favourites**  
Add your favourite channel to your favourites list by selecting "add favourite".  
[Maximum 15 channels]  
Remove channels by selecting "Remove Favourite" select "ALL" or the individual channel and

push Enter 

Exit MENU by pressing 

- **Parental Mode**  
**Pin #**  
Turn  to select number and press to enter; repeat to enter the 4 digit code. (Default is 0 on 1st time use)  
NOTE: Must be entered before the following items are operational.  
**Mode on/off**  
Turn On to initiate parental locking of selected channels etc; turn Off for full channel access  
**Lock / Unlock**  
Select the channel to be locked or unlocked  
**Skip / Un-skip**  
Select the channel to be bypassed from the menu  
**Change Pin**  
Personalise your Pin number. [4 digits max]

4.






## Equipment Operation

### SELECTING A SOURCE


Press the desired source button:

- |   |          |  |
|---|----------|--|
|  | Radio    | AM/FM/Sat  |
|  | CD       | CD/MP3 (MS-CD500)  |
|  | iPod/AUX | Press once for iPod (MS-IP500)<br>Press twice for AUX (MS-CD500) |
|  | AUX      | Aux direct (MS-IP500)  |






### ADJUSTING THE VOLUME

- Turn the  to adjust the volume (Zone 1 Default)

### ZONE VOLUME

- Press the  to select zone. Press again to step through zones.  
Zone 1 - All zones - Zone 2 - Zone 3 - Zone 4

### GENERAL SETUP

- Press the  and rotate the  to select the Setup menu. Press to enter.
- Turn the  to select the function and press to enter
- Turn the  to adjust and press  to return.

### SETTINGS

#### Treble

Adjusts the treble to the speakers

#### Bass

Adjusts the bass to the speakers

#### Balance

Adjusts the audio balance from left to right

#### Contrast

Adjusts the display contrast.

#### Key Sound

Press to turn ON / OFF

#### AUX Configuration

AUX ON/OFF - Select OFF if no auxiliary device is connected, this will remove the AUX feature from the source list.

AUX Name - Select the desired AUX name

AUX - TV - DVD - GAME - PORTABLE - COMPUTER

#### Clock Adjust


Adjusts the Clock time, 12/24 hour

- Turn the  to adjust the Hour, Press to confirm, repeat to adjust the minutes, Press to confirm.



## CHAPTER 6

### LOADING / EJECTING AN IPOD (MS-IP500 ONLY)



**Note:**

Failure to correctly insert your iPod will result in damage to your iPod and the FUSION Marine Stereo.

**Selecting the correct iPod Sleeve**

The MS-IP500 has 8 possible iPod solutions.

A different set of sleeves is used for each iPod model. The different sleeve combinations are outlined in chart below:

iPod	Top sleeve	Bottom sleeve
classic, 5th Gen (30gb)	A	A
classic, 5th Gen (60/80gb)	A	B
classic, 6th Gen (80gb)	B	A
classic, 6th Gen (160gb)	B	B
classic, 7th Gen	B	A
itouch, 1st Gen, 2nd Gen	D	D
nano, 2nd Gen	C	C
nano, 3rd Gen, + Adapter	A	A
nano, 4th Gen	E	E

**Please note:** For the iPod nano (3rd gen), the iPod must be placed inside the adaptor sleeve, and then placed inside Dock sleeve combination A.

**Please note:** Place the sleeves inside the Stereo Unit before inserting your iPod.


BUTTON	DESCRIPTION
	<b>iPod.</b> Press to access the iPod source
	<b>Play/Pause</b> Play/Pause track in CD/MP3 and iPod mode.
	<b>Forward/Next</b> <b>Short Press:</b> To select the next track in CD/MP3 or iPod mode. <b>Press and hold:</b> Fast-forward in CD/MP3 or iPod mode.
	<b>Back/Previous.</b> <b>Short Press:</b> To select the previous track in CD/MP3 or iPod mode <b>Press and hold:</b> Rewind in CD/MP3 or iPod mode





## Equipment Operation

Press the  to enter the iPod menu, use the  to navigate the functions of your iPod. The rotary encoder operates similar to the click wheel on your iPod. Turn to navigate and press to enter.

**Note:** Press the  to return to the previous menu screen.

### NO iPod Connected

If this appears on the display possible causes are

1. Ensure the iPod is correctly connected
2. Ensure the cable is not excessively bent
3. The iPods battery remains low ( refer to iPod manual and charge the battery )
4. The iPods software version is not compatible (update software version to be compatible with this



## AUX OPERATION

### CONNECTING AN AUXILIARY AUDIO DEVICE

1. The Left & Right AUX RCA plugs are located at the rear of the unit.
2. Connect your auxiliary audio device.

**Note:** You may require an adapter cable to connect your device.

### LISTENING TO YOUR AUXILIARY AUDIO DEVICE

1. Press the  on the main unit to select AUX mode (MS-IP500) or press  twice (MS-CD500)
2. Start playback on your auxiliary audio device. Use both the volume control on your auxiliary device (if available) and the volume control on the FUSION Marine Stereo to set the volume level.

### AUXILIARY NAMING

See page 9



## CHAPTER 6

---



If equipped, the Fusion remote control is normally mounted at the transom area which makes it easier to use during water activities.









It is a plug and play device and uses the same function buttons and rotary encoder as the helm head unit. It features the ability to select various speaker zones on the vessel. Refer to the Fusion

owner's manual for more detailed information.



## Equipment Operation

### BUTTON DESCRIPTION


BUTTON	DESCRIPTION
	<b>Power</b> Press to turn the unit ON/OFF
	<b>Source</b> Press to select the desired source Radio [FM-AM-SAT] - CD/MP3 - iPod - AUX
	<b>Mute</b> Press to Mute/Un-Mute sound in all zones
	<b>Menu</b> Press to enter menu system. Press to return to previous screen
	<b>Play/Pause</b> Play/Pause track in CD/MP3 and iPod mode.
	<b>Back/Previous</b> <b>Short Press:</b> To select the previous track in CD/MP3 and iPod mode. Start automatic tuning down the frequency spectrum in the tuner mode. <b>Press and Hold:</b> Rewind in CD/MP3 and iPod mode. Start manual tuning down the frequency spectrum in the tuner mode.
	<b>Forward/Next</b> <b>Short Press:</b> To select the next track in CD/MP3 and iPod mode. Start automatic tuning up the frequency spectrum in the tuner mode. <b>Press and Hold:</b> Fast forward in CD/MP3 and iPod mode. Start manual tuning up the frequency spectrum in the tuner mode.
	<b>Rotary Encoder</b> The Rotary Encoder operates the same way as the Rotary Encoder on your FUSION Marine Stereo Unit



## CHAPTER 6

---






### ALLOCATING ZONES FOR THE REMOTE.

Press and hold the Mute Button for 7-10 seconds then turn the  to select a : (Z1, Z2, Z3, Z4, Z1234). Press to select. The Remote will then shut down and will need to be turned on.

### ZONE VOLUME

Turn the  to adjust the volume in the allocated zone


### GENERAL SETUP

1. Press the  and turn the  to select the Setup menu. Press to enter.
2. Turn the  to select the function and press to enter.
3. Turn the  to adjust and press  to return.



## Equipment Operation

### Stereo Performance Package



TYPICAL STEREO PERFORMANCE UNDER DASH COMPONENTS.

The stereo performance package features extra speakers including a sub-woofer and a 2 channel amplifier to provide leading edge performance in sound and power. The simplicity of design contributes to low distortion and high efficiency. Normally the amp is located under the starboard helm or may be in the cockpit refreshment center. The circuit is protected by

twin 25 amp automobile type fuses. It is a good idea to carry extra fuses which are available at local marine or automotive stores. The amplifier does not require any type of maintenance other than periodic checking of the wiring connectors for tightness. Contact your Fusion owner's manual or closest Regal dealer for additional information.

Vessels with the optional power tower speakers use an additional 4 channel amplifier located under the helm or the cockpit refreshment center depending on the specific boat model.



## CHAPTER 6

---

### Stereo iPod

---

An iPod adapter is located inside the face of the FUSION stereo as standard equipment. Using a set of top and bottom sleeves it is able to fit most iPod versions.

Refer to the FUSION stereo instruction manual for further information on sleeve specifications.

Note: There is a separate iPOD dock coupled with a CD/DVD player. This option requires Regal View. This optional player is not part of the Fusion system.



## Equipment Operation

---

### Swim Platform

---

On swim platforms follow periodic inspections of the swim ladder and platform support hardware to insure that all connections and fittings are tight and in a non-corrosive state. Never dive off the swim platform.

*Do not store or add objects to the swim platform since additional weight will affect steering and maneuvering characteristics of the vessel.*

Remind passengers entering from the water to use the handhold to aid in safe boarding. Never use the stern drive to access the swim platform since serious injury could result from propeller blades and/or stern drive parts.



### WARNING

AVOID SERIOUS INJURY OR DEATH!  
DO NOT OPERATE THE BOAT  
WITH PEOPLE ON TOP OR HOLDING ON TO  
THE SWIM PLATFORM STRUCTURE OR HARDWARE.



## CHAPTER 6

---

### Swim Platform-Flexiteek

---



Flexiteek decking available on selected models features significant advantages over similar wood products. It is made from synthetics. Color is as natural as timber and uniform through the entire thickness adding to its appeal. It sands like wood resulting in a natural wood look and feel. It provides superior grip making it great

for boating in general and water sports. It is stain resistant with most washing away with soap and water. The product is UV resistant. Gentle sanding removes most marks on the decking with a minimum of product loss.





## Equipment Operation

---

### Toilet-Chemical

---



Before each outing make sure the chemical toilet is filled with the proper chemicals, paper is available, and the holding tank is empty.

To fill the toilet read and follow all the manufacturer's recommendations for mixing the solution. Use the fill to pour in the deodorant chemical and water. By pushing down on the bellows the chemical mix is released to rinse and help flush the toilet bowl. When the flush valve is pulled forward the toilet bowl waste water empties

into the holding tank. Close the flush valve after each use.

The chemical toilet features a holding tank level indicator. When full the lower holding tank must be emptied by first separating it from the upper toilet bowl assembly. Before proceeding, ensure the flush valve is completely closed. Find the latches that allow the 2 units to be separated. Once separated, find an environmentally friendly facility to dispose of the waste.



## CHAPTER 6

---

### Toilet-Chemical/Pump Out Fittings

---



As an option chemical toilets feature a deck fitting that permits a marina or waste station to pump out the vessel holding tank. A hose attachment screws into the deck fitting and removes the waste in the vessel toilet holding tank by activating a land pump. The pump-out fittings eliminate the need to remove the holding

tank manually from the vessel.

After the pump-out procedure rinse the waste hose briefly to eliminate a build-up of debris and odor before closing the pump-out deck fitting. Refurbish the holding tank chemical per the manufacturer's directions immediately after the pump-out procedure. For extended cruising, carry extra holding tank chemical and paper recommended by the manufacturer since household varieties are not usually "friendly" to the environment.

As part of your pre-cruise inspection monitor the chemical toilet by reading the monitor indicator level located on the toilet holding tank.



## *Equipment Operation*

---

### **Toilet-(Vacuum)Suction Style Flush** ---

A suction style flush toilet is available on select models. This toilet operates in a different way from other marine toilets. The system uses around 16 ounces per liquid or solid flush which is a substantial water savings over other systems. The toilet is connected to a pressurized fresh water supply tank or to a water strainer and intake seacock. An electrically controlled in-line solenoid valve lets fresh water into the toilet bowl. This unit is outfitted with special valving which prevents the possible contamination of the potable water system. The main components of this system normally are:

**Fresh Water Storage Tank-** This tank delivers the needed water to the toilet for flushing purposes when connected to a fresh water pump.

**Holding Tank-** Unit features polyethylene composition. A deodorant additive is required to keep the holding tank odor-free. The holding tank is connected to a deck fitting for pump-out purposes.

**Head Wall Switch-** Used to flush waste into the holding tank from the toilet. Normally these switches feature economizer cycles.

**Fresh Water and Waste Monitor-** Select vessels offer a monitor panel to display the waste level.

**Overboard Discharge Pump-** An optional pump sometimes called a macerator which vacates waste through the deck waste fitting when a pump out is used. A waste seacock may be installed through the hull as auxiliary equipment (only used beyond the 3 mile limit in the USA in International waters).

**Discharge Check Valve-** Ensures a one-way route for waste to holding tank.



## CHAPTER 6

---

The system uses a combination of suction and water flow from the fresh water tank to clear the head of waste.

The system components including the hose are formulated for the transfer of sanitary waste only. Do not allow the following items in the system: Strong acid or caustics such as drain openers, petroleum solvents or fuels, alcohol based products such as antifreeze and pine oil products along with sanitary napkins and baby diapers.

To operate the head;



1. Activate the pressurized fresh water system switch at the helm since normally the fresh water tank is the main water source for the system.

2. Activate the switch located at the head wall to flush liquid or solid waste. The system requires more water for solid over liquid waste. Note the typical switch control below.



3. Adding water to the toilet is recommended before flushing solid waste. Simply press the “add water” button and hold for 1 second. Approximately 17 ounces of water is added to the bowl. There are

system electronics that prevent overfill of the bowl.

The flush button is recommended for flushing liquid waste since it saves water and fills up the holding tank at a slower rate.

To empty the bowl without adding water or starting a flush sequence, push and hold both buttons together until the bowl contents are discharged. Pushing either button at this point returns toilet flushing to normal operation.



## *Equipment Operation*

---

**Note: Refill the toilet as soon as possible after emptying the bowl. If the plumbing trap remains without water the system can produce objectionable odors.**

4. Do not dispose of sanitary napkins or other non-dissolving items in the toilet. Do not attempt to flush facial tissue, wet strength tissue, paper towels, or excessive quantities of toilet paper down the toilet. These types of items do not dissolve and cause plugging of the system.
5. Use only a RV/Marine toilet tissue that disintegrates rapidly. Note that most household tissues cannot be relied upon to do so.
6. Make sure all passengers are aware of the toilet operation.
7. If using holding tank deodorant, use the approved ones for the system.
8. See the toilet operator's manual for more detailed operating information.



## CHAPTER 6

---

The holding tank level needs to be monitored periodically for content fullness. Do not operate the waste system when the holding tank is full. Before venturing out on a cruise it is a good idea to have the holding tank pumped out. Normally when the waste tank is overfull it may clog the charcoal vent line filter.

Since a small amount of water usually remains in the holding tank it is a good idea to rinse the tank especially after cleaning. Add water to the toilet bowl along with 8 ounces of manufacturer's tank deodorant and cleaner until the discharge is clear. Do not use chlorine based or caustic cleaners along with drain openers as damage to the seals and hoses may occur.

Rinsing the pump-out hose at the deck fitting with a bit of fresh water should be done after the marina pump-out equipment hose is removed. This prevents a build up of particles and tissue on the inner waste hose.



## Equipment Operation



Federal regulations prohibit pumping waste overboard within the territorial limits of the United States. Check with authorities regarding specific laws and regulations before attempting

to pump waste overboard.

The overboard discharge option consists of a hull bottom mounted seacock, head key switch, and a macerator (overboard discharge pump) to grind up the waste and deliver it through the seacock overboard.

The seacock is secured in the “closed” position and it must be “opened” before operating the overboard discharge pump. **Damage to system components and/or a potential leak could develop if the seacock is not in the “open” position before activating the pump.**

1. Locate the seacock. Remove the locking mechanism from the seacock and turn the valve to the “open” position by aligning the seacock handle with the valve.



2. The overboard pump key switch is located in the head. To activate the macerator pump turn the switch on and completely to the right. At this point the macerator pump will sound starting the pump out process. It will be required to hold the switch to the right until the tank is emptied. Once empty return the key switch to the “off” position. Have someone monitor the waste tank level visually during the pump out process.

Avoid running the discharge pump “dry”.



## CHAPTER 6

---

3. Close the seacock by repositioning the seacock handle aligning it across the hose. Ensure the seacock is closed completely. Relock the seacock. Failure to relock the seacock within the territorial limits of the United States could result in boat operator fines.





## Equipment Operation

---

### Trailer Switch

---



The trailer switch is located on the transom. It permits tilting the stern drive in the “up” or “down” positions from the stern of the boat. Always remove the keys from the ignition switch to prevent the unit from starting in the trailer “up” position. Make sure nobody is near the stern drive when using

the trailer switch. Return the stern drive unit to the “down” position before starting the engine. Failure to do so may result in stern drive component damage.



## CHAPTER 6

---

### Through-Hull Exhaust

---

If installed this component permits the exhaust to exit above the waterline at the hull side verses the normal stern drive underwater passageways. There is a helm switch which activates the device. When the switch is off the exhaust exits through the stern drive. Refer to the Volvo engine operator's manual for further information on this option.

**Note:** It is the duty of the operator to check appropriate local, state and national regulations in reference to using the through-hull exhaust system in that designated area. Some areas induce strict fines for sound decibels over a set number.




## Equipment Operation

---

### Washdowns

---




If installed the fresh water washdowns are normally located on the deck in the bow locker and/or at the cockpit aft storage compartment as shown in the photo. They operate from the pressurized fresh

water system pump. The fresh water system switch located at the helm area must be activated for the washdowns to cycle on and off.



## CHAPTER 6

### Windshield-Center Latch



Lock Both Latches



Magnet

The center windshield shall be closed and locked at all times the boat is moving. Make sure the two locking latches are firmly seated in a horizontal position against the windshield framework.

In the open position at the dock make sure the center windshield is held securely by the magnet. See illustration.



## WARNING

AVOID BODILY INJURY!  
CLOSE AND SECURE CENTER WINDSHIELD  
AT ALL TIMES THE VESSEL IS MOVING!



## *Equipment Operation*

---

### **Wide-Angle Mirror**

---



Select models offer a wide angle windshield mounted water sports mirror. The mirror offers the boat operator a crystal clear view of water sports activities. An observer is still required.

To loosen the mirror from the windshield turn both lock mechanisms counterclockwise.

To adjust the mirror simply move the mirror to the desired location. Clean the mirror with a soft, lint free cloth and rubbing alcohol. Do not use harsh cleaners which can scratch the finish.



# *Cosmetic Care & Maintenance*

## **COSMETIC CARE**



This section covers the care and maintenance of your Regal FasDeck vessel. Many cosmetic care topics including exterior hardware, upholstery, fiberglass and canvas are covered along with major equipment and systems. Refer to the owner's information packet and the appropriate engine manufacturer's manuals for further detailed instructions.

### **Upholstery**

---

Cockpit and interior vinyl require periodic cleaning to maintain a neat appearance and to prevent the build up of dirt, mildew and contaminants that may stain and reduce the vinyl life if they are not removed. The frequency of cleaning depends on the amount of use and conditions to which the vinyl is subjected.

Most common stains can be cleaned using warm, soapy water and clear rinses. Scrubbing with a soft bristle brush will help loosen soiled material from embossed surfaces and under welting. If the stains are not removed with the above method use a mild cleaner such as Fantastic. This cleaner should be used only as needed and not the normal means.

With more stubborn stains, rubbing alcohol or mineral spirits may be tried cautiously. Widespread solvent use can severely damage or discolor vinyl. Try to remove stains immediately before they have a chance to penetrate the surface of the vinyl.



## CHAPTER 7

---

Powdered abrasives, steel wool, or industrial strength cleaners are not recommended for cleaning our vinyl. Lacquer solvents will cause immediate damage. Dilute chlorine bleach before using. Do not wax the vinyl as it may cause cracking. Always wear protective gloves and make sure there is sufficient ventilation when cleaning vinyl. Wear eye protection.

Remember that suntan oil will damage vinyl. Use suntan lotion instead of suntan oil. Exposure to the sun is a natural enemy of vinyl upholstery. Keep the vessel covered with a cockpit cover when not in use.

### Cockpit Carpet

---

Use approved cleaners on carpet. Always try on a test area first. Many spots and spills can be removed using a cleaner combined with a clean, white terry towel. Try not to soak an area excessively and do not use solvents because most interior carpet is rubber backed and glued in place. Solvents and abrasives will break down the backing and fibers.

**Note: Always roll up cockpit carpet before towing your boat.**

**Store carpet in a locker.**

### Plastics

---

Use plastic cleaners and polishes recommended for marine use only. Use proper applicators. Read all instructions carefully. Test the product in a small area first. Use a soft rag and always rinse the surface with water. Ammonia based cleaners and abrasives will damage plastic parts.

## NOTICE

NEVER CLEAN PLASTIC SURFACES WITH A DRY CLOTH OR GLASS CLEANING SOLUTIONS CONTAINING AMMONIA. NEVER USE SOLVENTS OR WIPE WITH ABRASIVES



## *Cosmetic Care & Maintenance*

---

### **Interior Fabrics**

---

Clean flat good interior fabrics with dry cleaning fluid style cleaners approved for use with soft fabrics. Allow adequate ventilation and follow the label instructions carefully. Use a soft cleanser with feldspar to clean stubborn marks or stains on wallpaper. Normal interior vinyl such as used on the headliner on cruisers and head clean up with a mild soap and water solution. Rinse immediately with clean water and wipe dry. Always test an area with a cleaner before applying it to a larger area.

### **Fiberglass & Gelcoat**

---



## **CAUTION**

AVOID BODILY INJURY!  
WAXED GELCOAT SURFACES  
CAN BE VERY SLIPPERY.  
DO NOT WAX NORMALLY USED AREAS  
OF THE DECK, LINER, OR GUNWALES.  
DO NOT WAX ANY TEXTURED  
OR NONSKID SURFACES  
SUCH AS FLOORS, WALKWAYS,  
STEPS, LADDERS OR SWIM PLATFORMS.  
WEAR NON-SLIP FOOTWEAR WHEN WALKING  
ON VESSEL SURFACES.

Routine maintenance is the only practical way to keep the surface of your boat looking shiny and new. Most objects left outdoors will gradually deteriorate from exposure to the sun, water, dust and pollution. Such outdoor exposure can cause your boat's gelcoated surface to change or fade. Darker colors tend to fade more rapidly than lighter colors because they absorb more of the sun's rays (ultraviolet and infrared). Basic maintenance includes monthly washing of the boat's surface to remove normal accumulation of soil and stain.





## CHAPTER 7

---

Use a mild detergent such as dishwasher powder or liquid. Do not use automatic dishwasher detergent. Avoid any kind of alkaline cleaners such as trisodium phosphate (TSP), abrasives, bleaches and ammonia. For best results use cleaners that are recommended for fiberglass.

### NOTICE

WIRE BRUSHES, SCOURING PADS, OR OTHER ABRASIVE TYPE MATERIALS AND SOLUTIONS SHOULD NEVER BE USED ON THE HULL OR DECK OF YOUR BOAT. THEY CREATE SMALL SCRATCH MARKS THAT WILL COLLECT MARINE GROWTH AND OTHER FOREIGN MATERIALS.

It is recommended that you wax the gelcoat surface twice yearly to prevent loss of gloss and to protect the finish. Use only waxes for fiberglass and follow the label instructions. Apply a 3' x 3' section at a time using clean applicator cloths or a buffing bonnet. When a haze develops, use a power buffer at low speeds (1200-2000 rpm) to remove the haze. Keep the buffer moving to avoid heat buildup. The power buffer is very efficient at removing contaminants from gelcoat. Never wax gelcoat in the direct sun.

When the washing and waxing as recommended does not restore the shine it may be necessary to use a fine rubbing compound. Do not apply rubbing compound in direct sunlight. A power buffer at low speed does an excellent job to remove impurities from the gel coat that cause dulling. Use light pressure and keep the buffer moving. Re-wax after compounding to buff the surface.

“Hairline cracks” or “spider webbing” could develop in the gelcoat surface of a hull or deck. This can be caused by impact or other factors. Small air pockets or gouges may also occur through **normal** wear.



## Cosmetic Care & Maintenance

---

These do not affect the strength of the hull or deck and can be repaired by yourself, a marine professional or a Regal dealer.

The affected area should be chipped or sanded away and a thin layer of color matched gelcoat applied. This layer is then sanded smooth and buffed to its original luster.

Most minor scratches, nicks, and dents can be removed by compounding the surface. Marine type compounds can be found at most auto body supply stores. Specify a number 25 which is a coarser compound up to a number 55 being less coarse. Various glazes and polishes are available as needed. Ask your marine professional or Regal dealer for more information. Fiberglass hulls are strong but they can be damaged. A fiberglass hull has virtually no internal stresses. Thus when a part is broken or punctured, the rest of the hull retains its original shape. A severe blow will either be absorbed or result in a definite localized break. A break of this nature should be checked and repaired by a marine professional or a Regal dealer.

### Minor Repairs

---

You will need the following materials for minor repairs:

- Gelcoat
- Clear Liquid Catalyst
- Putty Knife
- Razor Blade
- Fine Sandpaper (400,600,1000)
- Wax Paper (to cover repair area)



## WARNING

AVOID BODILY INJURY!  
GELCOAT & FIBERGLASS RESIN ARE FLAMMABLE.  
WORK IN A WELL VENTILATED AREA FREE FROM  
OPEN FLAMES. DO NOT SMOKE!



## CHAPTER 7

---

For minor repairs refer to the following procedure:

1. Clean the area to be repaired and get rid of any wax or grease residues.
2. Clean out scratches, chips, and nicks.
3. Sand area to be repaired so gelcoat will bond.
4. In a separate container, measure only the amount of gelcoat you will need. Mix a ratio of 2% ratio of catalyst to the amount of gelcoat being used (a spoonful of gelcoat will require only a drop or two of catalyst). Do not pour any unused portions of the gelcoat/catalyst mixture back into either original container.
5. Apply gelcoat to area leaving a slight lift above the surface.
6. Cover the area with wax paper. It will help the mixture to set up faster.
7. Remove wax paper and shave off any extra gelcoat with a razor blade.
8. After the area is shaved smooth, start with the 400, 600, and finally 1000 grit sand papers.
9. Buff the area with compound, polish and a finish wax. You may notice a difference between the repaired area and the original finish due to the natural weathering process.

### Canvas

---

Boat canvas is in most cases subjected to more severe punishment than practically any other type of material. Moisture, dirt and chemicals from industrial fallout, heat, ultraviolet rays and salt water are all factors which accelerate the deterioration of your boat canvas.



## *Cosmetic Care & Maintenance*

---

These elements can cause serious damage if left unchecked.

The boat top and other canvas supplied on your Regal boat are manufactured from top quality materials to provide you with years of trouble free service. The following information on the care, cleaning and proper storage of the fabrics and fasteners that make up your marine canvas is being provided to help you maintain the appearance and ease of operation.

Sunbrella is used on most Regal tops, aft curtains, camper enclosures, bow tonneaus and cockpit covers. Sunbrella is a woven fabric made from 100% solution dyed acrylic fiber. It is color fast and will withstand long term exposure to the sun (ultraviolet rays) without excessive fading.

Sunbrella is a woven fabric. Even though it is treated with water repellency some “misting” through the fabric is typical. With new canvas, the greatest potential for leakage is through the sewn seams. Because Sunbrella and the long term thread used is synthetic, the holes created by sewing will not swell up and seal when exposed to water as cotton does. Usually the movement of the fabric in use will move the fibers enough to seal the holes. You may apply Apseal or Uniseal to the seams to speed up this process.

When the canvas is new, the fit will normally be tight. It is designed this way because Sunbrella stretches as it ages. The initial tight fit allows for a suitable fit for the life of the canvas. The Sunbrella fit will vary slightly in the heat, cold, and rain.

### **Sunbrella Cleaning Instructions**

---

Sunbrella should be cleaned regularly before substances such as dirt, roof particles, etc., are allowed to accumulate on and become embedded in the fabric. The fabric can be cleaned without being removed from the boat. Simply brush off any loose dirt, hose down, and clean with a mild solution of natural soap in lukewarm water. Rinse thoroughly to remove soap. **DO NOT USE DETERGENTS!** Allow to air dry. For heavily soiled fabric, remove the top from the frame.



## CHAPTER 7

---

Soak the fabric in a solution that has been mixed to the following proportions.: 1/2 cup of bleach and 1/4 cup of Ivory or Lux soap (liquid or soap) per each gallon of lukewarm water. Allow the fabric to soak until the bleach has killed the mildew and the stains can be brushed out with a common kitchen scrub brush. Rinse the fabric thoroughly in cold water to remove all the soap. This may require several rinsings. Incomplete rinsing can cause deterioration of sewing threads and prohibit the fabric from being properly retreated. Allow the fabric to dry completely. **DO NOT STEAM PRESS OR DRY IN AN ELECTRIC OR GAS DRYER!** Excessive heat can damage and shrink the fabric since it is heat sensitive.

This method of cleaning may remove part of the water and stain repellent that was applied to the fabric during its manufacture. It is recommended to retreat with such water repellency products as Apsel and Uniseal. We do not recommend any wax based treatments such as Thompson's Water Seal or any of the silicone products such as SC-15 or Aqua-Tite. Wax based products prevent the fabric from breathing, and encourage mildew growth while the silicone products interact with the original fluorocarbon finish and seem to cause a rapid loss of water repellency.

### Clear Vinyl, Zipper & Snap Care

---

Never store canvas wet or in an unventilated, moist area. Always roll the canvas instead of folding. This is of particular importance on side curtains or any other part with the clear vinyl "glass". Roll the top carefully around the bows and cover with the storage boot provided.

The clear vinyl "glass" used in side curtains, aft curtains, visors, and camper enclosures is very susceptible to heat and cold. Keep vinyl curtains from touching metal tubing to minimize burning the vinyl.

If the boat is stored with top, side curtains and aft curtain in place, heat build up inside the boat may discolor the vinyl.

To clean the clear "vinyl" glass, use a solution of Ivory or Lux soap, liquid or flakes, and lukewarm water. Allow to air dry. Never use any



## *Cosmetic Care & Maintenance*

---

type of abrasive cleaner as it will scratch the “vinyl” glass. There are many cleaners and scratch removers on the market specifically for clear vinyl. Handle the clear curtains carefully. They are soft and prone to scratching.

Canvas parts are designed with zippers. When zippers are new they can be a little difficult to use. Zip carefully without forcing the zipper or the material. They will loosen with use. A zipper lubricant may be used to help new zippers as well as maintaining used ones. The most vulnerable part of the zipper is the starts. Use care when beginning to close the zipper.

Canvas snap fasteners should be unsnapped as close to the button as possible. Never remove canvas by pulling roughly on the edge of the material. This can damage the canvas as well as the fasteners. Use petroleum jelly on snaps to keep them from developing corrosion especially in harsh environments.

### **Metal**

---

Keep all stainless steel and other metal parts rinsed and wiped dry. To maintain their finish annually polish the stainless steel and other bright works at least annually. Use commercially available metal products and read the labels carefully before use. Refer to the flyer in the owners information pouch. Most marinas and boating retail outlets carry metal care products.

### **Hull Bottom**

---

Never use wire brushes or highly abrasive scouring pads on your hull bottom. It could damage the gel coat surface or the bottom paint. The bottom of your boat needs to be clean since the build up of natural coatings from water or marine life can potentially create drag and affect your boat's performance. Contact a marine professional or Regal dealer for more information.



## CHAPTER 7

---

FREQUENT STAINS/CLEAN-UP STEPS	1	2	3
Coffee, Tea, Chocolate.....	B		
Permanent Marker*.....	E	B	C
Household Dirt.....	A	B	
Grease.....	D	B	
Ketchup, Tomato Products.....	A	B	
Latex Paint.....	A	B	
Oil Base Paint.....	D	B	
Mustard.....	A	B	C
Suntan Oil.....	A	B	
Asphalt/Road Tar.....	D	B	
Crayon.....	D	B	
Engine Oil.....	B		
Spray Paint.....	B		
Chewing Gum.....	D	A	
Shoe Polish*.....	D	B	
Ballpoint Pen*.....	E	B	A
Lipstick.....	A	B	
Eyeshadow.....	E	B	
Mildew*.....	C	B	A
Wet Leaves *.....	C	B	A

A= Soft brush; warm soapy water/rinse/ dry

B= Fantastik cleaner

C= One tablespoon ammonia, 1/4 cup of hydrogen peroxide, 3/4 cup of warm water/ rinse/dry

D= Scrape off residue ( use ice to lift gum)

E= Denatured alcohol/rinse/dry

\* These products contain dyes which leave permanent stains.



## *Cosmetic Care & Maintenance*

---

### **MAINTENANCE**

#### **Engine**

---

Each engine package is unique and quite complex. A select portion of the maintenance items are covered in this chapter. Many times because of the advanced ignition and fuel injection systems used on marine engines it is best to use trained marine professionals. For more detailed information, refer to the manufacturer's engine owner's manual or call your closest authorized Regal dealer.

#### **Stern Drive**

---

The stern drive unit should be checked before each outing. Tilt up the drive and check for any debris around the intake and any fish line tangled in the propeller. Check your engine manual for stern drive maintenance schedules or call your nearest authorized Regal dealer.

#### **Propellers**

---

Out-of-balance or nicked props will effect performance or cause vibration. Damaged props should be replaced, but those that are chipped or bent can usually be reconditioned by a marine dealer or a propeller repair facility. When cruising, consider carrying a spare set of props on board because many marinas do not carry a full inventory of replacement propellers. Also, carry an extra set of prop hardware. Refer to the manufacturer's engine manual for appropriate stern drive and inboard propeller replacement.

Be sure to make a note of the propeller diameter and pitch while the vessel is in dry dock. They are pressed into the prop for easy reading. In an emergency an aluminum propeller blade can be straightened by laying the propeller blade on a 2 x 4 and hammering the bent portion of the blade until straight. This procedure will assist the operator in reaching port so he can have the propeller re-pitched.





## CHAPTER 7

---

It is advantageous to carry the needed tools to change propellers. Use the following procedure to remove single stern drive propellers.


This method provides a safety margin from sharp blades especially those with stainless steel propellers. A 2" x 4" piece of wood placed across the ventilation plate allows safe removal of the propeller. With propeller units you may need to add a shim to the 2" x 4" piece of wood to remove the propeller safely. See the engine manufacturer's owner's manual for further information.




## *Cosmetic Care & Maintenance*

---

### **VOLVO DUO PROP INSTALLATION**



Coat both shafts with marine grease. Place the remote control in forward position to lock shafts.  
Install the front propeller.




Install propeller nut. Tighten to 45 ft. lbs. Make sure the chamfered edge of the prop nut is facing forward. Failure to install prop nut correctly could result in loss of prop or damage to the lower unit.




## CHAPTER 7

---

### VOLVO DUO PROP INSTALLATION



Shift remote control to reverse to lock the propeller shaft. Install the rear propeller.




Install the rear propeller nut and tightenit to 50 foot pounds using a torque wrench. Shift the remote control to neutral. The propeller shoud turn freely.



## Cosmetic Care & Maintenance


### MERCRUISER BRAVO ONE



#### Alpha One and Bravo One

- a - Apply Lubricant on Propeller Shaft Splines
- b - Forward Thrust Hub
- c - Flo-Torque Drive Hub
- d - Propeller
- e - Continuity Washer
- f - Drive Sleeve Adapter
- g - Tab Washer
- h - Locknut

### MERCRUISER BRAVO THREE



#### Bravo Three

- a - Rear Propeller Locknut
- b - Rear Propeller
- c - Rear Propeller Thrust Hub
- d - Front Propeller Locknut
- e - Front Propeller
- f - Front Propeller Thrust Hub



## CHAPTER 7

---

### Steering

---

Your boat uses a rack or rotary style steering system featuring a cable that functions with assistance through the engine power steering pump. As you turn the wheel force is applied through the system to a hydraulic cylinder found at the aft end of the engine and attached through the engine power steering pump hoses.

With the engine running, check the engine power steering pump level before each outing. Add the appropriate power steering fluid. Periodically inspect the entire steering system for tightness and signs of wear and leaks including the steering wheel. Lubricate the steering shaft at the engine. Refer to the manufacturer's engine manual in the owner's pouch for additional information along with the maintenance chart in this chapter.

CHECK HOSE CONNECTIONS  
FOR LEAKS & TIGHTNESS

CHECK NUT FOR  
TIGHTNESS.





## *Cosmetic Care & Maintenance*

---

### **Battery**

---

Frequently check your battery terminals for corrosion build-up. If you find a greenish, powdery substance, remove the cable connections and clean both the terminals and the connectors with a wire brush. When the cleaning is finished reconnect the battery cables and coat the terminal with an approved grease or petroleum jelly to help prevent further corrosion. Check the electrolyte level at least every 30 days, more often in hot weather. The level should be maintained between the top of the battery plates and the bottom of the fill cap opening. Add distilled water as needed after charging the batteries or periodically as needed. Do not overfill because sulfuric acid could run over and cause burns or an explosion.

Batteries should be charged outside the boat. Do not smoke or bring flames near a battery that is being or has recently been charged. The hydrogen gas generated by battery charging is highly explosive.

Set batteries on a block of wood rather than concrete since this procedure will help the batteries from losing their charge.

Do not allow a metal object or loose wires to spark across battery posts while working close to the battery. Contact across terminals will cause a short circuit and personal injury may result.

Tighten all battery connectors securely. Check their tightness by pulling on the connectors. They should not move from their tightened position. Be sure to reinstall the positive boot over the battery terminal after tightening the battery post connection. While using the boat, use the volt meter to monitor the charge level of the battery. Monitor the charge with the engines turned off (static condition).

The engine alternators recharge the batteries. A fully charged battery will indicate between 12.3 and 12.6 volts on the voltmeter. Readings below this could indicate a dead battery cell or a charging system malfunction which should be checked by a marine professional.



## CHAPTER 7

---



### **WARNING**

TO PREVENT BODILY INJURY!  
BATTERIES CONTAIN SULFURIC ACID (POISON)  
WHICH ALSO CAN CAUSE BURNS.  
AVOID CONTACT WITH THE SKIN, EYES & CLOTHING.  
IF CONTACTED, FLUSH WITH WATER AT LEAST 15  
MINUTES. IF SWALLOWED, DRINK LARGE AMOUNTS  
OF WATER OR MILK. FOLLOW UP WITH MILK OF  
MAGNESIA, BEATEN EGG OR VEGETABLE OIL. GET  
MEDICAL ATTENTION IMMEDIATELY!



### **WARNING**

TO PREVENT BODILY INJURY!  
WEAR GOGGLES, RUBBER GLOVES  
AND A PROTECTIVE APRON  
WHEN WORKING WITH A BATTERY.  
BATTERY ELECTROLYTE CAUSES SEVERE EYE  
DAMAGE AND SKIN BURNS.  
IN CASE OF SPILLAGE, WASH AREA WITH  
A SOLUTION OF BAKING SODA AND WATER.



## *Cosmetic Care & Maintenance*

---

### **Remote Control**

---



Check the helm control box and the cable attachment at the engine for tightness and shifting without binding. This applies to engines with standard remote controls only.

Shift and throttle controls at both the engine and helm areas must be checked on a periodic basis. At the engine end, make sure all control cable hardware is tight and control cable brackets are secure. An application of silicone spray on the cable ends periodically will keep control cables working freely and fights corrosion. At the helm end check to make sure the control box hardware is tightly secured. Contact a marine professional or Regal dealer for further assistance.





## CHAPTER 7


### Seating



The bucket seat slider needs periodic inspection and maintenance. Loosen the swivel knob located on the slider and pull the slider off the pedestal. Inspect all fasteners and metal for fatigue. Lubricate the points shown in the illustration with a marine type grease. type of grease will not run off under warm temperatures. Use a paint brush

to apply the grease. Also, use silicone spray for areas that can not be accessed with the grease. Reassemble slider to pedestal with the delrin cup positioned correctly.

#### BUCKET SEAT SLIDER MAINTENANCE





## Cosmetic Care & Maintenance

---

### Bilge Pump

---


The bilge pump is usually installed in the engine compartment just below the engine front. Check for foreign materials stuck in the strainer area or discharge hose.

Check all clamps and electrical connections for tightness. A quick check of the bilge pump automatic float switch is afforded by lifting up on the float and listening for the pump operating. Look around the float area for foreign debris and remove as necessary.

### Fuel Tank & Fittings

---

Periodically inspect the fuel tank components for loose clamps at the vent, fill and feed locations. Examine each hose for signs of deterioration and leakage. Check the fuel sender for loose bolts, nuts, and leaks at all areas of contact. Also, inspect the fuel tank for signs of leakage or abrasion. Tighten all components as needed.





## CHAPTER 7

---

### Fuse Panel

---



The fuse panel is located under the dash area. On select models the panel can be accessed on the bow side of the helm. Lift the starboard bow seat backrest to access the fuse panel. Fuses are of the automotive type and can be obtained at most auto aftermarket stores or your closest authorized Regal

dealer who can order it as a designated fuse pack. It is recommended that you carry all the different amperages. When a fuse “blows” determine the cause before replacing the fuse. Never replace with a higher amperage fuse since the equipment, wiring or even worse a fire could develop due to an overload.



## *Cosmetic Care & Maintenance*

---

### **Stereo**

---

The Fusion® stereo head unit requires little maintenance. When washing the cockpit, do not discharge water directly at the stereo unit. Possible damage may result. As with any CD unit clean your CD's to keep them from skipping. This process also aids in keeping dust out of the unit. Never allow water to enter the iPod mechanism behind the head cover.

For further information, refer to your stereo owner's manual located in the owner's packet.



## CHAPTER 7

---

### **Automatic Fire Extinguisher**

---

Vessels with the automatic fire extinguisher system should check the halon unit for tightness at the engine compartment monthly. At that time the unit itself should be weighed to ensure it is full. If the green dash indicator light is not on when the key is in the ignition position there is a system malfunction that must be investigated immediately. Refer to the manual in the owner's packet


### **Blower**

---

Check the blower hoses to ensure they are fastened in the bilge properly and there are no holes in them. The hose connected to the blower needs to be positioned about 3/4 of the way down in the bilge to evacuate fumes properly. All vents need to be checked for debris. Make sure the blower motor is securely fastened and all hose clamps and or tie wraps are tight. Also, check all electrical eyelet connectors for tightness.



### Galvanic/Stray Current Corrosion

CORROSION TABLE	
Gold	<div>Least Active</div>  <div>Most Active</div>
Stainless Steel	
Bronze	
Copper	
Brass	
Steel	
Aluminum	
Zinc	
Magnesium	

Metal parts underwater can be subjected to two basic styles of electrolysis: galvanic corrosion and stray current corrosion. Both can damage the drive, propeller, underwater parts, boat and motor if not correctly monitored (testing at 2 week intervals) and avoided.

Galvanic corrosion is an electrochemical reaction between two or more metals. Drive systems consist of several different metals. Some are more active than others.

Galvanic corrosion of the more chemically active metals can occur whenever two or more dissimilar metals that are “grounded” (connected by actually touching each other, or through a wire or metal part) are immersed in a conductive solution (any material that can conduct electricity). Anything but pure water is conductive. Saltwater, fresh water with a high mineral content and polluted freshwater are highly conductive. Conductivity increases with temperature. That is why Florida boats experience more corrosion than boats in Maine.

Specifically look at a typical marine drive unit with a stainless steel propeller. The aluminum is the more chemically active metal (called the anode) and the stainless steel propeller is the less chemically active metal (called the cathode).



## CHAPTER 7

---

Typically electrons flow from the anode (the aluminum drive unit), via the external conducting path to the cathode (stainless steel propeller). If there is a very large anode connected to a small cathode, the anode will corrode very slowly. If a very large cathode is connected to a small anode, the anode will corrode very quickly. Obviously, if you do not control galvanic corrosion, over time the aluminum will corrode away.

The first sign of galvanic corrosion is paint blistering (starting on sharp edges) below the water line- a white powdery substance forms on the exposed metal areas. As the corrosion advances, the exposed metal will become deeply pitted as the metal is actually eaten away.

Another condition which will increase galvanic corrosion is the removal or reduction in surface area of the sacrificial anodes. Never add aftermarket products that are connected to the engine ground such as stainless steel steering aids and trim planes.

Zinc connected to aluminum will form a corrosion cell but the aluminum (drive) becomes the cathode and the zinc (anode) corrodes.

Even though your boat may not have shore power aboard current from nearby vessels with shore power can produce stray current galvanic corrosion. Stray current corrosion occurs when metal with an electrical current flowing into it is immersed in water that is grounded (lake, ocean, pond). The current can leave the metal and flow through the water to ground. This will cause rapid corrosion of the metal at the point where the current leaves.

When a vessel nearby is plugged into shore power, they can potentially tie your aluminum drive unit to their boat via the green grounding shore power lead. Your aluminum drive unit could be the receiving end of a large galvanic cell (a battery) interconnected with nearby vessels or even through the marina's metal structures via their electrical system.



## Cosmetic Care & Maintenance

---

The vessel should be tested every couple of weeks to determine the integrity of the anode protection system. If not installed, Volvo and Mercury offer an optional corrosion protection system that utilizes the anode/cathode theory to assist in offsetting galvanic corrosion.

Another way to test the system is to measure the hull potential. This is accomplished by immersing a reference electrode, usually a silver/silver chloride into the water about six inches behind the drive. With leads attached to a digital multi-meter the hull potential is read on the DC scale and compared to recommended specifications for the water body type. See the owner's information vendor packet for more information or contact your nearest authorized Regal dealer.

### Tips To Aid In Maintaining Galvanic Integrity

1. *Test the galvanic integrity of your vessel every 2 weeks.* Raise the outdrive and inspect anodes/parts for signs of galvanic corrosion, stray current corrosion or loose fasteners. *Contact your closest Regal dealer/marine professional where signs of galvanic corrosion exist.*
2. Never paint over anodes as they will become inoperative. Always leave at least one inch between bottom paint and any underwater fitting such as seacocks, swim platform stanchions and all drive and propulsion related underwater parts.
3. Periodically remove vessel from water and clean/pressure wash all outdrive, anode and hull bottom areas to remove growth.
4. Ensure vessel is using the correct anode metal for the body of water that it is moored. See the engine/drive manufacturer information packets for more information or contact an authorized dealer.
5. Ensure that the drive is completely "in" down to provide more complete anode protection when vessel is moored.
6. Do not attempt to use magnesium anodes in saltwater. They will provide overprotection.





## CHAPTER 7

7. If marina moored, contact appropriate personnel if signs of galvanic corrosion appear on your drive system. Ask them to check for stray electrical current which may be originating from a nearby vessel's faulty DC wiring or from a marina pier, piling or dock carrying leaking marina ground wiring such as a dockside cord partially submerged.


GALVANIC/STRAY CURRENT CORROSION	
<i>Cause/Observed Condition</i>	<i>Corrective Action</i>
Sacrificial anodes consumed	Replace anodes when 30% consumed
Sacrificial anodes not grounded to drive	Remove anodes, clean contact surface, reinstall, check for continuity
Loss of continuity between underwater parts & ground	Provide good ground connections
Nearby vessel with stray current	Contact appropriate personnel Remove your vessel from water
Paint on drive heavily worn, exposing more metal	Prime and repaint or install additional anodes
Sacrificial anodes painted	Remove paint or replace anodes
Drive tilted/anodes out of water	Leave drive down, install additional anodes below water
Power trim cylinders only corroded	Provide a good ground to drive, all parts must be grounded
Corrosion in area of exhaust outlets	Remove deposits
Corrosion occurring after vessel is removed from saltwater	Wash exterior and flush interior with freshwater
Stainless steel parts corroding	Clean parts, remove foreign material, ensure continuity
Underwater drive parts corroded, sacrificial anodes OK	Oxide film on anode (fresh water only) Replace anode Poor grd. Remove/scrape anode



## Cosmetic Care & Maintenance

### Zinc Anodes

Sacrificial zinc anodes are located on the stern drive housing, trim cylinders and/or propshaft to protect softer metals exposed to the water. Electrolysis attacks the least noble metals first. Because zinc is a less noble metal, it will decompose before other metals. Check these zinc anodes periodically and have them replaced when they are 30% consumed. Notwithstanding, zinc is the most popular metal used to protect parts that are exposed to saltwater, freshwater or brackish water.



Zinc anodes in brackish or salt water need to be checked more frequently. If the anodes seem to be requiring frequent replacement there may be a boat leaking DC current into the water taxing the anodes. This is especially possible around a marina environment. Contact a marine professional who can measure the galvanic activity with a special electrode and electric VOA meter. Refer to the engine manufacturer's manual for exact anode location and detailed information. **Stern drive or related parts damage due to galvanic or stray current corrosion is not covered under the Regal limited warranty.**



## CHAPTER 7

### VOLVO MAINTENANCE GUIDE

FUNCTION <i>Each Trip</i>	ADJUST	CHECK	LUBE	FILL	REPLACE	TIGHTEN
Anodes		*				
Leaks, Cooling System		*				
Stop Switch		*				
Leaks, Fuel System		*				
Oil, Engine		*		*		
Oil, Drive		*		*		
Safety Equipment		*				
Shift System		*				
Fluid, Power Steering		*		*		
Steering Cable		*				
<i>Monthly</i>						
Battery		*				
Exhaust Sys		*				*
<i>Every 50 Operating Hours</i>						
Battery Connections		*				*
All Belts		*				*
Exhaust System Hoses, Clamps		*				*
Fasteners		*				*
Fuel System		*				



## Cosmetic Care & Maintenance

### VOLVO MAINTENANCE GUIDE CONT.

FUNCTION <i>Per Season</i>	ADJUST	CHECK	LUBE	FILL	REPLACE	TIGHTEN
Bellows & Clamps Drive		*			Every 2 Years	
Exhaust Manifold, Risers		*				
Carb, Fuel Filter					*	
Water Pump Impeller					Every 2 Years	
Leaks, Fuel System		*				
Oil, Engine					Refer To Volvo Engine Operator's Manual	
Oil, Drive						
Oil Filter, Engine						
Propeller & Shaft		*	*			
Remote Control Cable		*				
Spark Plugs					*	
Spark Plugs Wires, Boots		*				
Steering System Cable			*			
Throttle Cable		*	*			
Serpentine where applicable		*				
Carb Adj.	*					
Engine Alignment		*				
Gimbal Bearing			*			
Universal Joints & Splines		*				



## CHAPTER 7

### MERCRUISER MAINTENANCE GUIDE

	EACH TRIP	WEEKLY	EVERY 2 MTHS.	EVERY YEAR (100 HRS)	EVERY 3 YRS. (300 HRS)	EVERY 2 YRS.	EVERY 5 YRS.
Oil, Engine	*						
Oil, Drive	*						
Oil, Trim Pump	*						
Fluid, Power Steering	*						
Salt Usage, Flush Cooling	*						
Water Pick-Ups		*					
Anodes		*					
Fuel Pump Site Tube		*					
Battery Connection		*					
Propeller Shaft/Nut			*				
Engine, Corrosion Guard			*				
Touch-Up Paint				*			
Engine Oil & Filter				*			
Drive Oil,Change				*			
Fuel Filter, Replace				*			
Steering & Remote Control				*			



## Cosmetic Care & Maintenance

### MERCRUISER MAINTENANCE GUIDE CONT.

	EACH TRIP	WEEKLY	EVERY 2 MTHS.	EVERY YEAR (100 HRS)	EVERY 3 YRS. (300 HRS)	EVERY 2 YRS.	EVERY 5 YRS.
U-Joints, Splines & Bellows				*			
Lube Gimbal Bearing & Engine Coupler				*			
Test MerCathode Bravo's				*			
Engine Mounts, Retorque				*			
Check ignition parts, timing				*			
PCV Valve, Replace				*			
Flame Arrestor, Clean				*			
Belts, Inspect				*			
Leaks & Tightness, Exhaust Sys.				*			
Disassemble Seawater Pump				*			
Leaks & Tightness, Cooling System				*			
Clean seawater section, cooling system				*			
Replace Coolant						*	
Lube U-joints				*			



## CHAPTER 7

---

### Engine

---

Each engine and stern drive package is unique and quite complex. A select portion of the maintenance items are covered in this chapter including general lubrication specifications and periodic maintenance. Because of the advanced ignition and fuel injection systems used on marine engines it is best to contact your Regal dealer for more of the detailed service procedures.



### CAUTION

AVOID ENGINE DAMAGE!  
FOLLOW ALL ENGINE BREAK-IN PROCEDURES  
AS RECOMMENDED BY THE ENGINE MANU-  
FACTURER. FAILURE TO FOLLOW THE BREAK-  
IN PROCEDURE MAY VOID THE ENGINE AND  
STERN DRIVE WARRANTY.



### CAUTION

AVOID ENGINE DAMAGE!  
DO NOT RUN ENGINE AT A CONSTANT RPM  
FOR PROLONGED PERIODS OF TIME DURING  
BREAK-IN PERIOD. CHECK ENGINE OIL OFTEN.



### CAUTION

AVOID ENGINE DAMAGE!  
DO NOT RUN ENGINE OUT OF WATER UNLESS  
YOU HAVE AN OPTIONAL FLUSHETTE.  
FOLLOW MANUFACTURER'S ATTACHING &  
RUNNING INSTRUCTIONS.



## *Cosmetic Care & Maintenance*

---

### **Recommended Lubricant Specifications**

#### **Volvo Engine Oil Requirements**

Due to recent EPA mandates on internal combustion engines new units are built with catalytic convertors installed in the exhaust manifolds, along with a system of sensors and computer controls. These newer engines require special oil requirements to extend the life of the catalysts.

Refer to the Volvo engine operator's manual for the correct oil requirements for catalyst type engines, or contact your nearest Regal or Volvo dealer for further information.

For other engines not manufactured as catalyst engines refer to your engine operator's manual for correct oil recommendations.






## CHAPTER 7

---

### Volvo Engine

#### *Checking the Engine Oil*

Before adding oil refer to the Volvo engine operator's manual for oil viscosity and type or contact your closest Regal or Volvo marine authorized dealer.



1. To properly check the dipstick (A) oil level run the engine to normal operating temperature and wait about 5 minutes.

2. The oil must be between the B & C marks on the dipstick. Add the recommended oil to maintain the proper level. Make sure you

use the correct oil for non catalyzed or catalyzed engines depending on the age of the vessel.

3. Recheck the engine oil dipstick level.

**Note: Refer to your Volvo engine owner's manual for adding any oil during the break-in period since special blends are required.**

*Note: All fluid recommendations are based on this manual's printing date. Regal is not responsible for the accuracy of the information since it can change at any time. For more detailed information and procedures check your engine operator's manual or contact your closest authorized Regal dealer.*




## Cosmetic Care & Maintenance

### NOTICE

**PREVENT ENGINE DAMAGE!**  
DO NOT ALLOW THE CRANKCASE OIL LEVEL TO RECEDE BELOW THE ADD MARK, AND DO NOT FILL ABOVE THE FULL MARK. OVERFILLING RESULTS IN REDUCED ENGINE LIFE, HIGH OPERATING TEMPERATURES, FOAMING & LOSS OF POWER.

#### *Checking the Power Trim/Tilt Fluid Level*



1. At least once annually preferably at the start of the boating season check the system fluid level. Begin with the stern drive trimmed in (down) as far as possible.
2. Remove the fill cap on the power trim pump reservoir.
3. Check the fluid level. It should be between the minimum and maximum marks on the reservoir.
4. Add Volvo Penta DuraPlus Power Trim/Tilt and Steering Fluid as required.
5. Replace the fill cap and tighten cap securely.



## CHAPTER 7

---

### *Checking Power Steering Fluid*

1. Check the power steering fluid before each boating outing. Remove the steering reservoir and check the fluid level. If the engine has not been running use the “COLD” mark. Use the “HOT” mark for engines that have been running at normal operating temperature as indicated by the temperature gauge.
2. The fluid should be between the minimum and maximum marks on the dipstick. If needed, fill to the proper level with Volvo Penta Dura Plus Power Trim/Tilt & Steering Fluid. DO NOT OVERFILL THE STEERING PUMP RESERVOIR.



### **CAUTION**

PREVENT STEERING OPERATION IMPAIRMENT  
OR COMPONENT DAMAGE!  
NEVER FILL THE POWER STEERING SYSTEM  
WITH AN UNKNOWN OIL.

3. Replace the fill cap and tighten securely.


### **NOTICE**

HELPFUL HINT:  
TO FILL TRIM, CRANKCASE & POWER STEERING  
LEVELS WITHOUT SPILLING FLUID  
PURCHASE A FUNNEL AT AN AUTOMOTIVE  
STORE WITH A LONGER NECK THAT WILL FIT THE  
RESERVOIR OPENINGS.



## Cosmetic Care & Maintenance

### Volvo Stern Drive



## CAUTION

FULLY THREAD OIL DIPSTICK INTO THE OIL LEVEL HOLE IN THE DRIVE UNIT TO PROPERLY CHECK THE OIL LEVEL. IMPROPER OIL LEVELS MAY RESULT IN SERIOUS STERN DRIVE COMPONENT DAMAGE.

It is recommended to check the drive oil level on a weekly schedule. Fully thread the dipstick into the hole. At this point, remove the dipstick and make sure the oil level is at the top of the mark as shown above. If the oil level is low, add enough oil to bring the level to the top of the mark on the dipstick. **DO NOT OVERFILL.** Tighten up the dipstick with a slotted screwdriver.

If the oil color is milky in appearance there probably is water in the unit normally caused by a leaking seal.

No metal flakes should be present in the oil. If the above conditions exist contact a Regal dealer.



## CHAPTER 7

---

### **MerCruiser Engine**

#### *Checking Engine Crankcase Oil*

1. Before adding oil make sure it is the type recommended for the type of engine installed. Consult your MerCruiser engine operator's manual. Check the engine oil by first allowing the engine to warm up. Stop the engine and allow about 5 minutes for the oil to drain to the oil pan to obtain an accurate reading.
2. Remove the dipstick. Wipe it clean and reinstall it into the dipstick tube. Wait 1 minute to allow any trapped air to vent. ( Install dipstick with oil indication marks facing the flywheel end of the engine. Add engine oil type and viscosity as recommended in the engine operator's manual. to the full or OK points on the oil dipstick.  
**DO NOT OVERFILL!**
3. Remove the dipstick and look at the oil level. Level must be between full or OK range and add. Reinstall dipstick into the tube.
4. When checking or filling the engine crankcase oil ensure that the vessel is level in the water or on a trailer.

For changing the engine oil & filter see the MerCruiser maintenance schedule and operation manual or contact your Regal dealer.

*Note: Above are basic recommendations. Regal is not responsible for the accuracy of the information since it can change at any time. For more detailed information and procedures check your engine operators manual or call your closest Regal dealer.*



## *Cosmetic Care & Maintenance*

---

### *Changing Engine Crankcase Oil*

Due to recent EPA mandates on internal combustion engines new units are built with catalytic convertors installed in the exhaust manifolds, along with a system of sensors and computer controls. These newer engines require special oil requirements to extend the life of the catalysts.

Refer to the MerCruiser engine operator's manual for the correct oil requirements for catalyst type engines, or contact your nearest Regal or MerCruiser dealer for further information.

For other engines not manufactured as catalyst engines refer to your engine operator's manual for correct oil recommendations.



## CHAPTER 7

### *Checking MerCruiser Stern Drive Oil*




## CAUTION

ENVIRONMENTAL HAZARD!  
DISCHARGE OF OIL OR OIL WASTE  
INTO THE ENVIRONMENT IS RESTRICTED BY  
LAW. DO NOT SPILL OIL OR OIL WASTE INTO THE  
ENVIRONMENT WHEN USING OR SERVICING  
YOUR VESSEL. DISPOSE OF OIL OR OIL WASTE  
AS DEFINED BY LOCAL & STATE AUTHORITIES.

1. Drive oil level must be checked with the engine cold before starting.
2. Check the gear oil level in the reservoir located on the engine. Keep the gear oil level at the recommended ranges as marked on the reservoir. If any water is visible at the bottom of the reservoir or there are any metal chips in the drive oil do not run the engine since component damage can result. Contact your Regal dealer for more information.

### *Filling the Stern Drive*



1. If more than 2 ounces of High Performance Gear Lubricant is required to fill the monitor reservoir a seal may be leaking. Contact your Regal dealer.
2. If drive lubricant is free from water and metal chips proceed to fill the reservoir. Remove the gear lube monitor cap. Fill the reservoir with High Performance Gear Lubricant (Merc part # 92-802854A1).

A=Drive Reservoir




## Cosmetic Care & Maintenance

3. Fill the reservoir so that drive oil level is in the operating range. Do not overfill reservoir. For changing the drive oil refer to the MerCruiser operation manual or contact a Regal dealer for more information.

### Checking Power Steering Fluid

1. Stop the engine and center the sterndrive unit.
2. Remove the combo fill cap/dipstick and observe the level.
  - a. Proper fluid level with engine at normal operating temperature should be within the warm range.
  - b. Proper fluid level with engine cold should be within cold range.
3. Fill to line with Quicksilver Power Trim & Steering Fluid (Merc # 92-802880A1) or Dextron III automatic transmission fluid. If you can not see any fluid in the power steering reservoir contact your Regal dealer since a leak must of developed in the system.







## CHAPTER 7

---

### *Checking Power Trim Fluid*



## CAUTION

ALWAYS CHECK THE OIL LEVEL  
WITH THE STERN DRIVE  
IN THE “FULL” DOWN OR “IN” POSITION.

1. Place the stern drive unit in the full down position.
2. Observe the oil level. Level must be between the “MIN” or “MAX” lines on the reservoir.
3. Fill as necessary with Power Trim & Steering Fluid (Merc part # 92-802880A1).

### *Refilling The Reservoir*

1. Remove the fill cap from the reservoir. Fill cap is vented.
2. Add lubricant to bring level to the within the “MIN” and “MAX” lines on the reservoir. Use Power Trim & Steering Fluid (92- 802880A1).
3. Install the cap.

### *Changing Power Trim Fluid*

1. Power steering fluid does not require changing unless it becomes contaminated with water or debris. Contact a Regal dealer to change the fluid.



## Cosmetic Care & Maintenance


### Checking Engine Coolant



## WARNING

AVOID BODILY INJURY!  
ALLOW ENGINE TO COOL DOWN BEFORE REMOVING THE COOLANT PRESSURE CAP. A SUDDEN LOSS OF PRESSURE COULD CAUSE HOT COOLANT TO BOIL AND DISCHARGE VIOLENTLY. AFTER THE ENGINE HAS COOLED, TURN THE CAP 1/4 TURN TO ALLOW PRESSURE TO ESCAPE SLOWLY, THEN PUSH DOWN AND TURN THE CAP COMPLETELY OFF.

1. Remove the cap from the heat exchanger and observe the level of the fluid.
2. The coolant level in the heat exchanger should be at the bottom of the filler neck. A low coolant level means you should contact your Regal dealer.
3. Install the cap onto the heat exchanger.
4. When reinstalling the pressure cap, be sure to tighten it until it seats on the filler neck.
5. With the engine at normal operating temperature, check the coolant level in the coolant recovery canister.






## CHAPTER 7


6. The coolant level should be between the “ADD” and “FULL” marks.

7. Add Extended Life Antifreeze/Coolant (Mercury part # 92-877770K1).

	<b>CAUTION</b>
<p>AVOID ENGINE DAMAGE! DO NOT USE ALCOHOL OR METHANOL BASED ANTIFREEZE OR PLAIN WATER IN THE COOLANT SECTION OF THE <b>CLOSED COOLING SYSTEM</b> AT ANY TIME.</p>	

<b>NOTICE</b>
<p>ADD COOLANT ONLY WHEN THE ENGINE IS AT A NORMAL OPERATING TEMPERATURE.</p>

### *Filling Engine Coolant*



1. Remove the fill cap from the coolant recovery canister.

2. Fill to the “FULL” line with Extended Life Antifreeze/Coolant Mercury part # 92-877770K1.

3. Reinstall the cap onto the coolant recovery canister.

### Changing Engine Coolant

Call your Regal dealer to change coolant in the entire system.

# Troubleshooting

The following diagnostic information will assist you in identifying minor electrical, fuel, and mechanical problems. Some of the items listed require technical training and tools. Additional assistance is available in the engine manufacturer's owner's manual. Also, you can contact your closest Regal dealer or marine professional for more information. Most defects can be found by doing a logical sequence of elimination.



## WARNING

PREVENT INJURY OR DEATH! USE ONLY APPROVED MARINE REPLACEMENT PARTS THAT ARE IGNITION PROTECTED.



## WARNING

PREVENT INJURY OR DEATH! BEFORE PERFORMING ANY MAINTENANCE WORK, TURN OFF THE BATTERY SWITCH AND REMOVE THE IGNITION KEY FROM THE SWITCH.

## Chapter 8

---

ENGINE & STERN DRIVE DIAGNOSTIC CHART	
Problem	Possible Cause
Engine Overheating	Water pick-up feeds are blocked by debris  Cooling system drain plugs not installed  Cooling system leak  Impeller is damaged or blocked by debris  Propeller is over propped for the circumstances, causing the engine to work extra hard  Debris in oil is holding heat more than normal - bad oil filter  Bad thermostat or gauge  Raw water cooling system has corroded from raw water left in the system
Low Oil Pressure	High oil level  Low oil level  Oil system leak  Drive oil sensor not reset at last oil change  Increased engine temperature (see engine overheating)
Engine Will Not Crank	Binnacle control lever not in neutral  Emergency stop switch activated

# *Troubleshooting*

<b>ENGINE &amp; STERN DRIVE DIAGNOSTIC CHART</b>	
<b>Problem</b>	<b>Possible Cause</b>
	Battery switch turned off  Battery is weak  Fuses are blown on the engine  Bad ignition relay / ignition switch
Engine Cranks But Will Not Start	Fuel tank vent obstructed  Low battery level  Inadequate fuel level  Inadequate fuel pump pressure  Fuel tank vent blocked  Water in fuel  Spark plugs have a bad gap  Distributor malfunction
Hard Starting	Flooded Engine  Fuel lines obstructed  Water in fuel  Debris in fuel - bad fuel filter
Engine Runs Rough	Bad fuel quality  Inadequate fuel pump pressure  Water or debris in fuel

## Chapter 8

---

ENGINE & STERN DRIVE DIAGNOSTIC CHART	
Problem	Possible Cause
	Manifold vacuum leak
Stern Drive Groans	Not enough lubricant on drive shaft or in drive  Bad gimbal bearing due to water in bellows  Poor engine alignment
Excessive Vibration	Drive prop was grounded, bent, or destroyed  Engine mounts loose / broken  Bad oil quality / type  Distributor cap / rotor corroded  Loose serpentine belt  Bad alignment
Water In Oil / Power Trim / Power Steering Fluid	Could be any number of problems - Contact your Regal dealer

# *Troubleshooting*

<b>CONTROL SYSTEM DIAGNOSTIC CHART</b>	
<b>Problem</b>	<b>Possible Cause</b>
No Reading On Gauge or Gauge Is Inaccurate	Faulty gauge  Faulty wiring to gauge  Faulty sender
Gauge Reads Erratic	Loose ground or hot wire connection
Binnacle Control Lever Stiff / Inoperative / Stalls When Shifting	Shift system bushings and seals broken  Kinked, broken, damaged cable  Friction brake is too tight and must be loosened  Control box jammed
Depth Gauge Inaccurate	Blocked transducer sight hole  Bad gauge  Bad transducer
Stern Drive Trim Not Functioning	Bad motor in trim control unit  Faulty wiring  Water in bellows / power trim fluid
Steering System Not Functioning	Uneven load  Poorly lubricated steering system  Lack of power steering fluid  Kinked, broken, damaged cable



## Chapter 8

---

ELECTRICAL SYSTEM DIAGNOSTIC CHART	
Problem	Possible Cause
No 12 Volt Power At Battery	Battery switch turned off  Weak or dead battery  Battery cables disconnected from storage  Bad voltmeter or voltmeter connection
Battery Not Charging While Engine Is Running	Loose / damaged serpentine belt  Faulty alternator - check with volt meter  Faulty volt meter
Battery Will Not Hold Charge	Faulty / old battery
12 Volt Equipment Not Working	Fuse blown - investigate why the equipment was drawing too much current or why it had a circuit short. Check fuses in dash fuse box, underneath the dash, and in the engine compartment  Weak or dead battery if all 12v equipment fails to function  Corroded / loose wire connection  Internal equipment short / failure

# *Troubleshooting*

<b>BILGE &amp; DRAINAGE SYSTEM DIAGNOSTIC CHART</b>	
<b>Problem</b>	<b>Possible Cause</b>
Bilge Pump Not Functioning Automatically	<p>Float switch jammed - check for debris</p> <p>Automatic bilge pump fuse blown - investigate why the equipment was drawing too much current or why it had a circuit short</p> <p>Battery connection corroded</p> <p>Impeller is damaged or blocked by debris</p> <p>Bad bilge pump motor</p> <p>Bilge pump discharge hose blocked</p>
Bilge Pump Not Functioning Manually	<p>Battery switch turned off</p> <p>Bilge pump dashboard fuse blown - investigate why the equipment was drawing too much current or why it had a circuit short</p> <p>Battery connection corroded</p> <p>Bad bilge pump switch</p> <p>Impeller is damaged or blocked by debris</p> <p>Bad bilge pump motor</p> <p>Bilge pump discharge hose blocked</p>

## Chapter 8

---

STEREO DIAGNOSTIC CHART	
Problem	Possible Cause
No Power At Stereo	Battery switch turned off  Fuse is blown - investigate why the equipment was drawing too much current or why it had a circuit short. Check ignition panel breaker, memory fuse in engine compartment, memory fuse underneath dash, and ignition protection fuse underneath dash  Water in unit
Stereo Will Not Play	Water in unit  Radio Signal Unavailable  Bad antenna  Mode selection isn't correct
Stereo Memory Lost	Stereo memory fuse in engine compartment or underneath dash is blown - investigate why the equipment was drawing too much current or why it had a circuit short
No Output Sound / Volume Is Low / Sound Is Distorted	Balance and max volume settings are limiting the speaker volume - adjust zone settings and setup settings  Rotary encoder malfunction  Loose speaker wire  Water in speakers
Added Performance Package Speakers Working Only	Amplifier fuse blown - investigate why the equipment was drawing too much current or why it had a circuit short

# *Troubleshooting*

<b>STEREO DIAGNOSTIC CHART</b>	
<b>Problem</b>	<b>Possible Cause</b>
	Standard zone max volume settings are low  Loose speaker wire connections  Water in cockpit speakers
Standard Speakers Working Only	Added speaker zone max volume settings are low  Loose speaker wire connection  Water in bow speakers
iPod Not Working	iPod not plugged in properly using appropriate sleeves  iPod mode not selected  Internal iPod problem
LCD Screen Not Displaying	Water in unit



## Chapter 8

---

### AUDIBLE ALARMS

It is important to read the engine owner's manual to diagnose engine alarms and faults. Depending on the propulsion package you chose to equip on your Regal, alarm sounds can vary.

On your Regal boat, your engine sounds an alarm in the case of one of the following causes:

- Low Oil Pressure
- Engine Overheating

To quickly diagnose these problems, look at the multi-gauge equipped on your vessel. Monitor the oil pressure gauge and temperature gauge, and troubleshoot accordingly. Be weary of faulty gauges however, and investigate the problem at the engine.



## *Storage & Winterization*

Storage procedures are outlined in this chapter. These are **general guidelines** to follow before longer periods of storage such as over the winter in colder climates. Be sure to familiarize yourself with all relevant information in the owner's pouch. Special winterization procedures are necessary for the boat equipment and systems. Use the enclosed checklists to help you identify areas of concern and maintenance. These lists cover land stored boats either inside or outside. Call a Regal dealer or marine professional for further information.



### **WARNING**

EXPLOSION, FIRE AND POLLUTION HAZARD!  
DO NOT FILL FUEL TANK TO RATED CAPACITY  
LEAVE ROOM FOR EXPANSION.



### **CAUTION**

REMOVE BATTERY(IES) WHEN VESSEL  
IS IN LONG PERIODS OF STORAGE.



### **CAUTION**

TO PREVENT ENGINE DAMAGE!  
USE ONLY ETHYLENE GLYCOL BASE ANTIFREEZE.  
DO NOT USE ALCOHOL BASE PRODUCTS.



## CHAPTER 9

---

### DECOMISSIONING CHECKLIST

#### ENGINE

- ☐ Run engine. Pour a fuel stabilizer/conditioner in the fuel tank. Allow time for it to circulate through the fuel system.
- ☐ Change all engine fluids as referenced in the engine manufacturer's owners manual. Contact a Regal dealer.
- ☐ Drain cooling and exhaust system or have a marine professional "pickle" the engine. Contact a Regal dealer.
- ☐ Spray all exterior parts with a rust preventative.

#### STERN DRIVE

- ☐ Remove drive. Perform maintenance as referenced in the manufacturer's owners manual. Contact your Regal dealer.
- ☐ Remove propeller. Refurbish as needed.
- ☐ After cleaning touch up paint on stern drive as needed.
- ☐ Apply coat of wax to stern drive.

#### BOAT

- ☐ Check hull bottom for any fiberglass damage.
- ☐ After cleaning apply a coat of wax to hull and deck surfaces.
- ☐ Pour a pint of 50/50 antifreeze into bilge pump.
- ☐ *Never block up boat bottom. May cause structural damage.*



## *Storage & Winterization*

---

- ☐ Remove battery. Use a trickle charger as needed.
- ☐ Remove all loose gear and electronics from boat. Inspect all equipment for wear and damage. Store in a clean, dry environment.
- ☐ Remove drain plug. Clean drain plug hole of debris as needed. Enclose drain plug in plastic bag and tie to steering wheel.
- ☐ Make sure bow is higher than stern to permit proper drainage.
- ☐ Clean all upholstery and store so it breathes.
- ☐ Conduct a visual inspection to ensure boat is balanced properly on the trailer, cradle or blocks.
- ☐ Cover boat with appropriate cover. Tie down for protection from rain, snow and/or wind. Prop up cover to provide proper ventilation. Do not cover up the fuel vents.
- ☐ Drain the fresh water system per instructions in this chapter.

### **TRAILER**

- ☐ Repack all wheel bearings per manufacturer's specifications.
- ☐ Check all trailer parts for excessive wear. Replace/refurbish as needed.
- ☐ Use touch up paint on trailer as needed.
- ☐ Lubricate all moving parts as needed.
- ☐ Check all lighting and brakes (if applicable).





## CHAPTER 9

---

### FRESH WATER SYSTEM

1. Activate the fresh water pump switch.
2. Open all faucets including transom shower (if equipped) and allow tank to empty.
3. Drain the water tank. Shut off fresh water pump switch.
4. Mix nontoxic antifreeze with water in accordance with the manufacturer's recommendations. (Available at marina & RV stores)
5. Pour solution into the fresh water tank.
6. Turn on fresh water pump switch.
7. Open water faucet and purge until a steady stream of nontoxic antifreeze flows from the faucet. If equipped, do the same to the transom shower. Turn the fresh water switch to the "off" position.

### WASTE SYSTEM

1. With **chemical** heads, make sure to dump both upper and lower tanks. Rinse well with fresh water.
2. With **vacuum designed** head, pump out holding tank. Add nontoxic antifreeze to toilet and holding tank. Pump from toilet to holding tank to eliminate any water remaining in supply lines.

## NOTICE

AVOID VESSEL AND ENGINE DAMAGE!  
CONTACT MARINE PROFESSIONAL FOR  
WINTERIZATION INSTRUCTIONS. DAMAGE IS  
NOT COVERED BY REGAL WARRANTY.



## *Storage & Winterization*

---

### **RECOMMISSIONING CHECKLIST**

#### **ENGINE/STERN DRIVE**

- ☐ Check all components per engine manufacturer's owners manual especially fluid levels.
- ☐ Run engine on "ear muffs" (flushette) before launching. Check for fuel, exhaust, oil, and water leaks.

#### **BOAT**

- ☐ Install drain plug.
- ☐ Install battery and tighten all terminals.
- ☐ Check all equipment, switches, alarms, gauges and breakers for proper operation.
- ☐ Add necessary chemicals and water to **chemical** head.
- ☐ Add water to fresh water tank. Turn on faucet to purge tank. Refill water tank.
- ☐ Make sure all safety gear is on board and in excellent working condition.
- ☐ After launching, check controls and gauges for proper operation.

#### **TRAILER**

- ☐ Make sure all equipment is in excellent working condition.



## CHAPTER 9

---

*Notes*



# Trailer

This chapter covers trailering/towing basics including equipment, maintenance, and techniques of using a trailer. *Check with state and local agencies for detailed information on required equipment, safety issues, and licensing.*

## BEFORE TOWING

Before towing your boat, be sure to check the air pressure of your tires for the recommended inflation rating. Also, be certain that your tow vehicle is in good working order.

Stow all gear to be carried properly, especially heavy items such as batteries or anchors. Be sure these items are secured. Don't overload and try to carry excessive weight on your trailer.

Give consideration to the weight distribution of your trailer. If the rear end of your vehicle sags, chances are the load is positioned too far forward on your trailer.


This can make it especially difficult to drive safely, as the hitch may be in danger of striking the road. Also, this situation can be caused by worn vehicle rear shock absorbers. One option is to install a set of air shocks which will assist in supporting the load. As a rule of thumb 5 to 7 percent of the total trailer load should be on the trailer tongue.

Check all lights to ensure they all work properly. You may find it helpful to ask someone to check your turn signals, brake lights, and towing lights while you remain in the vehicle. Be certain that the trailer winch cable is securely attached to the boat's bow eye and the cable lock is engaged. Make sure the bow of the boat is snug against the bow stop at the winch stand.




## CHAPTER 10

### TRAILER TERMINOLOGY



TYPICAL TRAILER SHOWN

## *Trailer*





## CHAPTER 10

---

It is a good idea to tie another line or secure an extra cable to the winch stand and boat bow eye as a backup system.

Be certain that your trailer is of rated capacity for the size and weight of your boat, including the weight for all fuel, water and gear. Your authorized Regal dealer can advise you on the proper trailer capacity and tongue weight ( the weight exerted on the rear of your vehicle).

Never use a bumper mounted trailer hitch. Always use a bolted or welded frame-mounted hitch, class 2 or 3. Consult your Regal dealer for more information.

Should your trailer be equipped with surge brakes, that is brakes on the trailer that cut in with a very slight delay when your brakes are applied, be sure to follow recommended service and maintenance instructions. Be sure that the trailer master cylinder is filled with the recommended fluid before towing your boat. Inspect the trailer brake lines for any leakage. Also, if you notice brake fluid on the inside of the tires, you may have a wheel cylinder leaking. Consult a professional.

Never place your hands between the trailer hitch coupling and the hitch ball on your towing vehicle while hooking up. Be sure the tongue jack is in the full up position before departure. Be certain safety chains are crisscrossed and secured; do not allow them to drag on the road.

Be sure to buy a suitable set of tie downs which can be attached to the boats' stern eyes and the eyelets provided on most trailers. Tighten them securely and neatly fold up the extra strap material and secure it with tape so it doesn't loosen and dangle on the road.

Check the trailer lug nuts for the proper torque. Use a foot pound wrench and torque in a star sequence to the correct poundage as recommended by the trailer manufacturer. Torque the lug nuts at half the poundage on all nuts. Then set the torque wrench to the full poundage and fasten to the last foot poundage figure.

Check the trailer tires often for voids, excessive wear or out of round tire conditions. If the trailer seems to vibrate you may have a bad tire or one that is unbalanced. These wheels can be rebalanced at most automotive or tire shops. Never pull a boat on a patched tire. Buy a spare tire and wheel including a hub and wheel bearing assembly. Mount it on the trailer for speedy installation should a blow out occur.

## **SPARE PARTS CHECKLIST**

Longer towing trips increase the need for special preparations. Sometimes these extended trips cover areas where it is difficult in locating repair parts due to a breakdown. Following is a checklist of recommended items to add a safety net to your trip.

### **Trailer-**

1. Trailer tire jack
2. Spare hub assembly including wheel bearings
3. Spare tire
4. Lug wrench
5. Jackstand
6. 12 volt air compressor- found at automotive box stores
7. Spare bearing protector
8. Extra tie-down straps
9. Trailer light bulbs
10. Brake pads and brake fluid
11. Grease gun

### **Tow Vehicle-**

1. Tool kit including necessary ratchet and sockets
2. Jumper cables
3. Extra fuses
4. Engine oil
5. Transmission fluid
6. Wheel chocks
7. Highway flares
8. 12 volt spotlight- type that plugs into 12 volt accessory outlet
9. Flashlight & spare batteries
10. Waterless hand cleaner and rags
11. Electrical connectors and crimpers
12. Low voltage electrical tester





## CHAPTER 10

---

Check the trailer harness often for signs of fraying. Check the harness connector for corrosion. Make sure the trailer harness when connected to the trailer has enough slack for turning.

Check the wheel bearings for wear periodically by a professional. On most trailers, there is a zerk fitting on the wheel hub to add the proper lubricant to the wheel bearing with a grease gun. These wheel bearing waterproof covers for the bearings can be purchased at retail outlets. Be sure everything is secured in the boat and canvas is down in the towing position with the bimini stored in the boot. Tilt the stern drive up to clear the road and any bumps that might occur while in transit.

### DRIVING

Practice maneuvering the vehicle and trailer in a large, empty parking lot or open space. If you practice slowly and cautiously, you will soon develop a feel for maneuvering the trailer.

Test your vehicle and trailer brakes before departure along with the lights. Pack a tool kit with extra bulbs, fuses and fluids.

Drive as smoothly as possible, anticipating your stops and giving yourself plenty of room for turning and stopping. Avoid any quick turns or sudden jerks of the steering wheel.

Remember to maintain safe speed limits. It takes longer to stop your loaded boat. Allow enough room to the front in bad weather.

Keep an eye on your rig through the rear view and side mirrors. If your rear view mirror is obstructed, purchase a set of side mirrors that extend out over the side of the vehicle for increased visibility. In addition, it is a good idea to install a set of round mirrors to the side mirrors as they help identify blind spots.

Plan to stop periodically on your way to check the trailer hitch for tightness, harness connector, tires and wheel bearings. Also, check to make sure the cockpit cover is secure and the load is balanced.

## LAUNCHING

Serious accidents can occur at the launching ramp. Therefore, it is imperative you be alert and attentive during launching and docking activities. Study the ramp area and surrounding water for any potential hazards, such as a short ramp or one with a drop off at the end. If you are uncertain of the conditions, ask someone else who has just used the ramp if there are any peculiarities to the area.

**Install the drain plug.** Attach 2 lines, one each at the bow and stern, to control your boat once it is off the trailer. If you need additional fenders to keep the sides of the boat from banging against the ramp walls, use those as well.

Unhook the stern tie-downs and the winch line to the bow. Unplug the trailer harness connector so the hot trailer light bulbs won't blow out when they come in contact with water.

When backing in, have someone assist, giving the palms up stop signal when the boat is in deep enough water to float off, or when the rear wheels of your vehicle approach the water's edge.

After your boat is floating freely, position it clear of the trailer before pulling out of the water. If there is no one to help you, secure one of the lines you've attached from the boat to the dock and use the other line to pull the boat off trailer. The process is easier with 2 people.



### CAUTION

AVOID LOSING VEHICLE TRACTION!  
DO NOT ALLOW REAR WHEELS TO ENCOUNTER  
SAND OR SLIPPERY CONCRETE CONDITIONS.




### WARNING

AVOID BODILY INJURY!  
RAMPS ARE VERY SLIPPERY. DO NOT ATTEMPT TO  
WALK OR STAND ON AN ANGLED BOAT RAMP.



## CHAPTER 10

### BACKING A TRAILER



A trailer backs in a direction opposite to an automobile. In 1, driver swings the rig near the launching ramp. In 2, the driver cuts the vehicle toward the driveway. In 3, the driver cuts the vehicle wheels to the left and then backs into the ramp as the trailer moves to the right. In 4, the driver straightens the vehicle wheels to follow the trailer as it backs down the ramp.

### NOTICE

ALLOW TRAILER WHEEL BEARINGS AND LIGHTS  
TO COOL BEFORE SUBMERGING

## LOADING



The most important thing to remember when pulling your boat out of the water is that often the ramp will be crowded. As you approach the ramp, make a visual inspection of the traffic and people, both at the ramp and all around you. This is an important time to use caution,

courtesy, and common sense. While you may feel it's your next turn, another boater may not be as courteous. Don't insist on your rightful place in line; it could lead to disastrous consequences in the confines of a crowded boat ramp. If there is any perceived danger, stand off until you can safely approach the ramp.

Back your trailer down to the water's edge. At this point it is a good idea to let a sufficient amount of line out of the winch to reach the bow eye. Make sure you disconnect the trailer harness to keep the bulbs from blowing out due them being subjected to the cold water.

On roller or bunk style trailers back up until the aft roller is just at the water level. This allows you to hook up the winch cable and to start cranking the boat on to the trailer properly. This method gives you a good starting point and helps keep the boat centered on the trailer as it is reloaded. It may be necessary to further back the trailer into the water. This permits cranking the boat easier on to the trailer.

Once the boat is positioned correctly on the trailer have someone hook up the winch cable hook to the bow eye. Also, this will help keep the boat bow against the trailer roller. Shut down the engine and run the stern drive up to the top of the trailer position.

With the bow snug against the roller, start to crank the boat up on to the trailer. Make sure the hull bottom or keel stays in the center of each roller as it is being cranked on the trailer. **Double check** to ensure the hitch is locked tight on the vehicle ball.



## CHAPTER 10

---

Make sure the boat is covered properly and all loose gear is stowed. On bunk style trailers, watch the bunks to make sure the boat is centered as they usually do not touch any rollers other than the aft one because the boat weight is being supported more by the bunks as it is cranked onto the trailer. Stop cranking the winch when the boat bow contacts the bow roller. Be sure the winch is in the locked position. Stand back and visually check to see that the boat is centered on the trailer. After pulling your boat away from the ramp, be sure to go through all the checks involved before departure. Reinstall the harness connector and check the lights, brakes, safety chain, winch, hitch, and tie downs. Remove the drain plug to exit any excess water in the bilge. Reinstall the hull drain plug and tighten it. For longer storage periods remove the drain plug and keep in a plastic bag tied to the steering wheel.



### WARNING

AVOID PERSON INJURY!  
DO NOT LET ANYONE STAND NEAR THE WINCH OR  
CABLE. THE CABLE COULD BREAK.



### CAUTION

HULL BOTTOM DAMAGE COULD RESULT  
FROM THE BOAT NOT BEING POSITIONED  
ON THE ROLLERS BUT RESTING  
ON THE TRAILER FRAME.  
AVOID BACKING TRAILER  
TOO FAR INTO THE WATER!



# Glossary & Index

Below is a brief list of nautical terminology. For more detailed glossaries we recommend you check your local library, book retailer, marine store or internet.

## GLOSSARY

**Abeam:** at right angles to the fore and aft line and off the boat

**Aboard:** on or in the boat

**Above:** the part of the boat on a vessel which is above the interior of the boat

**Aft, After::** aft is the boat section toward the stern or back of the boat

**Admidships:** toward the center of the boat from either side to side or rear to front

**Beam:** the width of a boat at its widest part

**Bilge:** the lower interior of the hull of the boat

**Bitter end:** the end of a line also the end of an anchor line

**Bow:** the front, or forward part of the boat

**Bulkhead:** the vertical partition or wall of a boat



## CHAPTER 11

---

**Cast off:** to let go or release

**Chine:** the line fore and aft formed by the intersection of the side and bottom of the boat

**Chock:** deck fitting used to secure or guide anchor or tie lines

**Cleat:** deck fitting with protruding arms around which lines are secured

**Cockpit:** the seating space used to accommodate passengers

**Cuddy:** a small cabin in the fore part of the boat

**Deck:** the open flooring surface on which crew and passengers walk

**Draft** the depth from the waterline of the boat to the lowest part of the boat, which indicates how much water is required to float the boat

**Fathom:** a measurement of depth; one fathom equals six feet

**Fender:** a cushion hung from the side of a boat to prevent it from rubbing against a dock or against other boats

**Fend off:** to push off to avoid sharp contact with dock or other vessel

**Fore:** the part of the boat toward the bow or front

**Freeboard:** the height of the top side from the waterline to the deck at its shortest point. (The distance from the sheer or gunwale to the water)

**Galley:** cooking area

**Gunwale:** rail or upper edge of the side of the boat

## *Glossary & Index*

---

**Head:** toilet

**Hull:** the part of the hull from the deck down

**Keel:** the lowest point of a boat; the backbone of the vessel

**Knots:** a measurement of speed indicating nautical miles per hour

**Lee:** the side opposite that from which the wind is blowing; the side sheltered from the wind

**Leeward:** the direction toward which the wind is blowing

**PFD:** personal flotation device; required for each person aboard

**Port:** the left side of the boat when facing forward (an easy way to remember the difference between “port” and “starboard” is that both “port” and “left” have four letters)

**Shank:** the main body of an anchor

**Sheer:** the curve of the boat’s deck from fore to aft when seen from the side

**Starboard:** the right side of the boat when facing forward

**Stern:** the aft end of the boat

**Stern drive:** an inboard/outboard (I/O) unit

**Stringer:** strengthening integral unit fastened from fore to aft inside the hull and fiberglass encapsulated for added strength: much like the skeleton system of our body

**Top off:** to fill up a tank

**Transom:** the vertical part of the stern





## CHAPTER 11

---

**Trim:** the boat's balance when properly loaded

**Wake:** the path of a boat left astern in the water

**Windward:** the direction from which the wind blows; opposite of leeward

# *Glossary & Index*

---

## INDEX

### A

Accidents	1-27
Accident Reporting	1-28
Alcohol	1-25
Anchor Light	1-16
Anchoring	5-24
Anchor Windlass	6-2
Audible Alarms	3-14
Audible Producing Devices	1-15
Automatic Fire Extinguisher	3-11
	6-3
	7-24

### B

Battery	4-1
	6-7
	7-17
Battery Switch	4-9
	6-8
Bilge Pump	4-6
	6-10
	7-21
Blower	4-7
	5-5
Bow Scuff Plate	5-12
Breakers & Fuses	4-8
Breast Lines	5-11
Bridge Clearance	2-10

### C

Canvas	6-14
	7-6
Carbon Monoxide	1-21
Capacity Plate	Int-14
Cardiopulmonary Resuscitation	5-29
Cockpit Carpet	6-20
Cockpit Table	6-21
Cockpit Refreshment Center	6-22
Cosmetics	7-1
Controls	3-6

### D

Dealer Responsibilities	Int-15
Depth Sounder	3-10
	6-24
Diagnostic Charts	8-1
Direct Current (DC)	4-1
Distress Signals	1-12
	1-13
Diver's Flag	1-29
Docking	5-15
Dock Lines	5-11
Drain Plug	6-23
Doors-Bow	6-13

### E

EPIRB	1-20
Electrical	4-1
	8-4
Emergencies	5-28
Engine	3-1
	7-11
	7-35
Engine Hatch	6-27
Engine Status Monitoring Panel	3-12
Environmental Awareness	5-31
Exhaust	1-21



## CHAPTER 11

---

### F

Fenders	5-10
Fiberglass Maintenance	7-3
Fire Extinguishers	1-10
	6-3
	7-24
First Aid	5-29
Float Plan	Int-9
Fresh Water System	4-15
	6-28
Fuel	4-2
	5-3
	7-21
	8-3

### G

Galvanic/Stray Current Corrosion	7-25
Garbage Placard	1-18
Gas Vapor Detector	6-30
Gathering Headway	5-16
Gauges (Instrumentation)	3-8
Gelcoat Maintenance	7-3
General Boating Safety	1-3
Getting Underway	5-1
Glossary	11-1
Gray Water	6-33
Grill	6-33

### H

HIN	Int-9
Horn	1-19
	4-7
Hour Meter	3-8
Hull Bottom	7-9
Hypothermia	5-30

### I

Ignition Switch	3-15
Index	11-5
Interior Fabrics	7-3
International Distress Signals	1-14
Interrupt Switch/Lanyard	3-18

### K

Knots	5-27
-------	------

### L

Labels	1-1
Ladders	6-34
Law of Salvage	5-26
Lighting	6-36
Loading	Int-14
	5-21
Launch & Cruise Checklist	Int-12

### M

Maneuvering	5-16
Maintenance Guides	7-30
Maintaining PFD'S	1-9
Masthead Light	1-16
	1-19
Mayday	1-15
MerCruiser	7-15
	7-32
	7-40
Metal (Cleaning)	7-9
Minimum Required Equipment	1-19
Mirror-Wide Angle	6-103
Mooring	5-12

## *Glossary & Index*

---

### **N**

Navigation Aids	2-6
Navigation Lights	1-15
	1-19
Navigation Rules	2-1
Neutra-Salt System (Volvo)	6-44
Neutral Safety Switch	3-16
New Boat Delivery Checklist	Int-17
Night Running	2-9

### **O**

Oil Pressure Gauge	3-8
Oil Spills	1-17
Overloading	Int-14
Owner's Information Packet	Int-8
Owner's Registration	Int-15
Owner Responsibilities	Int-15

### **P**

Personal Flotation Devices	1-7
	1-19
Plastics	7-2
Power Tower	6-39
Power Trim	5-19
Precautionary Safety Labels	1-2
Pre-departure questionnaire	5-1
Propellers	7-11
	8-3
Propulsion	3-1
Pump Out Fittings/Waste	6-99

### **R**

Recommissioning	9-5
Regal Vue	6-43
Registration Information	Int-19
Remote Control	3-16
	5-7
	7-19
	8-2
Right-Of-Way	2-2
Rules Of The Road	2-1

### **S**

Safety	1-1
	Int-14
Seating-	6-11
	6-68
Shallow Water Operation	5-22
Sirius Satellite Radio	6-73
Ski Pylon	6-74
	6-81
Specifications	Tech
Speed Control Devices	6-75
Speedometer	3-10
Spring Line	5-11
Starting & Stopping	5-6
Stern Line	5-11
Steering	5-8
	7-16
	7-26
Stereo	6-76



## CHAPTER 11


---

Stern Drive	3-2	<b>V</b>	
	3-13		
	5-14	Ventilation	1-22
	5-16		3-2
	7-11		5-6
	7-31	Visibility	2-9
	7-39		5-23
	9-2	Visual Distress Signals	1-12
	9-5	Volt Meter	3-9
Sunbrella Cleaning	7-7	Volvo	7-13
Swim Platform	6-89		7-30
Switches (DC)	4-4	Volvo Engine Alarm	3-14
<b>T</b>			
Tachometer	3-8		
Table/Cockpit	6-21	<b>W</b>	
Technical	12-1		
Temperature Gauge	3-9	Wake	1-33
Toilet	4-15	Warning Labels	1-1
	6-91	Washdowns	6-101
Towing	5-25	Warranty	Int-18
Trailer	10-1	Waste System	4-7
Trailer Switch	6-99	Water Skiing	1-29
Trim Angle	5-19	Water System	4-6
Trim Gauge	3-10	Weather	1-34
Through-Hull Exhaust	6-100	Windshield-Center Latch	6-102
Troubleshooting	8-1	Winterizing	9-1
Turning	5-17	Wiring Color Codes	4-2
<b>U</b>		<b>Z</b>	
Upholstery	7-1	Zinc Anodes	7-25



# Technical Information

## NOTICE



The following technical information and drawings are accurate up to the printing date listed at the beginning of this manual. These drawings can be an aid to troubleshooting electrical and mechanical problems along with the charts located in the troubleshooting chapter.

**Note that all product specifications, models, standard and optional equipment, systems, along with the technical information is subject to change without notice.**


For more information contact your nearest authorized Regal dealer. For the location of your nearest authorized dealer call 407-851-4360. or visit the web-site at [www.RegalBoats.com](http://www.RegalBoats.com).

Your Regal dealer has received special factory training on the entire product line and his services should be employed to solve technical problems.



---


## 24 & 27 FASDECK TYPICAL DOMESTIC COMPLIANT FUEL SYSTEM





## Technical Information

### 24 & 27 FASDECK TYPICAL WATER/WASTE SYSTEM



\*SOME ITEMS SHOWN ARE  
OPTIONAL EQUIPMENT












<b>24 FasDeck Specifications</b>		
LENGTH OVERALL W/ PLATFORM	USA 24'3"	CE 7.3 M
CENTERLINE LENGTH	22'4"	6.8 M
BEAM	8' 6"	2.5 M
DEADRISE	20 DEGREES	
APPROXIMATE DRY WEIGHT W/ VOLVO 5.0 L CATALYST W/DP STERN DRIVE	4320 LBS.	1714.5 KG
TOP UP-BRIDGE CLR.	7'	2.1 M
TOP DN-BRIDGE CLR.	4' 10"	1.4 M
APPROXIMATE BRIDGE CLEARANCE TO TOP OF POWER TOWER LT.	7' 10"	2.38 M
APPROXIMATE BRIDGE CLEARANCE W/ TOWER IN LOW- ERED FORWARD POSITION	Note: Add 8" more to this measurement for factory wake board racks.  5' 4"	Note: Add .2 M more to this measurement for factory wake board racks.  1.6 M
COCKPIT DEPTH	35 1/4	.89 M
APPROXIMATE DRAFT- DRIVE UP/ DOWN	18"-34"	.45-.86 M
FUEL CAPACITY	54 GALS EST.	204 L
WATER CAPACITY	11	41 L
APPROXIMATE WASTE CAPACITY	2.5 Est. Gallons w/ Chemical Toilet	9.4 Est. L w/ Chemical Toilet
PERSONS CAPACITY	13	8
MAXIMUM CAPACITY; PERSONS & GEAR	1810 LBS.	N/A
MAXIMUM LOAD RECOMMENDED; PERSONS & GEAR	N/A	769 KG




## Technical Information

27 FasDeck Specifications		
LENGTH OVERALL W/ PLATFORM	USA 27' 3"	CE 8.3 M
CENTERLINE LENGTH	25' 3"	7.7 M
BEAM	8' 6"	2.5 M
DEADRISE	21 DEGREES	
APPROXIMATE DRY WEIGHT W VOLVO 5.7 L CATALYST W/DP STERN DRIVE	5350 LBS.	2426.7 KG
TOP UP-BRIDGE CLR.	7'	2.1 M
TOP DN-BRIDGE CLR.	4' 10"	1.4 M
APPROXIMATE. BRIDGE CLEARANCE- TOP OF POWER TOWER LT.	7' 10"	2.38 M
APPROXIMATE. BRIDGE CLEARANCE W/ TOWER IN LOW- ERED FORWARD POSITION	6' 3"	1.98 M
COCKPIT DEPTH	35 1/4"	.89 M
APPROXIMATE. DRAFT- DRIVE UP/ DOWN	18"-34"	.45-.86 M
FUEL CAPACITY	74 GALS EST.	280 L
WATER CAPACITY	11	41 L
APPROXIMATE WASTE CAPACITY	2.5 Est. Gals. w/ Chemical Toilet	9.4 Est. L w/ Chemical Head
PERSONS CAPACITY	YACHT CERTIFIED	12
MAXIMUM LOAD RECOMMENDED; PERSONS & GEAR	N/A	1102 KG









24-27 HULL HARNESS ROUTING


24FD DECK - 01 25 11




24-27 DECK HARNESS





24-27 DECK HARNESS ROUTING













24 COMPONENT LAYOUT 1





24 COMPONENT LOCATIONS